



Spare parts for:

**Cooking equipment**



# Knobs

- Replacement dials for knobs
- Dials



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.  
Updates will be issued in case of additions  
and/or amendments.





# Knobs



## UNIVERSAL KNOBS



Photo	LF Code No.	Type	Hole	∅ (mm)
A	3241400	Manopola universale	a mezzaluna 10x8 mm	70
A	3241401	Manipola universale	a mezzaluna 8x6,5 mm	70
A	3241402	Manopola universale	a mezzaluna 6x4,6 mm	70
B	3241450	Disco autoadesivo con simbolo pilota	---	63
C	3241451	Disco autoadesivo senza simbolo pilota	---	63
D	3241452	Disco autoadesivo 1-2-3-4-5-6-7-8	---	63
E	3241453	Disco autoadesivo 1-2-3-4-5-6-7-8	---	63
F	3241454	Disco autoadesivo 30-90°C	---	63
G	3241455	Disco autoadesivo 30-90°C	---	63
H	3241456	Disco autoadesivo 30-110°C	---	63
I	3241457	Disco autoadesivo 30-110°C	---	63
J	3241458	Disco autoadesivo 100-180°C	---	63
K	3241459	Disco autoadesivo 50-250°C	---	63
L	3241460	Disco autoadesivo 50-300°C	---	63
M	3241461	Disco autoadesivo 50-300°C	---	63
N	3241462	Disco autoadesivo 50-320°C	---	63
O	3241463	Disco autoadesivo con simbolo freccia	---	63
P	3241464	Disco autoadesivo min/max	---	63
Q	3241465	Disco autoadesivo 0-1-0-1	---	63
R	3241466	Disco autoadesivo 0-1-2-3	---	63
S	3241467	Disco autoadesivo 0-1-2-3-4-5-6	---	63




# Knobs



Suitable for:

**3241927 ADHESIVE DISK 0-1-2-3**  
external  $\varnothing$  70 mm



GIGA Y65011

Suitable for:

**3241382 BLACK ADJUSTING KNOB**  
D-shaped hole 6x4.6 mm



INNOVA

**3241247 BLACK KNOB**  
round hole  $\varnothing$  6 mm  
for Fryer electric (TECNOINOX) FR35E - FR70E



ALPENINOX 004906

ELECTROLUX 004906

MBM RTCU700413

TECNOINOX RC00329000

ZANUSSI 004906

**3241271 BLACK KNOB**  
round hole  $\varnothing$  10 mm



GICO 3336019200

GICO 760308790

GICO 790305070

**3241275 BLACK KNOB**  
square hole: 7x7mm  
for Pasta cooker (MARENO) CP9



MARENO MA32000599

MARENO 32000599

**3241678 BLACK KNOB**  
round hole  $\varnothing$  6 mm  
for Fryer gas (FRYMASTER) J1C - MJCF - MJCFE  
MJ15 - MJ35 - MJ40 - MJ41 - MJ45 - MJ50



FRYMASTER 8060047

FRYMASTER 8100110

FRYMASTER 8101720

GARLAND F8100110

GARLAND 810-0110

**3241727 BLACK KNOB**  
D shaft hole 6x4,6 mm  
for thermostat



MORICE DM1155

MORICE DM1155-1

**3241728 BLACK KNOB**  
square hole 7x7 mm  
for GAS TAP



MORICE DM1155-2

MORICE DM1155/2

**3241733 BLACK KNOB**  
square hole 7x7 mm  
for GAS VALVE



MORICE DM1152

MORICE DM1152-1

**3241749 BLACK KNOB**  
D shaft hole 10x8 mm  
for gas tap PEL 22-23  
for Boiling pan (THIRODE)



THIRODE 132744



Suitable for:

# Knobs



**3241755 BLACK KNOB**  
square hole 5x5 mm  
for selector switch



BOURGEOIS MAN3007

SOLYMAC P72Q

**3241788 BLACK KNOB**  
D shaft hole 6x4,6 mm  
for Kitchen electric (AMBASSADE) CFE705RT  
CFE714RT



AMBASSADE 65044000

AMBASSADE 88044000

**3241701 BLACK KNOB  $\varnothing$  24 mm**  
D-shaft hole 6x4.6 mm  
for POTENTIOMETER



LINCOLN 369248

**3241699 BLACK KNOB  $\varnothing$  28 mm**  
round hole  $\varnothing$  6 mm



LINCOLN 369429

**3241348 BLACK KNOB  $\varnothing$  28 mm 1-10**  
D shaft hole 6x4.6 mm  
for Food-service trolley (BLANCO) SAG - SAW - STW



BLANCO 146654

**3241429 BLACK KNOB  $\varnothing$  30 mm SILK-SCREEN PRINTED**



ALPENINOX 003704

ELECTROLUX 003704

ZANUSSI 003704

**3241189 BLACK KNOB  $\varnothing$  32 mm**  
for Oven under cooktop gas (ZANUSSI) - Series N700  
Series N900  
for Pot stove gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0190

ELECTROLUX 0C0190

ZANUSSI 0C0190

**3241190 BLACK KNOB RING NUT 110-270°C**  
for Pot stove gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0194

ELECTROLUX 0C0194

ZANUSSI 0C0194

**3241356 BLACK KNOB  $\varnothing$  37 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Food-service trolley (RIEBER) BKW



RIEBER 33353024

**3241768 BLACK KNOB  $\varnothing$  37 mm 60 MINUTES**  
D-shaft 6x4.6 mm  
external dimensions of the dial 70x70 mm





# Knobs



Suitable for:

**3241249 BLACK KNOB  $\varnothing$  39 mm**  
D shaft hole 6x4.6 mm  
for Fryer (GIORIK)



EMMEPI 813429

GIORIK 5900198

Suitable for:

**3241698 BLACK KNOB  $\varnothing$  39 mm**  
round hole  $\varnothing$  6 mm



LINCOLN 369804

**3241240 BLACK KNOB  $\varnothing$  39 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Toaster (TECNOINOX)



TECNOINOX RC00001113

**3241243 BLACK KNOB  $\varnothing$  39 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Salamander (TECNOINOX) SE - SEF - SEL



ALPENINOX 003029  
ZANUSSI 003029

ELECTROLUX 003029

TECNOINOX RC00006301

**3241161 BLACK KNOB  $\varnothing$  40 mm**  
D shaft hole 6x4.6 mm  
for Panini grill (ARISTARCO) ORION



ARISTARCO 3345

ARISTARCO 621

**3241258 BLACK KNOB  $\varnothing$  40 mm**  
D shaft hole 6x4.6 mm  
for Pot stove gas (LOTUS) - Series 600



LOTUS 536002500

**3241357 BLACK KNOB  $\varnothing$  40 mm**  
D-shaped hole 6x4.6 mm



EMMEPI 809928

FB FABA PR10008

FIMAR CO1947

**3241392 BLACK KNOB  $\varnothing$  40 mm**  
D shaft hole 6x4.6 mm



MODULAR RRC5385-00  
WHIRLPOOL 771985010288

WHIRLPOOL F50119

WHIRLPOOL 483286008204

**3241515 BLACK KNOB  $\varnothing$  40 mm**  
D shaft hole 6x4.6 mm



ROLLER GRILL A14042

**3241611 BLACK KNOB  $\varnothing$  40 mm**  
D shaft hole 6x4.6 mm  
for Fryer (FRI FRI) - Series ECO



FRI FRI 400769



Suitable for:

# Knobs



## 3241547 BLACK KNOB $\varnothing$ 40 mm SCREENPRINTED

D-shaped hole 6x4.6 mm  
for Pot stove (LOTUS) - Series 600



LOTUS 536002501

Suitable for:

## 3241548 BLACK KNOB $\varnothing$ 40 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for Pot stove (LOTUS) - Series 600



LOTUS 536002000

## 3241183 BLACK KNOB $\varnothing$ 40 mm 0-1-2-3-4-5-6

D shaft hole 6x4.6 mm  
for Pot stove electric (LOTUS) - Series 600



LOTUS 536002100

## 3241224 BLACK KNOB $\varnothing$ 40 mm 0-300°C

D shaft hole 6x4.6 mm  
for Bratt pan (LOTUS) - Series 600  
for Fry top (LOTUS) - Series 600  
for Sausage grill (LOTUS) - Series 600



LOTUS 536002300

## 3241171 BLACK KNOB $\varnothing$ 40 mm 0-90°C

D shaft hole 6x4.6 mm  
for Bain-marie (LOTUS) 600BM - 61BM - 62BM - 62BS  
62EM  
for Bain-marie electric (LOTUS) BM-61EM - BM-62EM  
BM-62ET  
for Pasta cooker (LOTUS) 600CP - 61CP  
for Pasta cooker electric (LOTUS) CP-61EM  
CP-62ET



LOTUS 536002200

WHIRLPOOL 801522

## 3241354 BLACK KNOB $\varnothing$ 40 mm 1-2-3

D shaft hole 6x4.6 mm  
for Food-service trolley (RIEBER) STW - ZUB



RIEBER 33353026

## 3241222 BLACK KNOB $\varnothing$ 40 mm 100-180°C

D shaft hole 6x4.6 mm  
for Fryer (LOTUS) - Series 600



LOTUS 536002400

## 3241209 BLACK KNOB $\varnothing$ 41 mm

D shaft hole 6x4.6 mm  
for Hot cupboard (ZANUSSI)  
for Self service counter (WHIRLPOOL) DL121/C  
DL14/C  
for Self service counter (ZANUSSI) DL21/CP



ALPENINOX 033050  
WHIRLPOOL 133050

ELECTROLUX 033050  
ZANUSSI 033050

WHIRLPOOL 771985000986



# Knobs



Suitable for:

**3241586 BLACK KNOB  $\varnothing$  42 mm**  
D shaft hole 6x4.6 mm



SAMMIC 6100412

Suitable for:

**3241347 BLACK KNOB  $\varnothing$  42 mm 1-10**  
D shaft hole 6x4.6 mm  
for Food-service trolley (BLANCO) SGE - SWE



BLANCO 292846

**3241660 BLACK KNOB  $\varnothing$  42 mm 36-210°C**  
D shaft hole 6x4.6 mm




COCINAS SALA R2801

**3241378 BLACK KNOB  $\varnothing$  43 mm**  
round hole  $\varnothing$  6 mm



MILAN TOAST 18540

**3241163 BLACK KNOB  $\varnothing$  44 mm**  
square hole 6x6 mm  
for Panini grill (DIHR) SALAMANDRA S1  
SALAMANDRA S2



DIHR 8029

METOS 8029

**3241173 BLACK KNOB  $\varnothing$  44 mm**  
D shaft hole 6x4.6 mm  
for Toaster (SILANOS)



SILANOS 903940

**3241174 BLACK KNOB  $\varnothing$  44 mm**  
D shaft hole 6x4.6 mm  
for Toaster (SILANOS)



FORVED TOSTTIMERMAN  
SIRMAN RG04352

SILANOS 903961

SILANOS 903973

**3241373 BLACK KNOB  $\varnothing$  44 mm**  
pin hole 7x5 mm



FB FABIA PR40054

**3241380 BLACK KNOB  $\varnothing$  44 mm**  
squared hole 3.5x3.5 mm



MILAN TOAST 7840

**3241349 BLACK KNOB  $\varnothing$  44 mm 0-15**  
pin hole 5x3.5 mm



LOTUS 536002000



Suitable for:

# Knobs



Suitable for:

**3241730 BLACK KNOB  $\varnothing$  44 mm 0-15'**  
D shaft hole 6x4.6 mm



**3241121 BLACK KNOB  $\varnothing$  45 mm**  
D shaft hole 6x4.6 mm  
for Bratt pan (ANGELO PO) - Series SENIOR  
for Pot stove (ANGELO PO) - Series SENIOR



ANGELO PO 36M2620

**3241088 RED INSERT FOR KNOB  $\varnothing$  32 mm**



ANGELO PO 36M2800

**3241259 BLACK KNOB  $\varnothing$  45 mm**  
D shaft hole 6x4.6 mm  
for Fryer (ANGELO PO) - Series JUNIOR  
Series SENIOR - Series SUMMIT



ANGELO PO 36M4560

**3241331 BLACK KNOB  $\varnothing$  45 mm**  
square hole 5x5 mm



NUOVA SIMONELLI 15320006

SIRMAN IGS336

**3241612 BLACK KNOB  $\varnothing$  45 mm**  
D shaft hole 6x4.6 mm  
for Fryer (FRI FRI) - Series D4



FRI FRI 400755

**3241714 BLACK KNOB  $\varnothing$  45 mm**  
round hole  $\varnothing$  6 mm  
for THERMOSTAT



HENNY PENNY HP25863

**3241725 BLACK KNOB  $\varnothing$  45 mm**  
D shaft hole 6x4.6 mm  
for energy regulator



CAPIC E402720

CHARVET 02016A

ROSINOX

**3241724 INDEXED PLATE  $\varnothing$  70 mm 0-100**  
for energy regulator



CAPIC E402710

CHARVET 02021A

ROSINOX





Suitable for:

**3241726 BLACK KNOB ø 45 mm ON-1-2-3-4-FULL**  
for energy adjuster  
D-shaped hole 4x4.6 mm



ROBERTSHAW 524.235(28023)

Suitable for:

**3241231 BLACK KNOB ø 45 mm 90-180°C**  
D shaft hole 6x4.6 mm  
for Fryer (MARENO) FQE



MARENO MA1031019800

**3241617 BLACK KNOB ø 47 mm**  
D shaft hole 8x6.5 mm  
for Hot plate (MOVILFRIT) PLG



MOVILFRIT 913185

MOVILFRIT 913246

MOVILFRIT 913299

**3241932 BLACK KNOB ø 47 mm**  
D-shaped hole 6x4.6 mm  
for thermostat  
for Food-service trolley electric (ALTO-SHAAM) 1767-SK  
for Hot cupboard (ALTO-SHAAM) 1000-TH-1  
1000-THII - 500 - 750  
for Hot cupboard electric (ALTO-SHAAM) 767-SK



ALTO-SHAAM KN-26568

**3241933 BLACK KNOB ø 48 mm OFF-1-10**  
D-shaped hole 6x4.6 mm  
for thermostat  
for Potato heater (ALTO-SHAAM) 100-HSL/BCS-2  
100-HSL/BCS-2S - 100-HSL/TM - 100-HSL/TMS  
for Warm table (ALTO-SHAAM) 100-TMC - 200-HFT  
300-HFT - 300-HST - 300-TMC



ALTO-SHAAM KN-3473

**3241931 BLACK KNOB ø 48 mm OFF-60-200°F**  
D-shaped hole 6x4.6 mm  
for Hot cupboard (ALTO-SHAAM) 500-1D - 500-1DN  
500-2D - 500-2DN - 500-3D - 500-3DN



ALTO-SHAAM KN-3469

**3241720 BLACK KNOB ø 48 mm 0-15'**  
D shaft hole 6x4.6 mm  
for TIMER



**3241750 BLACK KNOB ø 49 mm**  
D shaft hole 6x4,6 mm  
for Fryer (THIRODE)  
for Fryer electric (THIRODE) FR25  
for Grill (THIRODE)  
for Hot plate (THIRODE)  
for Pot stove (THIRODE) B9PE800 - GAME800 - 07BBC



HMI 381224

THIRODE 381224

THIRODE 132742

THIRODE 132843



Suitable for:

# Knobs



**3241787 BLACK KNOB  $\varnothing$  49 mm 1-15**  
D-shaped hole 6x4.6 mm  
for Fryer electric (AMBASSADE) CME413FR



AMBASSADE 88044008

**3241107 BLACK KNOB  $\varnothing$  50 mm**  
square hole 7x7 mm  
for Pasta cooker (ZANUSSI) - Series H900



ALPENINOX 025260  
ELECTROLUX 054254  
WHIRLPOOL 125260

ALPENINOX 054254  
R.D.FRIULI  
ZANUSSI 025260

ELECTROLUX 025260  
WHIRLPOOL 771985000683  
ZANUSSI 054254

**3241230 BLACK KNOB  $\varnothing$  50 mm**  
D shaft hole 6x4.6 mm  
for Bain-marie (MARENO) BME  
for Bratt pan (MARENO) BRE  
for Fry top (MARENO) FTE



MARENO MA1036702200

**3241745 BLACK KNOB  $\varnothing$  50 mm**  
D shaft hole 10x8 mm  
for GAS TAP



BONNET 310997

**3241748 BLACK KNOB  $\varnothing$  50 mm**  
square hole 6x6 mm  
for MIXER TAP



BONNET 311114

**3241896 BLACK KNOB  $\varnothing$  50 mm**  
with cap - square hole 7x7 mm  
for water tap  
for Boiling pan (BONNET) B-MA.CD.110G  
for Bratt pan (BONNET) - Series GRANDE CARTE



BONNET 138184

**3241897 BLACK KNOB  $\varnothing$  50 mm**  
with cap - D shaft hole 10x8 mm  
for gas tap  
for Boiling pan (BONNET) CD 110L  
for Bratt pan (BONNET) - Series GRANDE CARTE



BONNET 132845

**3241898 BLACK KNOB  $\varnothing$  50 mm**  
with index - D-shaped hole 8x6.5 mm  
for gas tap  
for Kitchen (BONNET) B-B9FV800FG  
for Panini grill (BONNET) - Series GRANDE CARTE  
for Pot stove (BONNET) B-B9PCF.FV.FG



BONNET 132844

BONNET 311115

HOBART 132844



# Knobs



Suitable for:

**3444129 BLACK KNOB ø 50 mm**  
D shaft hole 6x4.6 mm  
with symbol  
for thermostats and timers



DESCO 31051  
EGO 8335612010

DESCO 863151

EGO 524413

Suitable for:

**3241379 BLACK KNOB ø 50 mm SCREENPRINTED**  
D-shaped hole 6x4.6 mm



MILAN TOAST 7845

**3241117 BLACK KNOB ø 50 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Solid top range (ZANUSSI) - Series 701




ALPENINOX 052604

ELECTROLUX 052604

ZANUSSI 052604

**3241118 BLACK KNOB ø 50 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Solid top range gas (ZANUSSI) - Series 701



ALPENINOX 054105

ELECTROLUX 054105

ZANUSSI 054105

**3241178 BLACK KNOB ø 50 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Salamander (BERTO'S) SAE



BERTO'S 27653300

**3241565 BLACK KNOB ø 50 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for EGO energy regulator



EGO 0000524162

**3241567 BLACK KNOB ø 50 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for thermostat EGO



EGO 0000524830

**3241891 BLACK KNOB ø 50 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for energy regulator  
for Pot stove electric (AMBASSADE) CE841VRT



AMBASSADE 88044001

**3241829 BLACK KNOB ø 50 mm 0-1-0-1**  
D-shaped hole 6x4.6 mm



EGO 0000524056

EGO 524056

**3241309 BLACK KNOB ø 50 mm 0-1-2-3**  
D shaft hole 6x4.6 mm



DOSILET 400010009

EGO 0000524058

EGO 524058



Suitable for:

# Knobs



**3241320 BLACK KNOB  $\varnothing$  50 mm 0-1-2-3**  
D shaft hole 6x4.6 mm



EGO 0000524051

EGO 524051

POTIS PT0113

**3241564 BLACK KNOB  $\varnothing$  50 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for EGO energy regulator



EGO 0000524054

**3241566 BLACK KNOB  $\varnothing$  50 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for EGO energy regulator



CF CENEDESE 63.6.0280  
SOLYMAC P82A

CF CENEDESE 63.7.0280  
THIRODE 308091

EGO 0000524010

**3241552 BLACK KNOB  $\varnothing$  50 mm 0-1-2-3-4**  
D shaft hole 6x4.6 mm



EGO 0000524059

EGO 524059

**3241433 BLACK KNOB  $\varnothing$  50 mm 1-2-3-4-5-6-7-8**  
D shaft hole 8x6 mm  
for Pot stove gas (ZANUSSI) RCF/G720 - RCF/G730




ALPENINOX 054126

ELECTROLUX 054126

ZANUSSI 054126

**3241827 BLACK KNOB  $\varnothing$  50 mm 100-180°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



EGO 524813

**3241870 RING NUT  $\varnothing$  52 mm**  
chrome plated metal  
for EGO thermostate knob



CAPIC E401313  
EGO 6762105000  
FRIMA  
METOS  
SOLYMAC P79A

DELRUE NEP1400  
EGO 6762108  
JEMI  
MORICE

EGO 6762105  
EGO 6762000020  
LOWERATOR 105121  
SILKO 0101211



# Knobs



Suitable for:

**3241741 BLACK KNOB  $\varnothing$  50 mm 100-350°C**  
D shaft hole 6x4.6 mm  
for EGO thermostat



EGO 0000524810

EGO 524810

THIRODE 308078

Suitable for:

**3241870 RING NUT  $\varnothing$  52 mm**  
chrome plated metal  
for EGO thermostate knob



CAPIC E401313  
EGO 6762105000  
FRIMA  
METOS  
SOLYMAC P79A

DELRUE NEP1400  
EGO 6762108  
JEMI  
MORICE

EGO 6762105  
EGO 6762000020  
LOWERATOR 105121  
SILKO 0101211

**3241775 BLACK KNOB  $\varnothing$  50 mm 200-400°C**  
D-shaped pin 6x4.6 mm  
for Fryer (PITCO FRIALATOR)



PITCO FRIALATOR P6071273

ROBERTSHAW R-Z34620-75

**3241377 BLACK KNOB  $\varnothing$  50 mm 3-6-9-12-15**  
D-shaped hole 6x4.6 mm



MILAN TOAST 14211

**3241353 BLACK KNOB  $\varnothing$  50 mm 30°-110°C**  
D shaft hole 6x4.6 mm  
for Food-service trolley (RIEBER) STW - ZUB



RIEBER 33353019

TECNOINOX RC00598000

**3241355 BLACK KNOB  $\varnothing$  50 mm 30°-110°C**  
D shaft hole 6x4.6 mm



RIEBER 33353017

**3241636 BLACK KNOB  $\varnothing$  50 mm 30°-110°C**  
D shaft hole 6x4.6 mm  
for EGO thermostat



EGO

REPAGAS 22405005

**3241319 BLACK KNOB  $\varnothing$  50 mm 30°-85°C**  
D shaft hole 6x4.6 mm



ANIMO 03042  
THIRODE 308064

EGO 0000524837

EGO 524803



Suitable for:

# Knobs



**3241721 BLACK KNOB  $\varnothing$  50 mm 30°-90°C**  
D shaft hole 6x4.6 mm



ANIMO 03040

EGO 524804

Suitable for:

**3444126 BLACK KNOB  $\varnothing$  50 mm 30-110°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



BLANCO 105373

EGO 524407

LOWERATOR 105373

THIRODE 308067

CAPIC E401220

HMI 163248

SOLYMAC P76B

EGO 8335623010

HMI 308067

THIRODE 163248

**3444125 BLACK KNOB  $\varnothing$  50 mm 30-90°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



EGO 0000524401

EGO 524401

EGO 8335601010

**3241165 BLACK KNOB  $\varnothing$  50 mm 50°-300°C**  
D shaft hole 6x4.6 mm  
for Panini grill (SILANOS) ROLLY



EGO

SILANOS 903970

SILANOS 903972

**3241375 BLACK KNOB  $\varnothing$  50 mm 50-300°C**  
D-shaped hole 6x4.6 mm



MILAN TOAST 16342

MILAN TOAST 16347

MILAN TOAST 16351

**3444128 BLACK KNOB  $\varnothing$  50 mm 50-300°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



CAPIC E401280

EGO 524403

DELRUE ET1062

EGO 8335604010

**3444441 BLACK KNOB  $\varnothing$  50 mm 50-300°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



DELRUE ET1062

EGO 0000524807

SOLYMAC P79B

**3444187 BLACK KNOB  $\varnothing$  50 mm 50-500°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



EGO 0000524834

EGO 524834

FIMAR C03611

**3241616 BLACK KNOB  $\varnothing$  50 mm 60°-200°C**  
D shaft hole 6x4.6 mm  
for Fryer (MOVILFRIT)



MOVILFRIT 901504

**3241637 BLACK KNOB  $\varnothing$  50 mm 60°-200°C**  
D shaft hole 6x4.6 mm  
for EGO thermostat



AMBASSADE 6527735

REPAGAS 57103027

CAPIC E401265

SOLYMAC P80A

EGO 524806

THIRODE 308066



# Knobs



Suitable for:

**3445000 BLACK KNOB  $\varnothing$  50 mm 90-200°C**  
D-shaped pin  $\varnothing$  6x4.6 mm  
for EGO thermostat



EGO 524848


Suitable for:

**3241510 BLACK KNOB  $\varnothing$  51 mm**  
D shaft hole 6x4.6 mm



ROLLER GRILL A14077

**3241512 BLACK KNOB  $\varnothing$  51 mm**  
D shaft hole 6x4.6 mm  
for Panini grill electric (ROLLER GRILL) SAVOJE  
for Rotisserie electric (ROLLER GRILL) RBE12  
RBE25 - RBE4 - RBE8  
for Salamander electric (ROLLER GRILL) SEM60  
for Sausage grill (ROLLER GRILL) RG11 - RG5 - RG7  
RG9



ROLLER GRILL A14078

**3241773 BLACK KNOB  $\varnothing$  51 mm**  
round hole  $\varnothing$  6 mm  
for Fryer gas (FRYMASTER) MJ41E - MJ45E



FRYMASTER 810-0334

FRYMASTER 8100334

**3241743 BLACK KNOB  $\varnothing$  52 mm**  
with red pointer  
round hole  $\varnothing$  10 mm  
for GAS VALVE



**3241129 BLACK KNOB  $\varnothing$  52 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove gas (AMBACH) - Series 700



AMBACH 5022902024

AMBACH 5022906228

AMBACH 5022906268

AMBACH 5022908971

**3241216 BLACK KNOB  $\varnothing$  52 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Solid top range gas (AMBACH) GK/70



AMBACH 5022908981

**3241215 BLACK KNOB  $\varnothing$  52 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for Pot stove electric (AMBACH) - Series 700  
Series 900



AMBACH 5022901044



Suitable for:

# Knobs



**3241130 BLACK KNOB ø 52 mm 1-2-3-4-5-6-7-8**  
D shaft hole 10x9 mm  
for Oven under cooktop (AMBACH)



AMBACH 5022908973

Suitable for:

**3241376 BLACK KNOB ø 52 mm 1-2-3-4-5-6-7-8**  
for MINISIT VALVE



ELFRAMO 00035809  
KOMEL 00035809

ELFRAMO 00035812  
KOMEL 00035812

ELFRAMO 00035813  
KOMEL 00035813

**3241212 BLACK KNOB ø 52 mm 50-300°C**  
D shaft hole 6x4.6 mm  
for Kitchen electric (AMBACH) EKE/70



AMBACH 5022901048

**3241746 BLACK KNOB ø 53 mm**  
with yellow pointer  
round hole ø 10 mm  
for GAS VALVE



CAPIC K102060

CAPIC Q104071

**3241747 BLACK KNOB ø 53 mm**  
with yellow pointer  
D shaft hole 10x6 mm  
for selector switch-thermostat



CAPIC Q104072

**3241055 FIXING CLIP**  
for knob with ø 8 mm hole



ALPENINOX 025245  
EGO 0000607007  
FOEMM 0000022001  
STAR 10 063009

ANGELO PO 3170290  
ELECTROLUX 025245  
GIORIK 5900242  
WHIRLPOOL 153816

EGO 607007  
EMMEPI C00196  
SILKO 0101455  
ZANUSSI 025245

**3241625 BLACK KNOB ø 54 mm**  
D shaft hole 6x4.6 mm  
for Fryer (FRI FRI) - Series FF - Series FFE  
Series FT



FRI FRI 400545

**3241866 BLACK KNOB ø 54 mm 0-300°C**  
D shaft hole 6x4.6 mm  
for Bratt pan (WHIRLPOOL) ABR/E800 - ABR/E810  
ABR/G810  
for Bratt pan (ZANUSSI) - Series HD900



ALPENINOX 0A5143  
WHIRLPOOL 205143

ELECTROLUX 0A5143  
ZANUSSI 0A5143

WHIRLPOOL 771985005872





# Knobs



Suitable for:

Suitable for:

**3241091 BLACK KNOB ø 55 mm**  
square hole 5x5 mm  
for Fryer electric (REPAGAS) EB12 - EB18 - EB8



ELFRAMO 00006500  
KOMEL 00006500  
REPAGAS 8700012

ELFRAMO 00006520  
KOMEL 00006520

ELFRAMO 650  
KOMEL 650

**3241092 BLACK KNOB ø 55 mm**  
D shaft hole 6x4.6 mm  
for Fryer electric (REPAGAS) EB12 - EB18 - EB8



ELFRAMO 00033241  
KOMEL 00033241  
REPAGAS 8500006

ELFRAMO 00033250  
KOMEL 00033250

ELFRAMO 00033260  
KOMEL 00033260

**3241817 BLACK KNOB ø 55 mm**  
D shaft hole 6x4.6 mm  
for Bratt pan (ZANUSSI) - Series N700  
Series N900  
for Fryer (ZANUSSI) - Series N700 - Series N900  
for Pasta cooker (ZANUSSI) - Series N700  
Series N900  
for Pot stove (ZANUSSI) - Series N700



ALPENINOX 0A5621  
WHIRLPOOL 205621

ELECTROLUX 0A5621  
ZANUSSI 0A5621

WHIRLPOOL 771985012720

**3241881 BLACK KNOB ø 55 mm**  
D shaft hole 8x6 mm  
for Pasta cooker (ZANUSSI) OC/G1 - OC/G2 - OCP/G1S  
OCP/G2D - OR/G1CL - OR/G1FL - OR/G1FR  
OR/G2FL - WS/G2 - WSF/G2



ALPENINOX 0C1007

ELECTROLUX 0C1007

ZANUSSI 0C1007

**40C1233 BLACK KNOB ø 55 mm**  
D-shaped hole 8x6.5 mm  
for Bain-marie (ZANUSSI) - Series N900  
for Bratt pan (ZANUSSI) - Series N700  
for Fry top (ZANUSSI) - Series N900  
for Fryer (ZANUSSI) - Series N700 - Series N900  
for Pot stove (ZANUSSI) - Series N700  
Series N900  
for Solid top range (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C1233

ELECTROLUX 0C1233

ZANUSSI 0C1233

**3241043 BLACK KNOB ø 55 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove gas (ALPENINOX) - Series 700  
for Pot stove gas (ZANUSSI) - Series 700



ALPENINOX 0A2126

ELECTROLUX 0A2126

ZANUSSI 0A2126



Suitable for:

# Knobs



## 3241044 BLACK KNOB ø 55 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Boiling pan gas (ALPENINOX)  
for Boiling pan gas (ZANUSSI)  
for Fry top gas (ALPENINOX)  
for Fry top gas (ZANUSSI)  
for Pot stove gas (ALPENINOX)  
for Pot stove gas (ZANUSSI)  
for Solid top range gas (ALPENINOX)  
for Solid top range gas (ZANUSSI)



ALPENINOX 0A2260

ELECTROLUX 0A2260

ZANUSSI 0A2260

## 3241443 BLACK KNOB ø 55 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for Pot stove (ZANUSSI) HCF/GE810 - ZCF/GE810



ALPENINOX 059850

ELECTROLUX 059850

ZANUSSI 059850

## 3241742 BLACK KNOB ø 55 mm 0-1-2-3-4-5-6-7-8

D-shaped hole 6x4.6 mm  
for Fryer (ELFRAMO) KGWDT12 - KGWDT20 - KGWT



ELFRAMO 00038683

KOMEL 00038683

## 3241267 BLACK KNOB ø 55 mm 1-2-3-4-5-6-7

D shaft hole 6x4.6 mm  
for Bratt pan (ZANUSSI) - Series HD900



ALPENINOX 059469

ELECTROLUX 059469

ZANUSSI 059469

## 3241413 BLACK KNOB ø 55 mm 100-280°C

D shaft hole 8x6 mm  
for Fry top (ZANUSSI) MR/G1070 - MR/G1071  
MR/G720 - MR/G721



ALPENINOX 058776

ELECTROLUX 058776

ZANUSSI 058776

## 3241430 BLACK KNOB ø 55 mm 105-185°C

D shaft hole 6x4.6 mm  
for Fryer (ZANUSSI) FR/E2D08 - MF/E1S08 - RF/E1S08



ALPENINOX 004783

ELECTROLUX 004783

ZANUSSI 004783

## 3241408 BLACK KNOB ø 55 mm 110-350°C

D shaft hole 6x4.6 mm  
for Pot stove (ZANUSSI) - Series HD900



ALPENINOX 059236

ELECTROLUX 059236

ZANUSSI 059236

## 3241417 BLACK KNOB ø 55 mm 120-300°C

D shaft hole 6x4.6 mm  
for Bratt pan (ZANUSSI) - Series HD900



ALPENINOX 059468

ELECTROLUX 059468

ZANUSSI 059468



# Knobs



Suitable for:

**3241440 BLACK KNOB ø 55 mm 120-330°C**  
D shaft hole 8x6 mm  
for Oven under cooktop gas (ZANUSSI) HCF/G1210  
HCF/G1610 - HCF/G810 - ZCF/G1210 - ZCF/G1610  
ZCF/G810



ALPENINOX 059220

ELECTROLUX 059220

ZANUSSI 059220

Suitable for:

**3241869 BLACK KNOB ø 55 mm 120-330°C**  
D shaft hole 8x6.5 mm  
for Pot stove gas (ZANUSSI) - Series HD900  
for Solid top range gas (ZANUSSI) - Series HD900



ALPENINOX 0A9065  
WHIRLPOOL 209065

ELECTROLUX 0A9065  
ZANUSSI 0A9065

WHIRLPOOL 771985006099

**3241476 BLACK KNOB ø 55 mm 80-320°C**  
D shaft hole 8x6.5 mm  
for Oven under cooktop (BARON) - Series 700  
Series 900



BARON BN824710110

BARON 824710110

**3241087 BLACK KNOB ø 56 mm**  
D shaft hole 6x4.6 mm  
for selector switch



BARON BN6A037800  
METOS BN6A037800  
OLIS BN6A037800

BARON 6A037800  
METOS 6A037800  
OLIS 6A037800

BARON 6A047500  
METOS 6A047500  
OLIS 6A047500

**3241776 BLACK KNOB ø 56 mm 100-200°C**  
D-shaped hole 6x4.6 mm  
for Fryer (PITCO FRIALATOR)



PITCO FRIALATOR PP10537  
PITCO FRIALATOR P6071271

PITCO FRIALATOR PP10539

PITCO FRIALATOR P6071268

**3241790 BLACK KNOB ø 57 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for GAS VALVE



**3241791 BLACK KNOB ø 57 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for GAS VALVE



**3241792 BLACK KNOB ø 57 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for GAS TAP



**3241793 BLACK KNOB ø 57 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for GAS TAP



**3241695 BLACK KNOB ø 58 mm 100-180°C**  
D shaft hole 6x4.6 mm  
for THERMOSTAT GF14



GARLAND F8160139

GARLAND 816-0139



# Knobs



Suitable for:

Suitable for:

**3241509 BLACK KNOB  $\varnothing$  60 mm**  
D shaft hole 8x6 mm



MUNDIGAS 3241509

**3241217 BLACK KNOB  $\varnothing$  60 mm PILOT-MAX-MIN**  
round hole  $\varnothing$  10 mm  
screw fastening to the spindle  
for Solid top range (AMBACH) - Series 900



AMBACH 5022907196

**3241218 KNOB FASTENING SCREW  $\varnothing$  6x32 mm**  
thread M3



AMBACH 3009600005

**3241066 BLACK KNOB  $\varnothing$  60 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Bain-marie gas (ZANUSSI)  
for Fry top gas (ZANUSSI)  
for Hot cupboard gas (ZANUSSI)  
for Pot stove gas (ZANUSSI)  
for Solid top range gas (ZANUSSI)



ALPENINOX 052138  
WHIRLPOOL 152138

ELECTROLUX 052138  
ZANUSSI 052138

WHIRLPOOL 771985002484

**3241260 BLACK KNOB  $\varnothing$  60 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Bain-marie gas (TECNOINOX) BM35G - BM70G  
for Pot stove electric (TECNOINOX) PC35G  
for Pot stove gas (TECNOINOX) PC70G



ALPENINOX 004957  
ZANUSSI 004957

ELECTROLUX 004957

TECNOINOX RC00401000

**3241540 BLACK KNOB  $\varnothing$  60 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (GICO)  
Series 64-PROFONDITA' 600 NUOVA



GICO 766100020

GICO 790106630

GICO 790119470

**3241144 KNOB BLACK INSERT**  
external  $\varnothing$  72 mm



GICO 290202440

**3241139 KNOB RING RED**  
external  $\varnothing$  72 mm



GICO 290202350

**3241143 KNOB SPRING  $\varnothing$  42x26 mm**



GICO 290202430



# Knobs



Suitable for:

**3241064 BLACK KNOB ø 60 mm 0-1-0-1**  
D shaft hole 6x4.6 mm  
for Boiling pan electric (ZANUSSI)  
for Fryer electric (ZANUSSI)



ALPENINOX 050341 ELECTROLUX 050341 ZANUSSI 050341

Suitable for:

**3241137 BLACK KNOB ø 60 mm 0-1-2-3-4**  
D shaft hole 6x4.6 mm  
for Pot stove electric (ZANUSSI) - Series H900



ALPENINOX 052183 ELECTROLUX 052183 WHIRLPOOL 771985002491  
ZANUSSI 052183

**3241414 BLACK KNOB ø 60 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove electric (ZANUSSI) SCE350 - SCE700



ALPENINOX 004913 ELECTROLUX 004913 TECNOINOX RC00289000  
ZANUSSI 004913

**3241814 BLACK KNOB ø 60 mm 1-1**  
D shaft hole 6x4.6 mm  
for Bain-marie (GICO) - Series 110 - Series 500  
Series 64 - Series 700 - Series 900 - Series 920  
for Self service counter (GICO) - Series 39



GICO 766100040 GICO 790106900 GICO 790119490

**3241062 BLACK KNOB ø 60 mm 1-2-3-4-5**  
D shaft hole 6x4.6 mm  
for Boiling pan electric (ZANUSSI)



ALPENINOX 051552 ELECTROLUX 051552 ZANUSSI 051552

**3241067 BLACK KNOB ø 60 mm 1-2-3-4-5-6-7-8**  
D shaft hole 6x4.6 mm  
for Bain-marie electric (ZANUSSI)  
for Bratt pan electric (ZANUSSI)  
for Fry top electric (ZANUSSI)  
for Fryer electric (ZANUSSI)  
for Hot cupboard electric (ZANUSSI)  
for Oven under cooktop electric (ZANUSSI)



ALPENINOX 026915 ELECTROLUX 026915 WHIRLPOOL 771985000741  
WHIRLPOOL 126915 ZANUSSI 026915

**3241244 BLACK KNOB ø 60 mm 1-2-3-4-5-6-7-8**  
D shaft hole 6x4.6 mm  
for Pot stove (TECNOINOX) PCC35E - PCC70E  
for Potato heater (TECNOINOX) SP35E



ALPENINOX 004897 ELECTROLUX 004897 EMMEPI E11110002  
TECNOINOX RC00287000 ZANUSSI 004897

**3241246 BLACK KNOB ø 60 mm 100-190°C**  
D shaft hole 6x4.6 mm  
for Fryer electric (TECNOINOX) FR35E - FR70E



ALPENINOX 004924 ELECTROLUX 004924 TECNOINOX RC00280000  
ZANUSSI 004924



Suitable for:

# Knobs



**3241248 BLACK KNOB ø 60 mm 100-300°C**  
 D shaft hole 6x4.6 mm  
 for Fry top electric (TECNOINOX) FTC35E - FTC70E  
 FTL35E - FTL70E - FTR35E - FTR70E



ALPENINOX 004916  
ZANUSSI 004916

ELECTROLUX 004916

TECNOINOX RC00284000

**3241651 BLACK KNOB ø 60 mm 165-190°C**  
 D shaft hole 6x4.6 mm  
 for Fryer gas (JEMI) - Series 1000 - Series 1300  
 Series 700 - Series 750 - Series 900



JEMI 996015

**3241245 BLACK KNOB ø 60 mm 30-90°C**  
 D shaft hole 6x4.6 mm  
 for Bain-marie electric (TECNOINOX) BM35E - BM70E



ALPENINOX 004909  
ZANUSSI 004909

ELECTROLUX 004909

TECNOINOX RC00268000

**3241134 BLACK KNOB ø 60 mm 50-300°C**  
 D-shaped hole 6x4.6 mm  
 for Fry top (GICO) - Series 110 - Series 500  
 Series 700 - Series 900 - Series 920  
 for Oven under cooktop (GICO) - Series 110  
 Series 900 - Series 920



GICO 766100130  
GICO 790119570

GICO 790106950

GICO 790109400

**3241421 BLACK KNOB ø 60 mm 90-250°C**  
 hole for mertik gas valve knob  
 for Pot stove gas (ZANUSSI) MMV/G1C - MMV/G2C  
 RMV/G1C - RMV/G2C



ALPENINOX 0A5586  
ELECTROLUX 006464

ALPENINOX 006464  
ZANUSSI 0A5586

ELECTROLUX 0A5586  
ZANUSSI 006464

**3241623 BLACK KNOB ø 62 mm SILK-SCREEN PRINTED**  
 D shaft hole 6x4.6 mm  
 for Pot stove gas (KÜPPERSBUSCH) - Series GHP  
 Series LGH



KÜPPERSBUSCH 189005

KÜPPERSBUSCH 189009

**3241633 BLACK KNOB ø 62 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for Pot stove (REPAGAS)



REPAGAS 00300078

**3241635 BLACK KNOB ø 62 mm SILK-SCREEN PRINTED**  
 D shaft hole 8x6.5 mm  
 for Pot stove (REPAGAS)



REPAGAS 30100053



# Knobs



Suitable for:

**3241684 BLACK KNOB  $\varnothing$  62 mm SILK-SCREEN PRINTED**  
for GAS TAP



GARLAND 4512120

Suitable for:

**3241685 BLACK KNOB  $\varnothing$  62 mm SILK-SCREEN PRINTED**  
for GAS TAP



GARLAND 4512140

**3241686 BLACK KNOB  $\varnothing$  62 mm SILK-SCREEN PRINTED**  
for GAS TAP



GARLAND 4512150

**3241687 BLACK KNOB  $\varnothing$  62 mm SILK-SCREEN PRINTED**  
for GAS TAP



GARLAND 4512139

**3241689 BLACK KNOB  $\varnothing$  62 mm SILK-SCREEN PRINTED**  
for Oven under cooktop (GARLAND) M43R - M44R



GARLAND 4512147

**3241688 BLACK KNOB  $\varnothing$  62 mm 70-260°C**  
for Oven under cooktop (GARLAND)



GARLAND 4512142

**3241083 BLACK KNOB  $\varnothing$  63 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Grill gas (AMBACH)



AMBACH 5022904344

**3241148 BLACK KNOB  $\varnothing$  63 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove (AMBACH) KKG



AMBACH 5022908810

**3241219 BLACK KNOB  $\varnothing$  63 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Pot stove electric (AMBACH)  
Series 700 VECCHIA - Series 900 VECCHIA



AMBACH 5022902025

AMBACH 5022904345

**3241680 BLACK KNOB  $\varnothing$  63 mm UNIVERSAL**  
D shaft hole 6x4.6 mm



GARLAND G02716-1



Suitable for:

# Knobs



**3241681 BLACK KNOB ø 63 mm UNIVERSAL**  
D shaft hole 9x8 mm



GARLAND G02716-2

GARLAND 1314002

Suitable for:

**3241682 BLACK KNOB ø 63 mm UNIVERSAL**  
D shaft hole 11x8 mm



GARLAND G02716-3

**3241374 BLACK KNOB ø 63 mm 110-190°C**  
D shaft hole 6x4.6 mm  
for Fryer (AMBACH) EF1/40 - FE/40 - FE/80



AMBACH 5022909977

**3241128 BLACK KNOB ø 63 mm 160-300°C**  
D shaft hole 8x6.5 mm  
for Oven under cooktop (AMBACH) - Series 850  
Series 900



AMBACH 5022904331

**3241394 BLACK KNOB ø 63 mm 50-300°C**  
D shaft hole 6x4.6 mm



AMBACH 5022904315

**3241656 BLACK KNOB ø 65 mm**  
D shaft hole 8x6.5 mm  
for Pot stove (MACFRIN)



MACFRIN 3150

MACFRIN 315000

**3241657 BLACK KNOB ø 65 mm**  
D shaft hole 8x6.5 mm  
for Rotisserie gas (MCM) 1EG - 8EG



MCM 030132

**3241024 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for COOKTOP OVEN



MARENO MA1840800

MARENO 1840800

MARENO MA1840800+...

MARENO 1840800+1842000

MARENO 1623300

MARENO 1841000

**3241040 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED**  
D-shaped hole 10x8 mm  
for valve equipped gas COOK TOP tap



EMMEPI 806133

MBM 168868

MBM RTCU900028

MBM 168345





# Knobs



Suitable for:

Suitable for:

## 3241081 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove gas (SILKO)



EBERHARDT 214005  
SILKO 0101953

EBERHARDT 214059

SILKO 0101786

## 3241157 KNOB BLUE STICKER



EBERHARDT 222195

SILKO 0101940

## 3241082 KNOB EXTENSION



EBERHARDT 212475

SILKO 9201543

## 3241094 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for thermostat



SILKO 0101206  
SILKO 0101958

SILKO 0101219  
SILKO 0101958+0101940

SILKO 0101220

## 3241098 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for selector switch



SILKO 0101213

SILKO 0101959

SILKO 0101959+0101940

## 3241255 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for Bratt pan gas (MARENO) BRG



MARENO MA1036703300+....

MARENO 1036702900

MARENO 1036703300+184200

## 3241272 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 10x9 mm  
for Pot stove (ANGELO PO) - Series VECCHIA SERIE



ANGELO PO 36M0560

## 3241576 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm



EBERHARDT 214006  
SILKO 0101787+0101795

GIORIK 5900246  
SILKO 0101965

SILKO 0101787  
SILKO 0101965+0101940

## 3241648 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Boiling pan (JEMI) - Series 700 - Series 900



JEMI 996021



Suitable for:

# Knobs



**3241649 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (JEMI) - Series 1000 - Series 1300  
Series 550 - Series 600 - Series 700 - Series 750  
Series 900



JEMI 990601

JEMI 9996019

**3241650 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pasta cooker (JEMI) - Series 700 - Series 900



JEMI 996026

**3241811 BLACK KNOB ø 65 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove gas (OLIS) - Series 700 - Series 900



BARTSCHER 02599200  
OLIS 2599200

METOS 2599200  
OLIS BN2599200

METOS BN2599200

**3241639 BLACK KNOB ø 65 mm 0-1**  
D shaft hole 6x4.6 mm  
for Oven under cooktop (JEMI) - Series 550  
Series 600 - Series 700 - Series 750 - Series 900



JEMI 996025

**3241640 BLACK KNOB ø 65 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for Pot stove (JEMI) - Series 550 - Series 600  
Series 700 - Series 900



JEMI 996023

**3241580 BLACK KNOB ø 65 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove electric (SILKO) - Series 700



SILKO 0101210

SILKO 0101957

SILKO 0101957+0101940

**3241573 BLACK KNOB ø 65 mm 0-295°C**  
D shaft hole 6x4.6 mm




EBERHARDT 214069  
SILKO R0101963+R0101940

ROSINOX RX94812578  
SILKO 0101963

SILKO R0101963  
SILKO 0101963+0101940

**3241157 KNOB BLUE STICKER**



EBERHARDT 222195

SILKO 0101940

**3241097 BLACK KNOB ø 65 mm 0-310°C**  
D shaft hole 6x4.6 mm  
for thermostat



SILKO 0101207  
SILKO 0101956+0101940

SILKO 0101215

SILKO 0101956

**3241584 BLACK KNOB ø 65 mm 0-90°C**  
D shaft hole 6x4.6 mm



SILKO 0101962

SILKO 0101962+0101940



Suitable for:

# Knobs



**3241845 BLACK KNOB ø 65 mm 0-90°C**  
 D-shaped hole 6x4.6 mm  
 for Bain-marie (OLIS) 70/02  
 for Kitchen (OLIS) 72 - 72T - 74 - 74T - 76 - 76E  
 76EE - 76FL - 76GE - 76T  
 for Kitchen electric (OLIS) 74E  
 for Kitchen gas (OLIS) 74G - 76G



METOS BN2599210  
OLIS 2599210

METOS 2599210

OLIS BN2599210

**3786368 KNOB GASKET**  
 external ø 45 mm - height 9 mm  
 for Bratt pan electric (OLIS) 74/02KBEB  
 74/02KBEBI - 74/02KBEMBI  
 for Fry top electric (OLIS) 72/02FTE - 72/02FTE  
 72/02TFTE - 72/02TFTE - 74/02FTE - 74/02FTE  
 74/02TFTE - 74/02TFTE  
 for Fryer electric (OLIS) 72/02FRE - 73/02FRE  
 74/02FRE  
 for Kitchen electric (OLIS) 72/02CEPT - 76/02CEPT  
 for Oven under cooktop electric (OLIS) 72/02CEPQ  
 72/02CEPQ - 72/02CEPQ - 74/02CEEPQ  
 74/02CEEPQ - 74/02CEPQ - 74/02TCEPT  
 76/02CEEANPQ - 76/02CEEANPT - 76/02CEEEACPO  
 76/02CEPQ - 76/02CEPQ - 76/02TCEPT  
 for Pasta cooker electric (OLIS) 72/02CPE



METOS BN2519490  
OLIS 2519490

METOS 2519490

OLIS BN2519490

**3241577 BLACK KNOB ø 65 mm 1-2-3-4-5-6-7**  
 D shaft hole 10x8 mm



SILKO SIR0102796

SILKO SIR0102796+...

**3241645 BLACK KNOB ø 65 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Fry top (JEMI) - Series 1000 - Series 1300  
 Series 550 - Series 600 - Series 700 - Series 750  
 Series 900  
 for Fryer (JEMI) - Series 1000 - Series 1300  
 Series 550 - Series 600 - Series 700 - Series 750  
 Series 900  
 for Pot stove (JEMI) - Series 550 - Series 600  
 Series 700 - Series 750 - Series 900



JEMI 996024

**3241646 BLACK KNOB ø 65 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 8x6.5 mm  
 for Fry top (JEMI) - Series 1000 - Series 1300  
 Series 550 - Series 600 - Series 700 - Series 750  
 Series 900  
 for Oven under cooktop (JEMI) - Series 1000  
 Series 1300 - Series 550 - Series 600 - Series 700  
 Series 750 - Series 900



JEMI 996020

**3241813 BLACK KNOB ø 65 mm 110-190°C**  
 D shaft hole 8x6.5 mm  
 for Fryer gas (OLIS) 72/02FRG - 73/02FRG  
 74/02FRG - 92/04FRG15L - 92G15L - 93/04FRG  
 93G



METOS BN2599201  
OLIS 2599201

METOS 2599201

OLIS BN2599201



Suitable for:

# Knobs



Suitable for:

## 3241812 BLACK KNOB ø 65 mm 60-300°C

D shaft hole 6x4.6 mm  
for Kitchen (OLIS) 76E - 76EE  
for Kitchen electric (OLIS) 74E  
for Oven under cooktop (OLIS) 74EPQ - 74EPT - 74F  
74STE - 76EANPQ - 76EANPT - 76EEACPQ  
76EEACPT - 800F - 94E - 94EE - 94GE  
94GEP96GE - 94GE1P - 96EDX - 96ESX - 96GE  
96GEE - 96GEEP - 96GEE2P - 96GEP - 96GE2P  
98E - 98GE - 98GEP - 98GE2P  
for Oven under cooktop electric (OLIS) 74CE




METOS BN2599208  
OLIS 2599208

METOS 2599208

OLIS BN2599208

## 3241285 BLACK KNOB ø 66 mm COLD WATER

D shaft hole 10x8 mm  
for Boiling pan (MARENO) - Series 900 PROTAGONISTA  
for Pasta cooker (MARENO) - Series 700  
Series 900



MARENO CM143100

MARENO MACM143100

## 3241284 BLACK KNOB ø 66 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Fry top (MARENO) - Series 700 - Series 900  
for Lava rock grill (MARENO)  
Series 900 PROTAGONISTA  
for Pot stove (MARENO) - Series 700 PROTAGONISTA  
Series 900 PROTAGONISTA



MARENO CM061700

MARENO MACM061700

## 3241287 BLACK KNOB ø 66 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm



MARENO CM059700

MARENO MACM059700

## 3241290 BLACK KNOB ø 66 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Pasta cooker (MARENO)  
Series 700 PROTAGONISTA - Series 900 PROTAGONISTA



MARENO CM061600

MARENO MACM061600

## 3241521 BLACK KNOB ø 66 mm 0-1-0-1

D shaft hole 6x4.6 mm  
for Bain-marie (MARENO) B7 - B9



MARENO CM140000

MARENO MACM140000

## 3241289 BLACK KNOB ø 66 mm 1-2-3-4-5-6

D shaft hole 6x4.6 mm  
for Pot stove (MARENO) - Series 900 PROTAGONISTA  
for Pot stove electric (MARENO)  
Series 700 PROTAGONISTA



MARENO CM062100

MARENO MACM062100

## 3241519 BLACK KNOB ø 66 mm 1-2-3-4-5-6

D shaft hole 6x4.6 mm  
for ENERGY REGULATOR



MARENO CM062500

MARENO MACM062500



# Knobs



Suitable for:

Suitable for:

**3241522 BLACK KNOB  $\varnothing$  66 mm 100-190°C**  
 D shaft hole 10x8 mm  
 for Boiling pan (MARENO) PI7 - PI9  
 for Fryer (MARENO) F12C/F7 - 4G15/F9 - 8G15  
 8G15/F9



MARENO CM062301

MARENO MACM062301

**3241281 BLACK KNOB  $\varnothing$  66 mm 100-300°C**  
 D shaft hole 10x8 mm  
 for Oven under cooktop (MARENO)  
 Series 700 PROTAGONISTA - Series 900 PROTAGONISTA



MARENO CM058001

MARENO MACM058001

**3241520 BLACK KNOB  $\varnothing$  66 mm 30-90°C**  
 D shaft hole 6x4.6 mm  
 for Bain-marie (MARENO) B7 - B9



MARENO CM140100

MARENO MACM140100

**3241288 BLACK KNOB  $\varnothing$  66 mm 50-300°C**  
 D shaft hole 6x4.6 mm  
 for Fry top (MARENO) - Series 700 PROTAGONISTA  
 Series 900 PROTAGONISTA



MARENO CM059800

MARENO MACM059800

**3241282 BLACK KNOB  $\varnothing$  66 mm 60-190°C**  
 D shaft hole 6x4.6 mm  
 for Fryer (MARENO) - Series 700 PROTAGONISTA  
 Series 900 PROTAGONISTA



MARENO CM062200

MARENO MACM062200

**3241283 BLACK KNOB  $\varnothing$  66 mm 90-300°C**  
 D shaft hole 10x8 mm  
 for Fry top (MARENO) - Series 700 PROTAGONISTA  
 Series 900 PROTAGONISTA



MARENO CM062401

MARENO MACM062401

**3241037 BLACK KNOB  $\varnothing$  68 mm**  
 D shaft hole 10x9 mm  
 for Pot stove (ANGELO PO) - Series JUNIOR  
 Series SENIOR



ANGELO PO 36M2390

**3241120 BLACK KNOB  $\varnothing$  68 mm**  
 D shaft hole 8x6.5 mm  
 for Pot stove gas (ANGELO PO) - Series JUNIOR  
 for Salamander gas (ANGELO PO) - Series JUNIOR



ANGELO PO 36M3050

**3241122 BLACK KNOB  $\varnothing$  68 mm**  
 D shaft hole 6x4.6 mm  
 for Pot stove (ANGELO PO) - Series JUNIOR  
 Series SENIOR



ANGELO PO 36M2400

**3241655 BLACK KNOB  $\varnothing$  68 mm**  
 D-shaped hole 6x4.6 mm



MACFRIN 3185

MACFRIN 318500

MACFRIN 3454



Suitable for:

# Knobs



## 3241262 BLACK KNOB ø 68 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove (ZANUSSI) - Series HD900



ALPENINOX 059265  
WHIRLPOOL 159265

ELECTROLUX 059265  
ZANUSSI 059265

WHIRLPOOL 771985003722

## 3241228 BLACK KNOB ø 70 mm

D shaft hole 6x4.6 mm  
for Bratt pan (WHIRLPOOL) AGB417 - AGB419 - AGB421  
AGB423 - AGB425 - AGB427 - AGB429 - AGB431  
for Bratt pan gas (WHIRLPOOL) AGB416 - AGB418  
AGB420 - AGB422 - AGB424 - AGB426 - AGB428  
AGB430



GIGA Y65010  
WHIRLPOOL 483286009386

GIGA 0000X00600

GIGA 0000Y65010

## 3241626 BLACK KNOB ø 70 mm

D shaft hole 6x4.6 mm  
for Bain-marie (IMEGAS)



IMEGAS

## 3241627 BLACK KNOB ø 70 mm

D shaft hole 8x6.5 mm  
for Pot stove (IMEGAS)



IMEGAS 0000110

## 3241628 BLACK KNOB ø 70 mm

D shaft hole 10x8 mm  
for Pot stove (IMEGAS)



IMEGAS

## 3241631 SELF-STICKING DISK OVEN ø 64 mm




IMEGAS

## 3241629 SELF-STICKING DISK 3 GAS BURNERS ø 64 mm



IMEGAS

## 3241630 SELF-STICKING DISK 4 GAS BURNERS ø 64 mm



IMEGAS

## 3241627 BLACK KNOB ø 70 mm

D shaft hole 8x6.5 mm  
for Pot stove (IMEGAS)



IMEGAS 0000110

## 3241628 BLACK KNOB ø 70 mm

D shaft hole 10x8 mm  
for Pot stove (IMEGAS)



IMEGAS



# Knobs



Suitable for:

**3241654 BLACK KNOB ø 70 mm**  
D shaft hole 10x8 mm  
for Rotisserie (EURAST)



EURAST 14090819

Suitable for:

**3241753 BLACK KNOB ø 70 mm**  
with red indicator  
D shaft hole 8x6.5 mm  
for PEL VALVE



**3241754 BLACK KNOB ø 70 mm**  
with red pointer  
D shaft hole 10x8 mm  
for PEL valve



SOLYMAC

**3241863 BLACK KNOB ø 70 mm**  
D shaft hole 6x4.6 mm



BERTO'S  
ELETTROBAR

DEXION  
METOS

DIHR

**3241419 BLACK KNOB ø 70 mm HOT WATER**  
D shaft hole 10x8 mm  
for Boiling pan (ZANUSSI) - Series HD900  
for Solid top range (ZANUSSI) - Series HD900



ALPENINOX 0G2258  
ELECTROLUX 059538

ALPENINOX 059538  
ZANUSSI 0G2258

ELECTROLUX 0G2258  
ZANUSSI 059538

**3241438 BLACK KNOB ø 70 mm HOT WATER**  
D shaft hole 10x8 mm  
for Boiling pan (ZANUSSI) - Series HD900  
Series H900



ALPENINOX 059516

ELECTROLUX 059516

ZANUSSI 059516

**3241864 BLACK KNOB ø 70 mm MIN-MAX**  
D shaft hole 6x4.6 mm



BERTO'S  
ELETTROBAR

DEXION  
METOS

DIHR

**3241006 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for GAS COOKTOP valve  
for Kitchen (MARENO) - Series 900



MARENO MA1322200+...  
MARENO 1322300+1322200

MARENO 132200  
MARENO 1322400

MARENO 1322200+1322300



Suitable for:

# Knobs



## 3241009 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for OVEN selector switch



MARENO MA1323513+...  
MARENO 1323600

MARENO 1323500  
MARENO 1323613

MARENO 1323513+1508100  
MARENO 1508100+1323513

## 3241042 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D-shaft hole 8x6.5 mm  
for Pot stove (MBM) - Series MAGISTRA



EMMEPI 806037

MBM 169337

MBM 169355

## 3241075 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove gas (GIGA)



GIGA 0000X00100

GIGA 0000Y65101

WHIRLPOOL 483286000329

## 3241140 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Bratt pan (ZANUSSI) - Series HD900  
for Fryer (ZANUSSI) - Series PR700



ALPENINOX 059304  
WHIRLPOOL 159304

ELECTROLUX 059304  
ZANUSSI 059304

WHIRLPOOL 771985003734

## 3241187 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove (MBM) - Series OMNIA



MBM RTCU700308  
MBM 168867

MBM RTCU700309

MBM 168861

## 3241227 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for Grill (WHIRLPOOL) AGB366 - AGB367 - AGB503  
AGB547 - AGB588 - AGB611  
for Grill electric (GIGA) SKRE/EGRS-M  
for Kitchen electric (WHIRLPOOL) AGB497



GIGA 000Y65006  
WHIRLPOOL 4832860009167

GIGA 0000X01300

GIGA 0000Y65006

## 3241268 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Bain-marie (ZANUSSI) - Series PR700  
for Pasta cooker (ZANUSSI) - Series PR700



ALPENINOX 004483

ELECTROLUX 004483

ZANUSSI 004483

## 3241313 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Boiling pan (ZANUSSI) - Series HD700  
for Fry top (ZANUSSI) - Series HD700  
for Solid top range (ZANUSSI) - Series HD700



ALPENINOX 058597  
WHIRLPOOL 158597

ELECTROLUX 058597  
ZANUSSI 058597

WHIRLPOOL 771985003581





# Knobs



Suitable for:

## 3241314 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove gas (ZANUSSI) - Series HD900



ALPENINOX 059206  
WHIRLPOOL 159206

ELECTROLUX 059206  
ZANUSSI 059206

WHIRLPOOL 771985003698

Suitable for:

## 3241315 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Pasta cooker (ZANUSSI) - Series HD900



ALPENINOX 002308  
ELECTROLUX 059378

ALPENINOX 059378  
ZANUSSI 002308

ELECTROLUX 002308  
ZANUSSI 059378

## 3241384 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove (CASTA)



CASTA 29/99800029

CASTA 700001

## 3241410 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for Kitchen gas (ZANUSSI) MCF/GE1050 - MCF/GE700  
RCF/GE1051



ALPENINOX 058541

ELECTROLUX 058541

ZANUSSI 058541

## 3241416 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Boiling pan (ZANUSSI) - Series HD700  
Series HD900



ALPENINOX 0A5002  
WHIRLPOOL 205002

ELECTROLUX 0A5002  
ZANUSSI 0A5002

WHIRLPOOL 771985005842

## 3241418 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6 mm  
for Pot stove (ZANUSSI) - Series PR700  
for Solid top range (ZANUSSI) - Series PR700



ALPENINOX 004329  
WHIRLPOOL 104329

ELECTROLUX 004329  
ZANUSSI 004329

WHIRLPOOL 771985011274

## 3241420 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6 mm  
for Pot stove (ZANUSSI) - Series HD700



ALPENINOX 0A2958  
WHIRLPOOL 202958

ELECTROLUX 0A2958  
ZANUSSI 0A2958

WHIRLPOOL 771985005818

## 3241472 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Fry top (BARON) - Series 110 - Series 140  
Series 700 - Series 900  
for Kitchen gas (BARON) 92TP2FG160



BARON BN824710100

BARON 824710100



Suitable for:

# Knobs



**3241473 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for HOT WATER INLET  
 for Boiling pan (BARON) - Series 900  
 for Pasta cooker (BARON) - Series 700 - Series 900



BARON BN824710150

BARON 824710150

**3241474 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for COLD WATER INLET  
 for Boiling pan (BARON) - Series 900  
 for Pasta cooker (BARON) - Series 700 - Series 900



BARON BN824710140

BARON 824710140

**3241528 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 8x6.5 mm  
 for Pot stove (MBM) - Series MINIMA



MBM RTCU600063  
MBM 168867

MBM RTCU600064

MBM 168861

**3241530 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for Pot stove gas (MBM) - Series DOMINA



MBM 164581

MBM 165927

MBM 168848

**3241532 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for (BARON) - Series 110 - Series 600 - Series 700  
 Series 900



BARON BN824710120

BARON 824710120

**3241536 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for Boiling pan (BARON) - Series 900  
 for Pasta cooker (BARON) - Series 700 - Series 900



BARON BN824710130

BARON 824710130

**3241591 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 8x6 mm  
 for Pot stove (OFFCAR) - Series 700 - Series 900



OFFCAR 401405

**3241622 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for Boiling pan gas (ZANUSSI) - Series 700  
 for Pasta cooker gas (ZANUSSI) - Series 700  
 for Pot stove gas (ZANUSSI) - Series 700  
 for Solid top range gas (ZANUSSI) - Series 700



ALPENINOX 0A2986  
WHIRLPOOL 202986

ELECTROLUX 0A2986  
ZANUSSI 0A2986

WHIRLPOOL 771985005826



# Knobs



Suitable for:

## 3241638 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Pot stove (REPAGAS)



REPAGAS 30118000

Suitable for:

## 3241815 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Bratt pan (WHIRLPOOL) ABR/G810  
for Bratt pan (ZANUSSI) BR/G810  
for Bratt pan gas (ZANUSSI) BR/G800 - M40GBP90  
for Fryer (ZANUSSI) AFR/G410 - AFR/G410D  
AFR/G810 - AFR/G810D - AFR/G810NL - AFR/410NL  
AFR/412 - CFR/G351 - CFR/G741 - M20GFR90  
M40GFR90 - OFR/G810 - S20GFR90 - XFR/G351  
for Fryer gas (WHIRLPOOL) XFR/G351



ALPENINOX 0A5188  
WHIRLPOOL 205188

ELECTROLUX 0A5188  
ZANUSSI 0A5188

WHIRLPOOL 771985005898

## 3241818 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6 mm  
for Oven under cooktop (WHIRLPOOL) CC4FG007  
CC6FG010  
for Pot stove (ZANUSSI) - Series PR700  
for Pot stove gas (WHIRLPOOL) CC2TG003 - CC4TG007  
CC4VG007 - CC6VG010  
for Solid top range gas (WHIRLPOOL) CTPF207  
CTPF210



ALPENINOX 004291  
WHIRLPOOL 104291

ELECTROLUX 004291  
ZANUSSI 004291

WHIRLPOOL 771985000447

## 3241820 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D shaft hole 8x6 mm  
for Solid top range (ZANUSSI) - Series PR700



ALPENINOX 004304  
WHIRLPOOL 104304

ELECTROLUX 004304  
ZANUSSI 004304

WHIRLPOOL 771985000450

## 3241868 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D shaft hole 10x8 mm  
for Bain-marie (ZANUSSI) - Series PR700  
for Boiling pan (ZANUSSI) - Series PR700  
for Bratt pan (ZANUSSI) - Series PR700  
for Pasta cooker (ZANUSSI) - Series PR700



ALPENINOX 0A5421  
WHIRLPOOL 205421

ELECTROLUX 0A5421  
ZANUSSI 0A5421

WHIRLPOOL 771985005940

## 3525019 EXTENSION FOR BALLCOCK VALVE

for Bain-marie (ZANUSSI) - Series PR700  
for Boiling pan (ZANUSSI) - Series HD900  
for Bratt pan (ZANUSSI) - Series HD700  
Series N700 - Series PR700  
for Pasta cooker (ZANUSSI) - Series PR700



ALPENINOX 0A2135  
WHIRLPOOL 202135

ELECTROLUX 0A2135  
ZANUSSI 0A2135

WHIRLPOOL 771985005757

## 3241871 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D-shaped hole 10x8 mm  
for GAS TAP



## 3241872 BLACK KNOB $\varnothing$ 70 mm SILK-SCREEN PRINTED

D-shaped hole 8x6.5 mm  
for GAS TAP





Suitable for:

**3241873 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**

D-shaped hole 10x8 mm  
for GAS TAP



# Knobs



Suitable for:

**3241874 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**

D-shaped hole 8x6.5 mm  
for GAS TAP



SICOMEX

**3241879 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**

D shaft hole 10x8 mm  
for Lava rock grill gas (ZANUSSI) HG/G400  
HG/G800  
for Pot stove (ZANUSSI) HCP/G400 - HCP/G800  
HPN/GI805 - HPN/GI806 - HT/G800 - HTF/G1210  
HTF/G810



**3241880 BLACK KNOB ø 70 mm SILK-SCREEN PRINTED**

D shaft hole 10x8 mm  
for Bratt pan gas (ZANUSSI) HBR/G800 - HBR/G805  
HBR/G810  
for Pot stove (ZANUSSI) HFR/G410 - HFR/G411  
HFR/G412 - HFR/G430 - HFR/G810



ALPENINOX 059386

ELECTROLUX 059386

ZANUSSI 059386


ALPENINOX 059348

ELECTROLUX 059348

ZANUSSI 059348

**3241613 BLACK KNOB ø 70 mm 0-1**

D shaft hole 6x4.6 mm  
for Fryer (OFFCAR) - Series 700 - Series 900



OFFCAR 401469

**3241007 BLACK KNOB ø 70 mm 0-1-0-1**

D shaft hole 6x4.6 mm  
for BRATT PAN thermostat



MARENO MA1323700+...

MARENO 1323700+1508100

MARENO 1323800

MARENO 1508100+1323700

**3241448 BLACK KNOB ø 70 mm 0-1-0-1**

D shaft hole 6x4.6 mm  
for Grill electric (ZANUSSI) HG/E400 - HG/E800  
ZG/E400 - ZG/E800



ALPENINOX 059333

ELECTROLUX 059333

ZANUSSI 059333

**3241860 BLACK KNOB ø 70 mm 0-1-0-1**

D shaft hole 6x4.6 mm



BERTO'S  
ELETTROBAR

DEXION  
METOS

DIHR



# Knobs



Suitable for:

Suitable for:

**3241008 BLACK KNOB ø 70 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for selector switch

**3241834 BLACK KNOB ø 70 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for PASTA COOKER AGB449/851244901000  
AGB451/851245101000-AGB528/851252801000  
AGB530/851253001000-AGB592/851259201000  
AGB593/851259301000  
for PASTA COOKER SKCP40E-SKCP60E-CCPE4-CCPE6-TCP40  
-TCP60E-ICPE4-ICPE6-KCP4E-KCP82E-OPCP4E-OPCP82E



MARENO 1322700+1508100  
MARENO 862900

MARENO 1322800

MARENO 1508100+1322700

GIGA Y65011  
WHIRLPOOL 483286009308

GIGA 0000X01000

GIGA 0000Y65011

**3241861 BLACK KNOB ø 70 mm 0-1-2-3**  
D shaft hole 6x4.6 mm

**3241316 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove electric (ZANUSSI) - Series HD700  
Series HD900



BERTO'S  
ELETTROBAR

DEXION  
METOS

DIHR

ALPENINOX 059230  
WHIRLPOOL 159230

ELECTROLUX 059230  
ZANUSSI 059230

WHIRLPOOL 771985003709

**3241523 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Kitchen electric (MBM) E4F  
for Pot stove electric (MBM) E2AR - E6AR

**3241531 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove electric (MBM) - Series DOMINA



EMMEPI 807771

MBM 169340

MBM 169363

MBM 164577  
MBM 169912

MBM 165926

MBM 168847

**3241533 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for (BARON) - Series 600 - Series 700 - Series 900

**3241590 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove (OFFCAR) - Series 700 - Series 900



BARON BN824710320

BARON 824710320

OFFCAR 401441



Suitable for:

# Knobs



**3241786 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
 D shaft hole 6x4.6 mm  
 for Kitchen electric (WHIRLPOOL) AGB496  
 for Kitchen gas (WHIRLPOOL) AGB582  
 for Oven under cooktop electric (WHIRLPOOL) AGB487  
 AGB585  
 for Pot stove electric (WHIRLPOOL) AGB364 - AGB365  
 AGB501 - AGB502 - AGB586 - AGB587



GIGA 0000Y04100

GIGA 0000Y65005

WHIRLPOOL 483286009632

**3241862 BLACK KNOB ø 70 mm 0-1-2-3-4-5-6**  
 D shaft hole 6x4.6 mm



BERTO'S  
ELETTRORBAR

DEXION  
METOS

DIHR

**3241719 BLACK KNOB ø 70 mm 0-8**  
 D-shaped hole 6x4.6 mm  
 for Bain-marie (DESCO) BME72 - Series OLD  
 for Fry top electric (DESCO) - Series OLD



DESCO 803151

**3241188 BLACK KNOB ø 70 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 8x6.5 mm  
 for Pot stove (MBM) - Series OMNIA



MBM RTCU700343  
MBM 168867

MBM RTCU700344

MBM 168861

**3241269 BLACK KNOB ø 70 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Boiling pan (ZANUSSI) - Series PR700  
 for Pasta cooker (ZANUSSI) - Series PR700



ALPENINOX 059779

ELECTROLUX 059779

ZANUSSI 059779

**3241270 BLACK KNOB ø 70 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Pasta cooker (ZANUSSI) - Series HD900  
 for Pot stove (ZANUSSI) - Series HD900



ALPENINOX 059554

ELECTROLUX 059554

ZANUSSI 059554

**3241587 BLACK KNOB ø 70 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 8x6 mm  
 for Fry top (OFFCAR) - Series 700



OFFCAR 401415

**3241589 BLACK KNOB ø 70 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 10x8 mm  
 for Fry top (OFFCAR) - Series 900



OFFCAR 401411



# Knobs



Suitable for:

**3241875 BLACK KNOB  $\varnothing$  70 mm 1-2-3-4-5-6-7-8**

D-shaped hole 10x8 mm  
for GAS TAP



SOLYMAC P72C

Suitable for:


**3241876 BLACK KNOB  $\varnothing$  70 mm 1-2-3-4-5-6-7-8**

D-shaped hole 8x6.5 mm  
for GAS TAP



**3241857 BLACK KNOB  $\varnothing$  70 mm 100-180°C**

D-shaped hole 6x4.6 mm  
for GAS TAP



**3241221 BLACK KNOB  $\varnothing$  70 mm 100-195°C**

D shaft hole 6x4.6 mm  
for Fryer (GIGA) E - E10B - MB - SKF



GIGA 0000X00700

GIGA 0000Y65002

WHIRLPOOL 483286009353

**3241428 BLACK KNOB  $\varnothing$  70 mm 100-280°C**

D shaft hole 8x6 mm  
for Fry top gas (ZANUSSI) HR/G420 - HR/G820  
HR/G821 - ZR/G420 - ZR/G820



ALPENINOX 059422

ELECTROLUX 059422

ZANUSSI 059422

**3241471 BLACK KNOB  $\varnothing$  70 mm 100-300°C**

D shaft hole 8x6.5 mm  
for Fry top (BARON) - Series 110 - Series 140  
Series 700 - Series 900



BARON BN824710070

BARON 824710070

**3241506 BLACK KNOB  $\varnothing$  70 mm 105-185°C**

D shaft hole 6x4.6 mm  
for Fryer (ZANUSSI) - Series N900 - Series PR700




ALPENINOX 059303

ELECTROLUX 059303

ZANUSSI 059303

**3241832 BLACK KNOB  $\varnothing$  70 mm 105-185°C**

D shaft hole 8x6 mm  
for Fryer (WHIRLPOOL) - Series 700  
for Fryer (ZANUSSI) - Series 700



ALPENINOX 058591

WHIRLPOOL 158591

ELECTROLUX 058591

ZANUSSI 058591

WHIRLPOOL 771985003579

**3241411 BLACK KNOB  $\varnothing$  70 mm 120-280°C**

D shaft hole 6x4.6 mm  
for Bratt pan (ZANUSSI) MBK/E2FM - RBK/E2FM  
for Bratt pan electric (ZANUSSI) RBR/E2FM  
RBR/E2IM



ALPENINOX 059403

ELECTROLUX 059403

ZANUSSI 059403

**3241816 BLACK KNOB  $\varnothing$  70 mm 120-300°C**

D shaft hole 6x4.6 mm  
for Bratt pan (WHIRLPOOL) M40GBP90  
for Bratt pan (ZANUSSI) M40EBP90  
for Bratt pan gas (ZANUSSI) M40GBP90



ALPENINOX 0A5279

WHIRLPOOL 205279

ELECTROLUX 0A5279

ZANUSSI 0A5279

WHIRLPOOL 771985005911



Suitable for:

# Knobs



**3241475 BLACK KNOB ø 70 mm 140-200°C**  
D shaft hole 6x4.6 mm  
for Fryer electric (BARON) - Series 900



BARON BN824710220


BARON 824710220

**3241614 BLACK KNOB ø 70 mm 140-200°C**  
D shaft hole 6x4.6 mm  
for Fryer (OFFCAR) - Series 700 - Series 900



OFFCAR 401461

**3241317 BLACK KNOB ø 70 mm 140-300°C**  
D shaft hole 8x6.5 mm  
for Oven under cooktop (ZANUSSI) - Series 700  
for Kitchen gas (ZANUSSI) MCF/G705F



ALPENINOX 058537

ELECTROLUX 058537

WHIRLPOOL 771985003563

WHIRLPOOL 158537

ZANUSSI 058537

**3241441 BLACK KNOB ø 70 mm 140-300°C**  
D shaft hole 8x6 mm  
for Pot stove (ZANUSSI) - Series HD700  
for Solid top range (ZANUSSI) - Series HD700



ALPENINOX 0A2965

ELECTROLUX 0A2965

WHIRLPOOL 771985005820

WHIRLPOOL 202965

ZANUSSI 0A2965

**3241415 BLACK KNOB ø 70 mm 140-320°C**  
D shaft hole 6x4.6 mm  
for Pot stove (ZANUSSI) MCF/M2 - MCF/M3 - RCF/M2  
RCF/M3




ALPENINOX 004330

ELECTROLUX 004330

ZANUSSI 004330

**3241446 BLACK KNOB ø 70 mm 140-320°C**  
D shaft hole 6x4.6 mm  
for Kitchen gas (ZANUSSI) MCF/GE1050 - MCF/GE700  
RCF/GE1051



ALPENINOX 058542

ELECTROLUX 058542

ZANUSSI 058542

**3241477 BLACK KNOB ø 70 mm 150-290°C**  
D shaft hole 8x6 mm  
for Pot stove gas (ZANUSSI) MCF/G2 - RCF/G2



ALPENINOX 004336

ELECTROLUX 004336

ZANUSSI 004336

**3241819 BLACK KNOB ø 70 mm 150-290°C**  
D shaft hole 8x6 mm  
for Oven under cooktop (WHIRLPOOL) CCF6G010  
CC4FG007 - CTPF007  
for Oven under cooktop (ZANUSSI) - Series PR700  
for Pot stove (ZANUSSI) - Series PR700  
for Solid top range (ZANUSSI) - Series PR700  
for Solid top range gas (WHIRLPOOL) CTPF207  
CTPF210



ALPENINOX 004299

ELECTROLUX 004299

ZANUSSI 004299





# Knobs



Suitable for:

**3241447 BLACK KNOB  $\varnothing$  70 mm 150-310°C**  
D shaft hole 6x4.6 mm  
for Fry top electric (ZANUSSI) RR/E1FL - RR/E1FR  
RR/E2FL - RR/E2FM



ALPENINOX 004710 ELECTROLUX 004710 ZANUSSI 004710

Suitable for:

**3241412 BLACK KNOB  $\varnothing$  70 mm 180-300°C**  
D shaft hole 8x6 mm  
for Fry top (ZANUSSI) HR/G403 - HR/G803 - HR/G814



ALPENINOX 059413 ELECTROLUX 059413 ZANUSSI 059413

**3241855 BLACK KNOB  $\varnothing$  70 mm 30-110°C**  
D shaft hole 6x4.6 mm



BERTO'S  
ELETTROBAR DEXION  
METOS DIHR

**3241011 BLACK KNOB  $\varnothing$  70 mm 30-90°C**  
D shaft hole 6x4.6 mm  
for BAIN MARIE thermostat



MARENO MA1323200  
MARENO 1323200 MARENO MA1323200+...  
MARENO 1323200+1508100 MARENO 1323100  
MARENO 1508100+1323200

**3241106 BLACK KNOB  $\varnothing$  70 mm 30-90°C**  
D shaft hole 8x6.5 mm  
for Bain-marie gas (ZANUSSI) - Series HD900



ALPENINOX 059801 ELECTROLUX 059801 WHIRLPOOL 159801

**3241853 BLACK KNOB  $\varnothing$  70 mm 30-90°C**  
D shaft hole 6x4.6 mm



BERTO'S  
ELETTROBAR DEXION  
METOS DIHR

**3241854 BLACK KNOB  $\varnothing$  70 mm 30-90°C**  
D shaft hole 6x4.6 mm




BERTO'S  
METOS DIHR  
ELETTROBAR

**3241535 BLACK KNOB  $\varnothing$  70 mm 40-100°C**  
D shaft hole 6x4.6 mm  
for Bain-marie (BARON) - Series 700 - Series 900  
for Pasta cooker (BARON) - Series 700 - Series 900



BARON BN824710240 BARON 824710240

**3241877 BLACK KNOB  $\varnothing$  70 mm 50-250°C**  
D-shaped hole 6x4.6 mm  
for GAS TAP



**3241014 BLACK KNOB  $\varnothing$  70 mm 50-300°C**  
D shaft hole 6x4.6 mm  
for BRATT PAN thermostat



MARENO MA1322500+...  
MARENO 1508100+1322500 MARENO 1322500+1508100 MARENO 1322600



# Knobs



Suitable for:

## 3241017 BLACK KNOB $\varnothing$ 70 mm 50-300°C

D shaft hole 6x4.6 mm  
for COOKTOP OVEN thermostat



MARENO MA1323300+...

MARENO 1323300+1508100

MARENO 1323400

MARENO 1508100+1323300

Suitable for:

## 3241149 BLACK KNOB $\varnothing$ 70 mm 50-300°C

D shaft hole 6x4.6 mm  
for Fry top (GIGA) - Series 900  
for Kitchen electric (WHIRLPOOL) AGB496 - AGB497  
for Kitchen gas (WHIRLPOOL) AGB493 - AGB495  
AGB582  
for Oven under cooktop (GIGA) - Series 900  
for Oven under cooktop (WHIRLPOOL) AGB604 - AGB605  
AGB606 - AGB609



GIGA Y65004

GIGA 0000Y04600

GIGA 0000Y04900

GIGA 0000Y65004

WHIRLPOOL 483286000406

WHIRLPOOL 483286009369

## 3241534 BLACK KNOB $\varnothing$ 70 mm 50-300°C

D shaft hole 6x4.6 mm  
for Fry top electric (BARON) - Series 600  
Series 700 - Series 900




BARON BN824710250

BARON 824710250

## 3241588 BLACK KNOB $\varnothing$ 70 mm 50-300°C

D shaft hole 6x4.6 mm  
for Fry top (OFFCAR) - Series 700 - Series 900  
for Oven under cooktop (OFFCAR) - Series 700  
Series 900



OFFCAR 401421


## 3241858 BLACK KNOB $\varnothing$ 70 mm 50-300°C

D-shaped hole 6x4.6 mm  
for GAS TAP




## 3241878 BLACK KNOB $\varnothing$ 70 mm 50-300°C

D-shaped hole 6x4.6 mm  
for GAS TAP



## 3241859 BLACK KNOB $\varnothing$ 70 mm 50-320°C

D-shaped hole 6x4.6 mm  
for GAS TAP



## 3241273 BLACK KNOB $\varnothing$ 71 mm SILK-SCREEN PRINTED

D shaft hole 8x6.5 mm  
for Bratt pan (WHIRLPOOL) 200-309  
for Fry top gas (GIGA) SKTG  
for Lava rock grill gas (GIGA) SKPLG  
for Pot stove (GIGA) - Series 700 NUOVA  
Series 900 NUOVA



GIGA Y65103

GIGA 0000X00800

GIGA 0000Y03700

GIGA 0000Y65103

GIGA 1000Y03700

WHIRLPOOL 483286009275

WHIRLPOOL 483286009382



# Knobs



Suitable for:

Suitable for:

**3241334 BLACK KNOB ø 71 mm SILK-SCREEN PRINTED**  
 D shaft hole 10x8 mm  
 for Boiling pan gas (GIGA) KPI10G - KP10G - KP15G  
 for Boiling pan gas (WHIRLPOOL) AGB371 - AGB373  
 AGB374 - AGB376 - AGB378 - AGB379 - AGB395  
 AGB397 - AGB398 - AGB400 - AGB402 - AGB403  
 for Pasta cooker (GIGA) KCP4 - KCP82 - OPCP4  
 OPCP82  
 for Pasta cooker gas (WHIRLPOOL) AGB448 - AGB450  
 AGB527 - AGB529



ELETTROBAR  
GIGA 1000X00800

GIGA Y65203  
GIGA Y03700

GIGA 0000Y65203  
WHIRLPOOL 483286009199

**3241600 BLACK KNOB ø 71 mm SILK-SCREEN PRINTED**  
 D shaft hole 6x4.6 mm  
 for Kitchen electric (FAGOR) CE-741 - CE-941



FAGOR U673004000

FAGOR U673016000

**3241597 BLACK KNOB ø 71 mm 1-2-3-4-5-6**  
 D shaft hole 6x4.6 mm  
 for Pot stove electric (FAGOR) - Series CE700  
 Series CE900



FAGOR U673003000

FAGOR U673015000

VAUBAN

**3241592 BLACK KNOB ø 71 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Fryer electric (FAGOR) FE-710 - FE-920



FAGOR X162100000

FAGOR X183020000

FAGOR X183025000

**3241595 BLACK KNOB ø 71 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Fryer gas (FAGOR) FG-710 - FG-940



FAGOR X313002000

FAGOR X313003000

**3241606 BLACK KNOB ø 71 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Fry top electric (FAGOR) FTE-710 - FTE-910  
 for Kitchen electric (FAGOR) CE-741 - CE-941  
 CE7-40  
 for Kitchen gas (FAGOR) CGE-741  
 for Oven under cooktop electric (FAGOR) CE-920  
 CE-940



FAGOR U673005000

FAGOR U673017000

**3241607 BLACK KNOB ø 71 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Bain-marie (FAGOR) - Series 700 - Series 900  
 for Bratt pan (FAGOR) SBE



FAGOR R212100000

FAGOR R212101000

VAUBAN

**3241608 BLACK KNOB ø 71 mm 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Bratt pan gas (FAGOR) SBG



FAGOR X152110000

FAGOR X152111000



Suitable for:

# Knobs



Suitable for:

## 3241609 BLACK KNOB $\varnothing$ 71 mm 1-2-3-4-5-6-7-8-9

D shaft hole 6x4.6 mm  
for Boiling pan (FAGOR) BM - ME



FAGOR S333005000

FAGOR S333006000

## 3241393 BLACK KNOB $\varnothing$ 72 mm

D shaft hole 6x4.6 mm  
for Pot stove electric (AMBACH) - Series 900



AMBACH 5022914031

## 3186348 GASKET FOR KNOB


external  $\varnothing$  64 mm - internal  $\varnothing$  54 mm - thic kn. 8 mm



AMBACH 5017314030

## 3241214 SELF-STICKING DISK 0-1-2-3


external  $\varnothing$  68 mm



AMBACH 5022914336

## 3241211 SELF-STICKING DISK 50-300°C

external  $\varnothing$  68 mm



AMBACH 5022914339

## 3241395 BLACK KNOB $\varnothing$ 72 mm

D shaft hole 10x8 mm  
for Pot stove gas (AMBACH) - Series 900



AMBACH 5022914032

## 3241396 SELF-STICKING DISK WITH PILOT SYMBOL

external  $\varnothing$  68 mm



AMBACH 5022914331

## 3241397 SELF-STICKING DISK 110-190°C

external  $\varnothing$  68 mm



AMBACH 5022914338



Suitable for:

**3241085 BLACK KNOB ø 72 mm SILK-SCREEN PRINTED**

D shaft hole 10x8 mm  
for Pot stove gas (BARON)



BARON BN6A019301  
BARON 6A019390  
METOS BN6A019301  
METOS 6A019301  
OLIS 1019301  
OLIS 6A019390

BARON BN6A019390  
METOS 6A019301+...  
METOS BN6A019390  
OLIS BN6A019301  
OLIS 6A019301

BARON 6A019301  
METOS 6A019390  
METOS 1019301  
OLIS BN6A019390  
OLIS 6A019301+...

# Knobs



Suitable for:

**3241390 BLACK KNOB ø 72 mm SILK-SCREEN PRINTED**

D shaft hole 8x6.5 mm  
for Pot stove (MODULAR) - Series 700



MODULAR 612.017.00

**3241569 BLACK KNOB ø 72 mm SILK-SCREEN PRINTED**

D shaft hole 8x6.5 mm  
for Pot stove gas (MODULAR) - Series 700



MODULAR 612.016.00

**3241560 BLACK KNOB ø 72 mm 0-1-2-3-4-5-6**


D shaft hole 6x4.6 mm  
for Pot stove electric (MODULAR) - Series 700



MODULAR 612.018.00

**3241840 BLACK KNOB ø 73 mm**

square hole 12x12 mm  
for Fryer (OLIS) FR/E950N - FR/G925N - FR/G950N  
FRE/925N - 710FRG - 7101FRE - 7121FRE - 720FRG  
7201FRE - 722FRG - 912FFRG - 9122PFRG  
914PFRG - 92FRG - 922FRE - 922FRG - 94FRG  
941FRE  
for Fryer electric (OLIS) 921FRE



BARON 6A033000

METOS 6A033000

OLIS 6A033000

**3241261 BLACK KNOB ø 73 mm SILK-SCREEN PRINTED**

D shaft hole 6x4.6 mm  
for Pot stove electric (SILKO)  
for Kitchen electric (TECNOX) CCT7246



SILKO 0101790

SILKO 0101790+0101795

**3241574 BLACK KNOB ø 73 mm SILK-SCREEN PRINTED**

D shaft hole 8x6.5 mm  
for Pot stove (SILKO) - Series 700 - Series 900



EBERHARDT 214060  
SILKO 0101234  
SILKO 0101798+0101940  
SILKO 0101954+0101940

GIORIK 5900254  
SILKO 0101798  
SILKO 0101953+0101940

ROSINOX RX94806189  
SILKO 0101798+0101795  
SILKO 0101954

**3241579 BLACK KNOB ø 73 mm 0-110°C**

D shaft hole 6x4.6 mm



EBERHARDT 214010

SILKO 0101791

SILKO 0101791+0101795



# Knobs



Suitable for:

**3241581 BLACK KNOB  $\varnothing$  73 mm 0-295°C**  
D shaft hole 6x4.6 mm



EBERHARDT 214016

SILKO 0101799

SILKO 0101799+0101795

Suitable for:

**3241585 BLACK KNOB  $\varnothing$  73 mm 0-310°C**  
D shaft hole 6x4.6 mm



EBERHARDT 214008

SILKO 0101789+0101795

SILKO 0101795

**3241575 BLACK KNOB  $\varnothing$  73 mm 0-90°C**  
D shaft hole 6x4.6 mm



EBERHARDT 214014

MARENO 7800800

SILKO 0101797

SILKO 0101797+0101795

**3241276 BLACK KNOB  $\varnothing$  75 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Fryer (GIORIK) - Series 600 - Series 700  
Series 900



GIORIK 2008672

**3241527 BLACK KNOB  $\varnothing$  75 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove (MBM) - Series MAGIS MAGISTRA



MBM 164360

MBM 168852

**3241632 BLACK KNOB  $\varnothing$  75 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove (REPAGAS)



REPAGAS 00130000

REPAGAS 0100144

REPAGAS 50100083

**3241659 BLACK KNOB  $\varnothing$  75 mm SILK-SCREEN PRINTED**  
D shaft hole 10x7 mm  
for Pot stove (COCINAS SALA)



COCINAS SALA R5001

**3241823 BLACK KNOB  $\varnothing$  75 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Grill gas (GIORIK) GG66  
for Pasta cooker gas (GIORIK) CPG1 - CPG1BM  
CPG2L - CPG66 - 2CPG - 22CPG - 23CPG - 3CPG



GIORIK 2008671

**3241824 BLACK KNOB  $\varnothing$  75 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (GIORIK) - Series GIO70  
Series GIO90



GIORIK 2012984

**3241525 BLACK KNOB  $\varnothing$  75 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for Boiling pan (MBM) E150A  
for Boiling pan electric (MBM) E150IA  
for Pasta cooker electric (MBM) EC45



EMMEPI 807770

MBM RTCP800104



# Knobs



Suitable for:

**3241882 BLACK KNOB  $\varnothing$  75 mm 0-110°C**  
D shaft hole 6x4.6 mm  
for Pasta cooker (GIORIK) CP1 - CP2L - CP22L  
for Pasta cooker (ZANUSSI) CP1BM



GIORIK 2008675

Suitable for:

**3241624 BLACK KNOB  $\varnothing$  75 mm 100-250°C**  
D shaft hole 6x4.6 mm  
for Fry top (EMMEPI) - Series 650 - Series 700  
Series 750 - Series 900  
for Oven under cooktop (EMMEPI) - Series 650  
Series 700 - Series 750 - Series 900



EMMEPI C99639

**3241620 BLACK KNOB  $\varnothing$  76 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (EMMEPI) - Series 650 - Series 700



EMMEPI C89433

EMMEPI C89459

**3241621 BLACK KNOB  $\varnothing$  76 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove (EMMEPI) - Series 650 - Series 700  
Series 750 - Series 900



EMMEPI C99683

**3241619 BLACK KNOB  $\varnothing$  76 mm 1-2-3-4-5-6-7-8**  
D shaft hole 10x8 mm  
for Fry top (EMMEPI)  
for Oven under cooktop (EMMEPI)



EMMEPI C99698

**3241126 BLACK KNOB  $\varnothing$  76 mm 170-300°C**  
D shaft hole 10x8 mm  
for Oven under cooktop (MBM) MAGISTRA



EMMEPI 806361

MBM RTCU800019

**3241842 BLACK KNOB  $\varnothing$  77 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Bain-marie (OLIS) 912PTCBE - 912PTCBG - 92CBE  
92CBG - 92TCBE - 94CBE - 94CBG - 94TCBE  
94TCBG



BARTSCHER 020482  
OLIS 2599003

METOS 2599003  
OLIS BN2599003

METOS BN2599003

**3241841 BLACK KNOB  $\varnothing$  77 mm 100-190°C**  
D shaft hole 6x4.6 mm  
for Fryer (OLIS) - Series 900



BARTSCHER 0230921  
METOS 2599014  
METOS 9998191002  
OLIS BN8215304  
OLIS 2994370  
OLIS BN2994370

EBERHARDT 202106  
METOS 2994370  
METOS BN2994370  
OLIS BN9998191002  
OLIS 8215304

METOS BN9998191002  
METOS 8215304  
METOS BN8215304  
OLIS 2599014  
OLIS 9998191002



Suitable for:

**3241844 BLACK KNOB  $\varnothing$  77 mm 30-90°C**  
D shaft hole 6x4.6 mm



METOS BN2994320  
OLIS 2994320

METOS 2994320

OLIS BN2994320

## Knobs



Suitable for:

**3241757 BLACK KNOB  $\varnothing$  80 mm**  
D-shaped hole 6x4.6 mm  
for FRYER thermostat



BOURGEOIS MAN3002

BOURGEOIS MAN3006

SOLYMAC P72N

**3241388 BLACK KNOB  $\varnothing$  82 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Fry top (MODULAR) 90/40FTG - 90/80FTRG



MODULAR 912.004.00

**3241389 BLACK KNOB  $\varnothing$  82 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (MODULAR) - Series 900




MODULAR 912.003.00

**3241391 BLACK KNOB  $\varnothing$  82 mm SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for Oven under cooktop (MODULAR) - Series 900



MODULAR 912.006.00

**3241387 BLACK KNOB  $\varnothing$  82 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove (MODULAR) - Series 1200 - Series 900



MODULAR 912.011.00

**3241386 BLACK KNOB  $\varnothing$  82 mm 50-300°C**  
D shaft hole 6x4.6 mm  
for Oven under cooktop (MODULAR) - Series 900



MODULAR 912.005.00

**3241921 BLACK KNOB CAP**  
for Food-service trolley (BLANCO) SAG2 - SAG3  
SGE3 ECOLINE



BLANCO 146781

**3241089 BLACK KNOB CASING**  
for MINISIT valve



ANGELO PO 36M2580

**3241088 RED INSERT FOR KNOB  $\varnothing$  32 mm**



ANGELO PO 36M2800





# Knobs



Suitable for:

**1241542 BLACK KNOB FOR CONVERTER**  
square hole 5x5 mm



CB 10010017

Suitable for:

**3241764 BLACK KNOB MIN-MAX**  
D shaft hole 6x4.6 mm  
for energy regulator



AMBASSADE 88044007


**3241740 BLACK KNOB OFF-LO-2-3-4-5-6-HI**  
D-shaped hole 6x4.6 mm  
for energy regulator with infinite position



ROBERTSHAW R-Z34620-120

ROBERTSHAW R-Z34620-122

**3241444 BLACK KNOB POINER**  
for Pot stove (ZANUSSI)



ALPENINOX 059207

ELECTROLUX 059207

WHIRLPOOL 159207

ZANUSSI 059207

**3241190 BLACK KNOB RING NUT 110-270°C**  
for Pot stove gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0194

ELECTROLUX 0C0194

ZANUSSI 0C0194

**3241425 BLACK KNOB RING NUT 110-270°C**  
for Bratt pan (ZANUSSI) - Series N700  
for Fry top (ZANUSSI) - Series N900



ALPENINOX 0C0597

ELECTROLUX 0C0597

ZANUSSI 0C0597

**3241442 BLACK KNOB RING NUT 120-190°C**  
for Fryer gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0623

ELECTROLUX 0C0623

ZANUSSI 0C0623

**3241422 BLACK KNOB RING NUT 30-90°C**  
for Bain-marie gas (ZANUSSI) PBV/G2



ALPENINOX 0C0503

ELECTROLUX 0C0503

ZANUSSI 0C0503

**3241761 BLACK KNOB SILK-SCREEN PRINTED**  
D shaft hole 6x4.6 mm  
for THERMOSTATIC GAS VALVE



AMBASSADE 88044009

**3241763 KNOB RED RING Ø 55 mm**



AMBASSADE 65043001



Suitable for:

# Knobs



Suitable for:

## 3241762 BLACK KNOB SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for GAS VALVE



AMBASSADE 88044006

## 3241765 BLACK KNOB SILK-SCREEN PRINTED

D shaft hole 6x4.6 mm  
for selector switch



AMBASSADE 88044002

## 3241760 KNOB RED RING



AMBASSADE 65043002

## 3241828 BLACK KNOB SILK-SCREEN PRINTED

for GAS VALVE JUNKERS



THIRODE 310291

THIRODE 310292

## 3241218 KNOB FASTENING SCREW $\varnothing$ 6x32 mm thread M3



AMBACH 3009600005

## 3241751 BLACK KNOB 0-1-2-3

D shaft hole 6x4,6 mm  
for selector switch



THIRODE 308075

## 3241729 BLACK KNOB 1-10

D shaft hole 6x4.6 mm  
for GAS VALVE GS Robertsshaw



ROBERTSHAW R-Z34620-77

## 3241769 BLACK KNOB 120 MINUTES with dial



## 3241735 BLACK KNOB 2-3-4-5-6-7-8 for GAS VALVE GC1300



BONNET 7479045

CAPIC G652221

SOLYMAC P72D



# Knobs



Suitable for:

Suitable for:

**3241168 BLACK KNOB 38x38 mm**  
square hole 3x3 mm



ARISTARCO 2686

ELETTROBAR 999044

**3241193 BLACK KNOB 46x51 mm**  
old type  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0189

ELECTROLUX 0C0189

ZANUSSI 0C0189

**3241190 BLACK KNOB RING NUT 110-270°C**  
for Pot stove gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0194

ELECTROLUX 0C0194

ZANUSSI 0C0194

**3241425 BLACK KNOB RING NUT 110-270°C**  
for Bratt pan (ZANUSSI) - Series N700  
for Fry top (ZANUSSI) - Series N900



ALPENINOX 0C0597

ELECTROLUX 0C0597

ZANUSSI 0C0597

**3241442 BLACK KNOB RING NUT 120-190°C**  
for Fryer gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0623

ELECTROLUX 0C0623

ZANUSSI 0C0623

**3241422 BLACK KNOB RING NUT 30-90°C**  
for Bain-marie gas (ZANUSSI) PBV/G2



ALPENINOX 0C0503

ELECTROLUX 0C0503

ZANUSSI 0C0503

**3241197 BLACK KNOB 46x51 mm**  
D-shaped hole 8x6.5 mm  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0191

ELECTROLUX 0C0191

ZANUSSI 0C0191

**3241801 FASTENING RING - 10 PCS**



ALPENINOX 0C6288

ELECTROLUX 069567

ALPENINOX 069567

ZANUSSI 0C6288

ELECTROLUX 0C6288

ZANUSSI 069567



Suitable for:

**3241195 KNOB RING NUT ø 84 mm SILK-SCREEN PRINTE**  
for Fry top (ZANUSSI) - Series N700 - Series N900  
for Lava rock grill (ZANUSSI) - Series N700  
for Pasta cooker (ZANUSSI) - Series N900  
for Pot stove (ZANUSSI) - Series N700  
for Solid top range (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0193

ELECTROLUX 0C0193

ZANUSSI 0C0193

# Knobs



Suitable for:

**3241196 KNOB RING NUT ø 84 mm SILK-SCREEN PRINTE**  
for Grill electric (ZANUSSI) - Series N900  
for Grill gas (ZANUSSI) - Series N700  
Series N900  
for Pot stove gas (ZANUSSI) - Series N700  
Series N900  
for Solid top range gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0192

ELECTROLUX 0C0192

ZANUSSI 0C0192

**3241266 BLACK KNOB 46x51 mm**  
D-shaped pin ø 6x4.6 mm  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0257

ELECTROLUX 0C0257

ZANUSSI 0C0257

**3241439 KNOB RING NUT ø 84 mm SCREEN-PRINTED**  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0259

ELECTROLUX 0C0259

ZANUSSI 0C0259

**3241445 KNOB RING NUT ø 84 mm SILK-SCREEN PRINTE**  
for Boiling pan (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0711

ELECTROLUX 0C0711

ZANUSSI 0C0711

**3241449 KNOB RING NUT ø 84 mm 0-1-0-1**  
for Bain-marie (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0518

ELECTROLUX 0C0518

ZANUSSI 0C0518

**3241479 KNOB RING NUT ø 84 mm 0-1-2-3**  
for Pasta cooker electric (ZANUSSI) PCP/E1SH  
PCP/E2SH



ALPENINOX 0C0560

ELECTROLUX 0C0560

ZANUSSI 0C0560

**3241468 KNOB RING NUT ø 84 mm 1-2-3-4-5-6**  
for Pasta cooker (ZANUSSI) - Series N700  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0307

ELECTROLUX 0C0307

ZANUSSI 0C0307



Suitable for:

**3241507 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6**  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0304

ELECTROLUX 0C0304

ZANUSSI 0C0304

**3241469 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6-7-8**  
for Pasta cooker electric (ZANUSSI) PCP/E1SH  
PCP/E2SH



ALPENINOX 0C0318

ALPENINOX 0C03187

ELECTROLUX 0C0318

ELECTROLUX 0C03187

ZANUSSI 0C0318

ZANUSSI 0C03187

**3241436 KNOB RING NUT  $\varnothing$  84 mm 105-185°C**  
for Fryer (ZANUSSI) - Series N700



ALPENINOX 0C0615

ELECTROLUX 0C0615

ZANUSSI 0C0615

**3241427 KNOB RING NUT  $\varnothing$  84 mm 30-90°C**  
for Bain-marie (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0515

ELECTROLUX 0C0515

ZANUSSI 0C0515

## Knobs



Suitable for:

**3241424 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6-7-8**  
for Boiling pan (ZANUSSI) - Series N900  
for Pasta cooker (ZANUSSI) - Series N700  
for Pot stove (ZANUSSI) - Series N700



ALPENINOX 0C0317

ALPENINOX 0C0317

ELECTROLUX 0C0317

ELECTROLUX 0C3017

ZANUSSI 0C0317

ZANUSSI 0C3017

**3241478 KNOB RING NUT  $\varnothing$  84 mm 100-300°C**  
for Oven under cooktop (ZANUSSI) PCF/M2 - PCF/M3



ALPENINOX 0C0258

ELECTROLUX 0C0258

ZANUSSI 0C0258

**3241426 KNOB RING NUT  $\varnothing$  84 mm 120-280°C**  
for Fry top (ZANUSSI) PR/E1FL - PR/E1FR - PR/E2FL



ALPENINOX 0C0466

ELECTROLUX 0C0466

ZANUSSI 0C0466



Suitable for:

# Knobs



**3241437 BLACK KNOB 46x51 mm**  
 D shaft hole 10x8 mm  
 for Bratt pan (ZANUSSI) - Series N700  
 Series N900  
 for Fry top (ZANUSSI) - Series N700 - Series N900  
 for Grill (ZANUSSI) - Series N700 - Series N900  
 for Pasta cooker (ZANUSSI) - Series N700  
 Series N900



ALPENINOX 0C0465

ELECTROLUX 0C0465

ZANUSSI 0C0465

**3241196 KNOB RING NUT ø 84 mm SILK-SCREEN PRINTE**  
 for Grill electric (ZANUSSI) - Series N900  
 for Grill gas (ZANUSSI) - Series N700  
 Series N900  
 for Pot stove gas (ZANUSSI) - Series N700  
 Series N900  
 for Solid top range gas (ZANUSSI) - Series N700  
 Series N900



ALPENINOX 0C0192

ELECTROLUX 0C0192

ZANUSSI 0C0192

**3241708 BLACK KNOB 46x51 mm**  
 new type  
 D shaft hole 8x6.5 mm  
 for Bratt pan (ZANUSSI) - Series N700  
 Series N900  
 for Fry top (ZANUSSI) - Series N700 - Series N900  
 for Fryer (ZANUSSI) - Series N700 - Series N900



ALPENINOX 0C5251

ELECTROLUX 0C5251

ZANUSSI 0C5251

**3241771 BLACK KNOB 48H**  
 with dial



**3241770 BLACK KNOB 6H**  
 with dial



**5054851 BLACK RING SILKSCREENED F/KNOB ø 94 mm**  
 REAR  
 for Pot stove (MARENO)  
 Series 700 PROTAGONISTA NUOVA  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0583990

**3241940 BLACK RING 0-1 KNOB ø 94 mm 0-1-0-1**  
 for Bain-marie (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA



MARENO CR0585780



# Knobs



Suitable for:

**3241922 BLACK TAP KNOB  $\varnothing$  81 mm**  
round hole  $\varnothing$  16 mm - fixing hole 7.5x5 mm  
for Food-service trolley (BLANCO) SAG2 - SAG3



BLANCO 362309

Suitable for:

**3241921 BLACK KNOB CAP**  
for Food-service trolley (BLANCO) SAG2 - SAG3  
SGE3 ECOLINE



BLANCO 146781

**3241803 BLACK-BLUE KNOB  $\varnothing$  75mm SILK-SCREEN PRINT**  
D shaft hole 10x8 mm  
for Pasta cooker electric (DESCO) 9CPE2



DESCO 60817

DESCO 62317

**3241153 BLACK-GREEN KNOB  $\varnothing$  75 mm**  
D shaft hole 6x4.6 mm  
for Fry top (GIGA) - Series 900



GIGA 0000Y04400

**3241543 BLACK-RED KNOB  $\varnothing$  68 mm SILK-SCREEN PRINT**  
D shaft hole 8x6.5 mm  
for Fry top (DOSILET) - Series CHEF



DOSILET 400010006

**3241546 BLACK-RED KNOB  $\varnothing$  70 mm SILK-SCREEN PRINT**  
D shaft hole 8x6.5 mm  
for Bratt pan (DOSILET) BR80 - 98Q  
for Pot stove gas (LOTUS) - Series 550  
Series 700 - Series 900



LOTUS 536019800

LOTUS 536019800+...

**3241549 BLACK-RED KNOB  $\varnothing$  70 mm SILK-SCREEN PRINT**  
D shaft hole 8x6.5 mm



LOTUS 536019800+

**3241802 BLACK-RED KNOB  $\varnothing$  75 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for Pasta cooker electric (DESCO) 7CPE1 - 7CPE2  
9CPE1 - 9CPE2



DESCO 60806

DESCO 62306

**3241804 BLACK-RED KNOB  $\varnothing$  75 mm 30-90°C**  
D shaft hole 6x4.6 mm  
for Bain-marie electric (DESCO) 7BME1P - 7BME2P  
9BME1P - 9BME2P



DESCO R\_62316

DESCO 62316

**3241308 BLACK-RED KNOB SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (ANGELO PO) - Series ALPHA  
Series DELTA - Series GAMMA



ANGELO PO 6300518

ANGELO PO 6300521



Suitable for:

# Knobs



**3241488 BLACK-RED KNOB SILK-SCREEN PRINTED**  
 D-shaped pin  $\varnothing$  6x4.6 mm  
 for Boiling pan (ANGELO PO) - Series DELTA  
 for Pasta cooker (ANGELO PO) - Series DELTA  
 Series OMEGA  
 for Pot stove (ANGELO PO) - Series DELTA  
 Series OMEGA



ANGELO PO 6300485

**3241489 BLACK-RED KNOB SILK-SCREEN PRINTED**  
 D shaft hole 10x9 mm  
 for Pot stove (ANGELO PO) - Series ALPHA  
 Series BIFRONTÉ - Series DELTA - Series GAMMA



ANGELO PO 6300489

**3241493 BLACK-RED KNOB SILK-SCREEN PRINTED**  
 D shaft hole 6x4.6 mm  
 for Oven under cooktop (ANGELO PO) - Series ALPHA  
 Series DELTA



ANGELO PO 6300484

**3241498 BLACK-RED KNOB SILK-SCREEN PRINTED**  
 D shaft hole 6x4.6 mm  
 for Fryer (ANGELO PO) - Series ALPHA  
 Series BIFRONTÉ - Series DELTA - Series GAMMA



ANGELO PO 6300481

**3241805 BLACK-RED KNOB SILK-SCREEN PRINTED**  
 D shaft hole 10x8.5 mm  
 for Boiling pan gas (ANGELO PO) 1A1PI2G - 1A1PI2GA  
 1D1PI2G - 1D1PI2GA - 2A1PD3G - 2A1PI3G  
 for Pasta cooker (ANGELO PO) MCF20 - MCF40  
 for Pasta cooker gas (ANGELO PO) 1A1CP1GA  
 1D1CP1GA - 191CP1GA



ANGELO PO 6300523

**3241494 BLACK-RED KNOB 1-2-3-4-5-6-7-8**  
 D shaft hole 6x4.6 mm  
 for Bratt pan (ANGELO PO) - Series ALPHA  
 Series DELTA - Series GAMMA



ANGELO PO 6300493

**3241486 BLACK-RED KNOB 100-270°C**  
 D shaft hole 6x4.6 mm  
 for Fry top electric (ANGELO PO) - Series ALPHA  
 Series DELTA - Series GAMMA - Series OMEGA



ANGELO PO 6300492

**3241495 BLACK-RED KNOB 100-270°C**  
 D shaft hole 6x4.6 mm  
 for Bratt pan (ANGELO PO) - Series ALPHA  
 Series DELTA - Series GAMMA



ANGELO PO 6300491





# Knobs



Suitable for:

**3241496 BLACK-RED KNOB 100-280°C**  
D shaft hole 10x9 mm  
for Fry top gas (ANGELO PO) - Series ALPHA  
Series BIFRONTE - Series DELTA - Series GAMMA



ANGELO PO 6300504

Suitable for:

**3241772 BLACK-RED KNOB 100-280°C**  
D shaft hole 8x6.5 mm  
for Bratt pan gas (ANGELO PO) 0G1BR3G - 1G1BR3G  
for Fry top gas (ANGELO PO) 0A0FT1G - 0A0FT2G  
0A0FT4G - 0A0FT5G - 0D0FT1G - 0D0FT2G  
0D0FT4G - 0D0FT5G - 1A0FT1G - 1A0FT2G  
1A0FT3G - 1A0FT4G - 1D0FT2G - 1D0FT3G  
1D0FT4G - 1D0FT6G



ANGELO PO 6300488

**3241487 BLACK-RED KNOB 100-300°C**  
D shaft hole 8x6.5 mm  
for Oven under cooktop (ANGELO PO) - Series ALPHA  
Series BIFRONTE - Series DELTA



ANGELO PO 6300510

**3241492 BLACK-RED KNOB 100-300°C**  
D shaft hole 8x6.5 mm  
for Oven under cooktop (ANGELO PO) - Series ALPHA  
Series DELTA - Series OMEGA



ANGELO PO 6300487

**3241499 BLACK-RED KNOB 100-300°C**  
D shaft hole 6x4.6 mm  
for Oven under cooktop (ANGELO PO) - Series ALPHA  
Series DELTA - Series OMEGA - Series SNACK



ANGELO PO 6300483

**3241491 BLACK-RED KNOB 110-190°C**  
D shaft hole 6x4.6 mm  
for Fryer (ANGELO PO) - Series ALPHA  
Series BIFRONTE - Series DELTA - Series GAMMA



ANGELO PO 6300480

**3241808 BLACK-RED KNOB 160-280°C**  
D shaft hole 8x6.5 mm  
for Pot stove gas (ANGELO PO) G1FAGS - G1FAGST  
1G1FAPG - 1G1FA0G - 1G1FA0GV - 1G1TP0G  
2G1FADG - 2G1FADGV - 2G1FAPG - 2G1FA0G  
2G1FA0GV - 2G1TP3G



ANGELO PO 6300553

**3241490 BLACK-RED KNOB 160-340°C**  
D shaft hole 10x9 mm  
for Fry top (ANGELO PO) - Series ALPHA  
Series BIFRONTE - Series DELTA - Series GAMMA



ANGELO PO 6300503



Suitable for:

# Knobs



**3241497 BLACK-RED KNOB 30-100°C**  
D shaft hole 8x6.5 mm  
for Bain-marie gas (ANGELO PO) - Series ALPHA  
Series DELTA



ANGELO PO 6300486

**3241500 BLACK-RED KNOB 30-100°C**  
D shaft hole 6x4.6 mm  
for Bain-marie electric (ANGELO PO) - Series ALPHA  
Series BIFRONTI - Series DELTA - Series GAMMA



ANGELO PO 6300482

**3241644 BLUE KNOB**



ANGELO PO 36M2630

ANGELO PO 36M2631

ANGELO PO 36M4030

COLUSSI 051610030

**3241731 BLUE KNOB**  
square hole 7x7 mm  
for GAS TAP



BONNET

**40C5254 BLUE KNOB ø 60 mm 110-190°C**  
D-shaped hole 8x6.5 mm  
for Fryer (ZANUSSI)



ALPENINOX 0C5254

ELECTROLUX 0C5254

ZANUSSI 0C5254

**3241529 BLUE KNOB ø 70 mm 0-1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Kitchen electric (MBM) E4F6  
for Pot stove electric (MBM) E26 - E27 - E27Q  
E4F7 - E4F7Q - E46 - E47 - E47Q - E6FA7  
E6FA7Q - E66 - E67 - E67Q



MBM RTCU700346

MBM RTCU700403

MBM 168877

**3241918 BLUE TAP KNOB ø 82 mm**  
round hole ø 16 mm - fixing hole 7.5x5 mm  
for Food-service trolley (BLANCO) SGE3 ECOLINE



BLANCO 295551

**3241921 BLACK KNOB CAP**  
for Food-service trolley (BLANCO) SAG2 - SAG3  
SGE3 ECOLINE



BLANCO 146781

**3241919 RING NUT ADAPTER FOR HANDLE**  
hole 7.5x5 mm  
for Food-service trolley (BLANCO) SAG2 - SAG3  
SGE3 ECOLINE



BLANCO 297909



# Knobs



Suitable for:

**3241690 BURNER BLACK KNOB**  
 D-shaped hole 8x6 mm  
 for Broiler (GARLAND) BR-3 4-3/GTC  
 for Oven under cooktop (GARLAND)



GARLAND 1089100

Suitable for:

**5035322 CHROME-PLATED BUSHING FOR KNOB ø 72 mm**  
 for Bain-marie (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Boiling pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Bratt pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Fry top (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA  
 for Oven under cooktop (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Pasta cooker (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Pot stove (MARENO)  
 Series 1100 PROTAGONISTA NUOVA



MARENO CR0580460

ROSINOX RX94812686

**3241801 FASTENING RING - 10 PCS**



ALPENINOX 0C6288  
ELECTROLUX 069567

ALPENINOX 069567  
ZANUSSI 0C6288

ELECTROLUX 0C6288  
ZANUSSI 069567

**3241055 FIXING CLIP**  
 for knob with ø 8 mm hole



ALPENINOX 025245  
EGO 0000607007  
FOEMM 0000022001  
STAR 10 063009

ANGELO PO 3170290  
ELECTROLUX 025245  
GIORIK 5900242  
WHIRLPOOL 153816

EGO 607007  
EMMEPI C00196  
SILKO 0101455  
ZANUSSI 025245

**3241883 FIXING KNOB CAP**



THIRODE 381285

**3241910 GAS TAP KNOB**  
 square hole 16x16 mm  
 for Bratt pan electric (ROSINOX) MBM80E - SBM50E  
 for Bratt pan gas (ROSINOX) MBM80G - SBM50G  
 for Fry top gas (ROSINOX) GR20G  
 for Pot stove gas (ROSINOX) 120MFNDET - 121G



ROSINOX RX94030939

**3241909 KNOB CAP FOR GAS TAP**  
 square cap 16x16 mm  
 D shaft hole 6x4.6 mm  
 for Bratt pan (ZANUSSI) SBM50G  
 for Bratt pan electric (ROSINOX) MBM80E - SBM50E  
 for Bratt pan gas (ROSINOX) MBM80G  
 for Fry top electric (ROSINOX) GR20E  
 for Fry top gas (ROSINOX) GR20G  
 for Pot stove (ROSINOX) 120M FNDET  
 for Pot stove gas (ROSINOX) 121G



ROSINOX RX94006830



Suitable for:

**3241914 KNOB CAP FOR WATER TAP**  
square cap 16x16 mm  
ø hole 8 mm  
for Bratt pan electric (ROSINOX) SBM35E  
for Bratt pan gas (ROSINOX) SBM50G



ROSINOX RX94006871

## Knobs



Suitable for:

**3241916 KNOB CAP RING NUT ø 46 mm**  
for Bratt pan gas (ROSINOX) MBM80G  
for Pot stove (ROSINOX) 120M FNDET



ROSINOX RX94030277

**3241119 GASKET FOR KNOB**  
for Solid top range gas (ZANUSSI) - Series 701



ALPENINOX 054108

ELECTROLUX 054108

ZANUSSI 054108

**3241398 GASKET FOR KNOB HOLE ø 8 mm**  
external ø 70 mm - central hole ø 8 mm



ANGELO PO 3152250

**3241385 GASKET FOR KNOB PIN 6x4.6 mm**  
ø external 17 mm - thickness 1,8 mm



ANGELO PO 3150790

**3241399 GASKET FOR KNOB PIN 6x4.6 mm**  
external ø 17 mm - thickness 4 mm



ANGELO PO 3152240

**3241885 GASKET FOR SELECTOR SWITCH KNOB**  
ø external 39 mm - ø internal 13 mm  
for Fryer gas (THIRODE) FR25G



THIRODE 366369

**3241229 GREEN KNOB ø 50 mm**  
D shaft hole 6x4.6 mm  
for Fryer (MARENO) FQE



MARENO MA1036700700

MARENO 1036700700

**3241251 GREEN KNOB ø 50 mm**  
D shaft hole 6x4.6 mm  
for Lava rock grill gas (MARENO) - Series PLG



MARENO MA1036700300

**3241777 GREY KNOB SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove gas (COMETTO)



COMETTO 64910



# Knobs



Suitable for:

**3241778 GREY KNOB**  
D shaft hole 6x4.6 mm  
for Pot stove electric (COMETTO)



COMETTO 64915

Suitable for:

**3241352 GREY KNOB ø 28 mm**  
round hole ø 6.4 mm  
with shaft locking bolt  
for Food-service trolley (RIEBER) LWB



RIEBER 33353025

**3241766 GREY KNOB ø 28 mm**  
square hole 5x5 mm  
for selector switch




**3241593 GREY KNOB ø 39 mm**  
D shaft hole 6x4.6 mm  
for Fryer electric (FAGOR) FE-18 - FE-25 - FE-4  
FE-6 - FE-8



FAGOR R343043000

FAGOR Z204504000

**3241615 GREY KNOB ø 49 mm**  
D shaft hole 6x4.6 mm  
for Salamander (GIORIK)



EMMEPI 8C1602

GIORIK 2006823

**3241069 GREY KNOB ø 55 mm 0-120°C**  
D-shaped hole 6x4.6 mm  
for Food-service trolley electric (ZANUSSI)  
for Warm table electric (ZANUSSI)



ALPENINOX 0C3022  
ELECTROLUX 0C3022  
ZANUSSI 0C3022

ALPENINOX 003844  
ELECTROLUX 003844  
ZANUSSI 003844

ALPENINOX 075543  
ELECTROLUX 075543  
ZANUSSI 075543

**3186342 GASKET FOR OVEN**  
soft - external ø 13,5 mm



ALPENINOX 053816  
WHIRLPOOL 125245

ELECTROLUX 053816  
ZANUSSI 053816

WHIRLPOOL 771985002739

**3241104 GREY KNOB ø 55 mm 120-330°C**  
D shaft hole 8x6.5 mm  
for Oven under cooktop (ZANUSSI) NUOVA SERIE 700



ALPENINOX 059249

ELECTROLUX 059249

ZANUSSI 059249

**3241038 GREY KNOB ø 60 mm SILK-SCREEN PRINTED**  
D-shaped hole 10x8 mm  
for COOKING RANGE series 110



ERRE 2 790109350  
GICO 790109350

GICO 766100000  
GICO 790119450

GICO 790106610



# Knobs



Suitable for:

**3241147 GREY KNOB ø 60 mm SILK-SCREEN PRINTED**  
D-shaped hole 8x6.5 mm  
for Pot stove (GICO) - Series 500 - Series 700  
Series 900 - Series 920



GICO 766100010  
GICO 790119460

GICO 790106620

GICO 790109340

Suitable for:

**3241144 KNOB BLACK INSERT**  
external ø 72 mm



GICO 290202440

**3241139 KNOB RING RED**  
external ø 72 mm



GICO 290202350

**3241143 KNOB SPRING ø 42x26 mm**



GICO 290202430

**3241539 GREY KNOB ø 60 mm 1-2-3**  
D-shaped hole 6x4.6 mm  
for Pot stove electric (GICO) - Series 110  
Series 500 - Series 900 - Series 920



GICO 766100050  
GICO 790119510

GICO 790106910

GICO 790109370

**3241538 GREY KNOB ø 60 mm 1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Pot stove electric (GICO) - Series 64  
Series 700



GICO 766100070

GICO 790119520

**3241199 GREY KNOB ø 70 mm COLD WATER**  
D shaft hole 10x8 mm  
for Boiling pan (ZANUSSI) - Series HD900  
for Pasta cooker (ZANUSSI) - Series HD900



ALPENINOX 059531

ELECTROLUX 059531

ZANUSSI 059531

**3241103 GREY KNOB ø 70 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove gas (ZANUSSI) - Series HD900



ALPENINOX 059244

ELECTROLUX 059244

ZANUSSI 059244

**3241109 GREY KNOB ø 70 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove gas (ZANUSSI) - Series HD700



ALPENINOX 058534  
WHIRLPOOL 158534

ELECTROLUX 058534  
ZANUSSI 058534

WHIRLPOOL 771985003561

**3241110 GREY KNOB ø 70 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove gas (ZANUSSI) - Series NUOVA 700



ALPENINOX 058561

ELECTROLUX 058561

ZANUSSI 058561



# Knobs



Suitable for:

**3241198 GREY KNOB ø 70 mm 0-1-2-3**  
D shaft hole 6x4.6 mm  
for Pasta cooker electric (ZANUSSI) - Series PR700



ALPENINOX 059546

ELECTROLUX 059546

ZANUSSI 059546

Suitable for:

**3241113 GREY KNOB ø 70 mm 110-190°C**  
D shaft hole 10x8 mm  
for Fryer (ZANUSSI) - Series HD700



ALPENINOX 003392

ELECTROLUX 003392

WHIRLPOOL 103392

**3241210 GREY KNOB ø 70 mm 120-300°C**  
D shaft hole 6x4.6 mm  
for Bratt pan gas (ZANUSSI) - Series HD900



ALPENINOX 002104

ELECTROLUX 002104

ZANUSSI 002104


**3241133 GREY KNOB ø 71 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Fry top gas (FAGOR) FTG-905 - FTG-910  
FTG-911CL - FTG-911CR - FTG-911L - FTG-911R  
for Kitchen gas (FAGOR) CG-740 - CG-741 - CG-761  
CG-982 - CGE-741  
for Pot stove gas (FAGOR) CG-720 - CG-920 - CG-940  
CG-941 - CG-960 - CG-961



FAGOR U542100000

FAGOR U542101000

**3241234 GREY KNOB ø 71 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Lava rock grill (FAGOR) - Series 700  
Series 900



FAGOR S312102000

FAGOR S312110000

**3241785 GREY KNOB ø 71 mm 0-90°C**  
D shaft hole 6x4,6 mm  
for Bain-marie (WHIRLPOOL) ABG532 - AGB453  
AGB454 - AGB531 - AGB591



GIGA Y65000

GIGA Y65014

GIGA 0000Y65014

WHIRLPOOL 483286009188

**3241599 GREY KNOB ø 71 mm 1-2-3-4-5-6-7**  
D-shaped hole 8x6 mm  
for Oven under cooktop electric (FAGOR)



FAGOR U842101000

FAGOR U842102000

**3241238 GREY KNOB ø 71 mm 12-3-4-5-6-7-8**  
D shaft hole 8x6 mm  
for Pot stove (FAGOR) - Series 700 - Series 900  
for Solid top range (FAGOR) - Series 700  
Series 900



FAGOR R202103000

FAGOR R202106000

FAGOR R202130000



# Knobs



Suitable for:

**3241610 GREY KNOB  $\varnothing$  76 mm 100-180°C**  
D shaft hole 6x4.6 mm  
for Fryer (OLIS) - Series 700 - Series 900



METOS BN2994380 METOS 2994380 OLIS BN2994380

Suitable for:

**3241132 GREY KNOB  $\varnothing$  77 mm SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove gas (OLIS) - Series 900



BARTSCHER 018270 METOS 2599001 METOS BN2599001  
OLIS 2599001 OLIS BN2599001

**3241232 GREY KNOB  $\varnothing$  77 mm 1-2-3-4-5-6**  
D shaft hole 6x4.6 mm  
for Hot plate electric (OLIS)



BARTSCHER 023855 EBERHARDT 209525 METOS 2994360  
METOS BN2994360 METOS 2599013 OLIS 2599013  
OLIS 2994360 OLIS BN2994360

**3241837 GREY KNOB  $\varnothing$  78 mm 1-2-3-4-5-6-7-8**  
D shaft hole 10x8 mm  
for Fry top gas (OLIS) 714TFG - 74TFTG - 78FTG  
78TFTG



BARTSCHER 02599006 METOS 2599006 METOS BN2599006  
OLIS 2599006 OLIS BN2599006

**3241145 GREY KNOB  $\varnothing$  77 mm 50-300°C**  
D shaft hole 6x4.6 mm  
for Bratt pan gas (OLIS) 94KBG



METOS BN2994340 METOS 2599011 METOS 2994340  
OLIS BN2994340 OLIS 2599011 OLIS 2994340

**3241263 GREY KNOB SILK-SCREEN PRINTED**  
D shaft hole 10x8 mm  
for Pot stove (ZANUSSI) - Series 900



ALPENINOX 0A2460 ELECTROLUX 0A2460 ZANUSSI 0A2460

**3241923 GREY TAP KNOB  $\varnothing$  46.5 mm**  
round hole  $\varnothing$  6 mm  
for Food-service trolley (BLANCO) SAG2



BLANCO 146442

**3241724 INDEXED PLATE  $\varnothing$  70 mm 0-100**  
for energy regulator



CAPIC E402710 CHARVET 02021A ROSINOX

**3241709 KNOB ADAPTER  $\varnothing$  27 mm**  
D shaft hole 8x6.5 mm



ALPENINOX 0C5400 ELECTROLUX 0C5400 ZANUSSI 0C5400

**3241144 KNOB BLACK INSERT**  
external  $\varnothing$  72 mm



GICO 290202440






# Knobs



Suitable for:

Suitable for:

## 3241157 KNOB BLUE STICKER



EBERHARDT 222195

SILKO 0101940

SILKO 1036609200

## 3241108 KNOB CAP



ALPENINOX 025255

ELECTROLUX 054367

ZANUSSI 025255

ALPENINOX 054367

WHIRLPOOL 154367

ZANUSSI 054367

ELECTROLUX 025255

WHIRLPOOL 771985002945

## 3241909 KNOB CAP FOR GAS TAP

square cap 16x16 mm  
D shaft hole 6x4.6 mm  
for Bratt pan (ZANUSSI) SBM50G  
for Bratt pan electric (ROSINOX) MBM80E - SBM50E  
for Bratt pan gas (ROSINOX) MBM80G  
for Fry top electric (ROSINOX) GR20E  
for Fry top gas (ROSINOX) GR20G  
for Pot stove (ROSINOX) 120M FNDET  
for Pot stove gas (ROSINOX) 121G



ROSINOX RX94006830

## 3241914 KNOB CAP FOR WATER TAP

square cap 16x16 mm  
ø hole 8 mm  
for Bratt pan electric (ROSINOX) SBM35E  
for Bratt pan gas (ROSINOX) SBM50G



ROSINOX RX94006871

## 3241916 KNOB CAP RING NUT ø 46 mm

for Bratt pan gas (ROSINOX) MBM80G  
for Pot stove (ROSINOX) 120M FNDET



ROSINOX RX94030277

## 3241082 KNOB EXTENSION



EBERHARDT 212475

SILKO 9201543

## 3241141 KNOB EXTENSION

D-shaped hole 10x8 mm  
for gas valve  
for OVEN-FRYER



ALPENINOX 059305

ZANUSSI 059305

ELECTROLUX 059305

WHIRLPOOL 159305

## 3241596 KNOB EXTENSION

D-shaped pin 6x8 mm  
for EUROSIT



FAGOR U842100000



# Knobs



Suitable for:

**3241218** **KNOB FASTENING SCREW**  $\varnothing$  6x32 mm  
thread M3



AMBACH 300960005

Suitable for:

**3241929** **KNOB FOR VALVES**  
for EUROPEAN MARKET



ROBERTSHAW R-82112

**3241142** **KNOB GASKET**  $\varnothing$  44 mm



ALPENINOX 059326  
ZANUSSI 059326

ELECTROLUX 059326

WHIRLPOOL 159326

**3241760** **KNOB RED RING**



AMBASSADE 65043002

**3241763** **KNOB RED RING**  $\varnothing$  55 mm



AMBASSADE 65043001

**3241692** **KNOB RING**  $\varnothing$  59 mm 150-500°C



GARLAND G02725-16

**3241439** **KNOB RING NUT**  $\varnothing$  84 mm **SCREEN-PRINTED**  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0259

ELECTROLUX 0C0259

ZANUSSI 0C0259

**3241195** **KNOB RING NUT**  $\varnothing$  84 mm **SILK-SCREEN PRINTE**  
for Fry top (ZANUSSI) - Series N700 - Series N900  
for Lava rock grill (ZANUSSI) - Series N700  
for Pasta cooker (ZANUSSI) - Series N900  
for Pot stove (ZANUSSI) - Series N700  
for Solid top range (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0193

ELECTROLUX 0C0193

ZANUSSI 0C0193

**3241196** **KNOB RING NUT**  $\varnothing$  84 mm **SILK-SCREEN PRINTE**  
for Grill electric (ZANUSSI) - Series N900  
for Grill gas (ZANUSSI) - Series N700  
Series N900  
for Pot stove gas (ZANUSSI) - Series N700  
Series N900  
for Solid top range gas (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0192

ELECTROLUX 0C0192

ZANUSSI 0C0192

**3241445** **KNOB RING NUT**  $\varnothing$  84 mm **SILK-SCREEN PRINTE**  
for Boiling pan (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0711

ELECTROLUX 0C0711

ZANUSSI 0C0711




# Knobs



Suitable for:

**3241449 KNOB RING NUT  $\varnothing$  84 mm 0-1-0-1**  
for Bain-marie (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0518 ELECTROLUX 0C0518 ZANUSSI 0C0518

Suitable for:

**3241479 KNOB RING NUT  $\varnothing$  84 mm 0-1-2-3**  
for Pasta cooker electric (ZANUSSI) PCP/E1SH  
PCP/E2SH



ALPENINOX 0C0560 ELECTROLUX 0C0560 ZANUSSI 0C0560

**3241468 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6**  
for Pasta cooker (ZANUSSI) - Series N700  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0307 ELECTROLUX 0C0307 ZANUSSI 0C0307

**3241507 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6**  
for Pot stove (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0304 ELECTROLUX 0C0304 ZANUSSI 0C0304

**3241424 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6-7-8**  
for Boiling pan (ZANUSSI) - Series N900  
for Pasta cooker (ZANUSSI) - Series N700  
for Pot stove (ZANUSSI) - Series N700



ALPENINOX 0C0317 ALPENINOX 0C3017 ELECTROLUX 0C0317  
ELECTROLUX 0C3017 ZANUSSI 0C0317 ZANUSSI 0C3017

**3241469 KNOB RING NUT  $\varnothing$  84 mm 1-2-3-4-5-6-7-8**  
for Pasta cooker electric (ZANUSSI) PCP/E1SH  
PCP/E2SH



ALPENINOX 0C0318 ALPENINOX 0C03187 ELECTROLUX 0C0318  
ELECTROLUX 0C03187 ZANUSSI 0C0318 ZANUSSI 0C03187

**3241478 KNOB RING NUT  $\varnothing$  84 mm 100-300°C**  
for Oven under cooktop (ZANUSSI) PCF/M2 - PCF/M3



ALPENINOX 0C0258 ELECTROLUX 0C0258 ZANUSSI 0C0258

**3241436 KNOB RING NUT  $\varnothing$  84 mm 105-185°C**  
for Fryer (ZANUSSI) - Series N700



ALPENINOX 0C0615 ELECTROLUX 0C0615 ZANUSSI 0C0615

**3241426 KNOB RING NUT  $\varnothing$  84 mm 120-280°C**  
for Fry top (ZANUSSI) PR/E1FL - PR/E1FR - PR/E2FL



ALPENINOX 0C0466 ELECTROLUX 0C0466 ZANUSSI 0C0466

**3241427 KNOB RING NUT  $\varnothing$  84 mm 30-90°C**  
for Bain-marie (ZANUSSI) - Series N700  
Series N900



ALPENINOX 0C0515 ELECTROLUX 0C0515 ZANUSSI 0C0515



Suitable for:

# Knobs



## 3241935 KNOB RING NUT ø 94 mm SCREEN-PRINTED

for Oven under cooktop (MARENO)  
900 PROTAGONISTA NUOVA



MARENO CR0682861

Suitable for:

## 5053767 KNOB RING NUT ø 94 mm SCREEN-PRINTED

for Boiling pan (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0682580

## 5054850 KNOB RING NUT ø 94 mm SCREEN-PRINTED

FRONT  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA  
Series 700 PROTAGONISTA NUOVA  
Series 900 PROTAGONISTA NUOVA  
for Solid top range (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0583980

## 3241941 KNOB RING NUT ø 94 mm 0-1-2-3

for Pasta cooker (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0584030

## 3241937 KNOB RING NUT ø 94 mm 0-1-2-3-4-5-6

FRONT  
for Pot stove (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0585830

## 5050567 KNOB RING NUT ø 94 mm 0-1-2-3-4-5-6

REAR  
for Pot stove (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0585820

## 5053765 KNOB RING NUT ø 94 mm 1-2-3-4-5

for Boiling pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pasta cooker (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0589870

## 3241939 KNOB RING NUT ø 94 mm 100-285°C

for Bratt pan (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0685100



# Knobs



Suitable for:

**5035321 KNOB RING NUT  $\varnothing$  94 mm 100-300°C**  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA



MARENO CR0584000

Suitable for:

**5048040 KNOB RING NUT  $\varnothing$  94 mm 110-280°C**  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0584020

**3241938 KNOB RING NUT  $\varnothing$  94 mm 90-280°C**  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0585150

**3241887 KNOB RING NUT SILK-SCREEN PRINTED**  
for Pot stove (CAPIC) W290113



CAPIC Q104224

**3241139 KNOB RING RED**  
external  $\varnothing$  72 mm



GICO 290202350

**3241143 KNOB SPRING  $\varnothing$  42x26 mm**



GICO 290202430

**3241691 OVEN OPENING BLACK KNOB**  
D-shaft hole 8.5x6 mm  
for Broiler (GARLAND)  
for Oven under cooktop (GARLAND)



GARLAND 1089101

**3241318 PIN EXTENSION 28 mm**  
D-shaped hole  $\varnothing$  6x4,6 mm



EGO 4772028000

**3241088 RED INSERT FOR KNOB  $\varnothing$  32 mm**



ANGELO PO 36M2800

**3241643 RED KNOB**



ANGELO PO 36M2640  
COLUSSI 051610030

ANGELO PO 36M2641

ANGELO PO 36M4010



Suitable for:

# Knobs



**3241732 RED KNOB**  
square hole 7x7 mm  
for GAS VALVE



DEL RUE

Suitable for:

**3241642 RED KNOB ø 60 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6.5 mm  
for Pot stove (JEMI) - Series 1000 - Series 1300  
Series 550 - Series 600 - Series 700 - Series 750  
Series 900



JEMI 990602

**3241039 RED KNOB ø 65 mm 0-1-2-3-4-5-6-7-8**  
D shaft hole 8x7 mm  
for EGA COOKTOP OVEN valve



EMMEPI 806139

MBM RTCU700031

**3241154 RED KNOB ø 70 mm OFF-5-10-15**  
D shaft hole 6x4.6 mm  
for Toaster electric (BERTO'S) 12T - 6T



BERTO'S 30949200

BERTO'S 35876300

BERTO'S 35877500

**3241155 RED KNOB ø 70 mm SILK-SCREEN PRINTED**  
D shaft hole 8x6 mm  
for Pot stove (BERTO'S) - Series 700 - Series 900



BERTO'S 31952000  
BERTO'S 35877000

BERTO'S 35875800  
BERTO'S 35877200

BERTO'S 35876200  
BERTO'S 35877300

**3241342 RED KNOB ø 72 mm OFF 5-10-15**  
D-shaped hole 8x6 mm  
for Panini grill (BERTO'S) - Series 600  
Series 900



BERTO'S 30949200  
BERTO'S 35877200

BERTO'S 35876200  
BERTO'S 35877300

BERTO'S 35877000

**3241344 RED KNOB ø 72 mm 50-300°C**  
D shaft hole 8x6 mm  
for Panini grill (BERTO'S) - Series 600  
Series 900



BERTO'S 30654700  
BERTO'S 35877000  
ELETTROBAR B.30654500

BERTO'S 31953500  
BERTO'S 35877200

BERTO'S 35876200  
BERTO'S 35877300

**3241524 RED KNOB ø 75 mm 0-1-2-3-4-5-6-7-8**  
D-shaped hole 10x8 mm  
for Oven under cooktop (MBM)  
Series MAGIS MAGISTRA



MBM 164392

MBM 168855



# Knobs



Suitable for:

**3241526 RED KNOB  $\varnothing$  75 mm 50-300°C**  
D shaft hole 6x4.6 mm  
for Fry top electric (MBM) EFT45L - EFT45LC  
EFT45R - EFT45RC - EFT90L - EFT90LC - EFT90LR  
EFT90LRC - EFT90R - EFT90RC  
for Kitchen electric (MBM) E4F  
for Kitchen gas (MBM) G4SFE - G6SFEA



MBM 164389

Suitable for:

**3241185 RED KNOB  $\varnothing$  76 mm 1-2-3-4-5-6-7-8**  
D shaft hole 10x8 mm  
for Fry top (MBM)  
for Oven under cooktop (MBM)



MBM RTCU800018

**3241821 RED KNOB  $\varnothing$  76 mm 1-2-3-4-5-6-7-8**  
D shaft hole 6x4.6 mm  
for Bratt pan (MBM) MAGISTRA GBR - MAGISTRA GBRA



EMMEPI 830829

MBM RTBF800085

**3241127 RED KNOB  $\varnothing$  76 mm 50-300°C**  
D shaft hole 6x4.6 mm  
for Oven under cooktop (MBM) MAGISTRA



EMMEPI 807607

MBM RTCU700076

MBM RTCU800103

**3241697 RED KNOB FOR INLET TAP**



ANGELO PO 3162200

**3241734 RED KNOB STOP**  
for GAS VALVE GC1300




BONNET 7492056

CAPIC G652220

SOLYMAC P72J

**3241756 RING FOR KNOB  $\varnothing$  92 mm**



BOURGEOIS CLAV3008

SOLYMAC P1033

**3241919 RING NUT ADAPTER FOR HANDLE**  
hole 7.5x5 mm  
for Food-service trolley (BLANCO) SAG2 - SAG3  
SGE3 ECOLINE



BLANCO 297909

**3241846 SELECTOR SWITCH KNOB  $\varnothing$  64 mm**  
for Oven under cooktop (OLIS) - Series 1100  
Series 700 - Series 900



METOS BN2599207

METOS 2599207

OLIS BN2599207

OLIS 2599207



Suitable for:

# Knobs



**3241886 SELECTOR SWITCH KNOB  $\varnothing$  51 mm**  
round hole  $\varnothing$  6x4,6 mm - height 28 mm  
for Bratt pan gas (THIRODE) B9PSA50G  
for Pot stove (THIRODE) D9FR



THIRODE 134938

Suitable for:

**3241883 FIXING KNOB CAP**



THIRODE 381285

**3241885 GASKET FOR SELECTOR SWITCH KNOB**  
 $\varnothing$  external 39 mm -  $\varnothing$  internal 13 mm  
for Fryer gas (THIRODE) FR25G



THIRODE 366369

**3241631 SELF-STICKING DISK OVEN  $\varnothing$  64 mm**




IMEGAS

**3241396 SELF-STICKING DISK WITH PILOT SYMBOL**  
external  $\varnothing$  68 mm




AMBACH 5022914331

**3241214 SELF-STICKING DISK 0-1-2-3**  
external  $\varnothing$  68 mm



AMBACH 5022914336

**3241397 SELF-STICKING DISK 110-190°C**  
external  $\varnothing$  68 mm



AMBACH 5022914338

**3241629 SELF-STICKING DISK 3 GAS BURNERS  $\varnothing$  64 mm**



IMEGAS

**3241630 SELF-STICKING DISK 4 GAS BURNERS  $\varnothing$  64 mm**



IMEGAS






# Knobs



Suitable for:

**3241211 SELF-STICKING DISK 50-300°C**  
external  $\varnothing$  68 mm



AMBACH 5022914339

Suitable for:

**3241647 SILVER KNOB**  
for DRAIN TAP  
for Bain-marie (JEMI)  
for Boiling pan (JEMI)  
for Pasta cooker (JEMI)



JEMI 1003004

**3241942 SILVER KNOB  $\varnothing$  55 mm 120-400°C**  
complete with ring nut  
D-shaped hole 6x4.6 mm  
for Panini grill electric (UNOX) XP010P - XP010PR  
XP010PT - XP020 - XP020P - XP020PR - XP020PT  
XP020R - XP020T



UNOX KMN1105A

**3241936 SILVER KNOB  $\varnothing$  83 mm**  
D-Shaft 10x8 mm  
for Solid top range (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0580430

**5035322 CHROME-PLATED BUSHING FOR KNOB  $\varnothing$  72 mm**  
for Bain-marie (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Boiling pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Bratt pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pasta cooker (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA



MARENO CR0580460

ROSINOX RX94812686



Suitable for:

**5054850 KNOB RING NUT  $\varnothing$  94 mm SCREEN-PRINTED**

FRONT  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA  
Series 700 PROTAGONISTA NUOVA  
Series 900 PROTAGONISTA NUOVA  
for Solid top range (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0583980

**5035323 SILVER KNOB  $\varnothing$  83 mm**

D-Shaft 10x8 mm  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0580320

**5035321 KNOB RING NUT  $\varnothing$  94 mm 100-300°C**

for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA



MARENO CR0584000

# Knobs



Suitable for:

**5035322 CHROME-PLATED BUSHING FOR KNOB  $\varnothing$  72 mm**

for Bain-marie (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Boiling pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Bratt pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pasta cooker (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA



MARENO CR0580460

FOSINOX RX94812686

**3241938 KNOB RING NUT  $\varnothing$  94 mm 90-280°C**

for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0585150



Suitable for:

# Knobs



## 5035908 SILVER KNOB ø 83 mm

D-Shaft 8x6.5 mm  
for Bain-marie (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA  
Series 600 PROTAGONISTA SNACK  
Series 700 PROTAGONISTA NUOVA  
Series 900 PROTAGONISTA NUOVA



MARENO CR0580660

## 5035322 CHROME-PLATED BUSHING FOR KNOB ø 72 mm

for Bain-marie (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Boiling pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Bratt pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pasta cooker (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA



MARENO CR0580460

ROSINOX RX94812686

## 5048342 SILVER KNOB ø 83 mm

D-Shaft 6x4.6 mm  
for Bain-marie (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Boiling pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Bratt pan (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pasta cooker (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Pot stove (MARENO)



MARENO CR0581710

Suitable for:

## 5054851 BLACK RING SILKSCREENED F/KNOB ø 94 mm

REAR  
for Pot stove (MARENO)  
Series 700 PROTAGONISTA NUOVA  
Series 900 PROTAGONISTA NUOVA



MARENO CR0583990

## 5054850 KNOB RING NUT ø 94 mm SCREEN-PRINTED

FRONT  
for Pot stove (MARENO)  
Series 1100 PROTAGONISTA NUOVA  
Series 700 PROTAGONISTA NUOVA  
Series 900 PROTAGONISTA NUOVA  
for Solid top range (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0583980

## 3241940 BLACK RING 0-1 KNOB ø 94 mm 0-1-0-1

for Bain-marie (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA



MARENO CR0585780



Suitable for:

**5035322 CHROME-PLATED BUSHING FOR KNOB  $\varnothing$  72 mm**  
 for Bain-marie (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Boiling pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Bratt pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Fry top (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Fryer (MARENO) - Series 900 PROTAGONISTA NUOVA  
 for Oven under cooktop (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Pasta cooker (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Pot stove (MARENO)  
 Series 1100 PROTAGONISTA NUOVA



MARENO CR0580460

ROSINOX RX94812686

**5053767 KNOB RING NUT  $\varnothing$  94 mm SCREEN-PRINTED**  
 for Boiling pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0682580

**3241937 KNOB RING NUT  $\varnothing$  94 mm 0-1-2-3-4-5-6**  
 FRONT  
 for Pot stove (MARENO)  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0585830

**5053765 KNOB RING NUT  $\varnothing$  94 mm 1-2-3-4-5**  
 for Boiling pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA  
 for Pasta cooker (MARENO)  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0589870

## Knobs



Suitable for:

**3241935 KNOB RING NUT  $\varnothing$  94 mm SCREEN-PRINTED**  
 for Oven under cooktop (MARENO)  
 900 PROTAGONISTA NUOVA



MARENO CR0682861

**3241941 KNOB RING NUT  $\varnothing$  94 mm 0-1-2-3**  
 for Pasta cooker (MARENO)  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0584030

**5050567 KNOB RING NUT  $\varnothing$  94 mm 0-1-2-3-4-5-6**  
 REAR  
 for Pot stove (MARENO)  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0585820

**3241939 KNOB RING NUT  $\varnothing$  94 mm 100-285°C**  
 for Bratt pan (MARENO)  
 Series 900 PROTAGONISTA NUOVA



MARENO CR0685100



Suitable for:

**5048040 KNOB RING NUT  $\varnothing$  94 mm 110-280°C**  
for Fry top (MARENO)  
Series 900 PROTAGONISTA NUOVA  
for Oven under cooktop (MARENO)  
Series 900 PROTAGONISTA NUOVA



MARENO CR0584020

# Knobs



Suitable for:

**3241407 SILVER-RED HANDLE  $\varnothing$  72 mm**  
D shaft hole 6x4.6 mm  
for Fryer (ANGELO PO) - Series ALPHA  
Series GAMMA - Series OMEGA



ANGELO PO 3015850

ANGELO PO 3015851

**3241508 SILVER-RED HANDLE  $\varnothing$  72 mm**  
D shaft hole 6x4.6 mm  
for Pot stove (ANGELO PO) - Series ALPHA  
Series OMEGA



ANGELO PO 3020250

ANGELO PO 3020251

**3241806 SILVER-RED HANDLE  $\varnothing$  72 mm**  
D shaft hole 6x4.6 mm  
for Pasta cooker electric (ANGELO PO) 0G1CP1  
0G1CP1E - 0G1CP1EC - 04WCP1EM - 090CP1E  
for Pasta cooker gas (ANGELO PO) 06WCP1GM  
08WCP1GM - 091CP1G - 1GGCP1G - 1G1CP2G  
191CP1G - 191CP2G



ANGELO PO 3019900

ANGELO PO 3019901

ANGELO PO 3112000

**3241809 SILVER-RED HANDLE  $\varnothing$  72 mm**  
D shaft hole 10x8 mm  
for Boiling pan gas (ANGELO PO) ALPHA 191PD1G  
ALPHA 191PD2G - ALPHA 191PI1G - ALPHA 191PI1GA  
ALPHA 191PI2G - ALPHA 191PI2GA - ALPHA 291PD3G  
ALPHA 291PI3G - GAMMA 1G1PD1G - GAMMA 1G1PI1G  
for Grill gas (ANGELO PO) ALPHA 090GRG  
ALPHA 190GRG - OMEGA 08WGRGV  
for Pasta cooker gas (ANGELO PO) ALPHA 091CP1G  
ALPHA 191CP1G - ALPHA 191CP2G - OMEGA 06WCP1GM  
OMEGA 08WCP1GM - 10CP1GA - 12CP1GA - 18CP2GA  
for Solid top range gas (ANGELO PO) ALPHA 190TPO  
ALPHA 191TPG - ALPHA 291TPCG



ANGELO PO 3015730

ANGELO PO 3015731

**3241403 SILVER-RED HANDLE  $\varnothing$  72 mm 100-300°C**  
D shaft hole 6x4.6 mm  
for Pot stove (ANGELO PO) - Series ALPHA  
Series OMEGA



ANGELO PO 3015900

ANGELO PO 3015901

**3241807 SILVER-RED HANDLE  $\varnothing$  72 mm 110-190°C**  
D shaft hole 6x4.6 mm  
for Fryer (ANGELO PO) 091FR1I - 191FR2I  
for Fryer electric (ANGELO PO) 091FR1E - 091FR3E  
1G0FR4E - 191FR2E - 191FR4E  
for Fryer gas (ANGELO PO) 0G1FR3G - 091FR1G  
091FR3G - 1G1FR4G - 191FR2G - 191FR4G



ANGELO PO 3015831



Suitable for:

**3241404 SILVER-RED HANDLE  $\varnothing$  72 mm 140-270°C**  
D shaft hole 8x6 mm  
for Pot stove (ANGELO PO) - Series ALPHA  
Series OMEGA



ANGELO PO 3010330

ANGELO PO 3010331

## Knobs



Suitable for:

**3241405 SILVER-RED HANDLE  $\varnothing$  72 mm ELECTRIC**  
D shaft hole 6x4.6 mm  
for Pot stove electric (ANGELO PO) - Series ALPHA  
Series GAMMA - Series OMEGA



ANGELO PO 3015940

ANGELO PO 3015941

**3241406 SILVER-RED HANDLE  $\varnothing$  72 mm GAS**  
D shaft hole 8x6 mm  
for Pot stove gas (ANGELO PO) - Series ALPHA  
Series GAMMA - Series OMEGA



ANGELO PO 3013170

ANGELO PO 3013171

**3241707 VALVE KNOB**  
for USA MARKET



FRYMASTER 8100433  
ROBERTSHAW R-82220

HENNY PENNY HP16267  
ROSINOX RX26645069

PITCO FRIALATOR P6071267

**3241826 WATER INLET KNOB**  
for Pasta cooker gas (DESCO) CPG1/PS



DESCO 115142

DESCO 115143

**3241505 WATER INLET TAP HANDLE**  
square hole 7x7 mm  
for Pasta cooker electric (DESCO) CPE1 - CPE7  
for Pasta cooker gas (DESCO) CPG1 - CPG2 - CPG7



DESCO 110141  
DESCO 110143

DESCO 110141+110142

DESCO 110142

**3241884 WATER TAP KNOB  $\varnothing$  33 mm**  
height 37 mm -  $\varnothing$  knob 10 mm  
knob length 50 mm  
for Bratt pan gas (THIRODE) B9PSA50G



THIRODE 313062

**3241594 YELLOW POINTER**



FAGOR Z603052000