




Spare parts for:
Cooking equipment



Rotary switches

- Selector switches



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.

Rel. 2014-01161044





Suitable for:

Rotary switches



3057265 SELECTOR SWITCH 2 POLES PR21 1102A4

contact capacity 21A 380V AC3 7,5Kw
square shaft 5x5 mm
start/stop function switch
h 48 mm - width 50 mm
depth 33 mm




3057259 SELECTOR SWITCH 3 POLES PR12 1103A4

contact capacity 12A 380V AC3 4Kw
square shaft 5x5 mm
start/stop function switch
h 42 mm - width 40 mm
depth 46 mm



3057262 SELECTOR SWITCH 3 POLES PR17 1103A4

contact capacity 17A 380V AC3 7,5Kw
square shaft 5x5 mm
start/stop function switch
h 48 mm - width 50 mm
depth 45 mm



3057266 SELECTOR SWITCH 3 POLES PR21 1103A4

contact capacity 21A 380V AC3 7,5Kw
square shaft 5x5 mm
start/stop function switch
h 48 mm - width 50 mm
depth 45 mm



3057260 SELECTOR SWITCH 4 POLES PR12 1104A4

contact capacity 12A 380V AC3 4Kw
square shaft 5x5 mm
start/stop function switch
h 42 mm - width 40 mm
depth 46 mm



3057261 SELECTOR SWITCH 5 POLES PR12 9151C8

contact capacity 12A 380V AC3 4Kw
square shaft 5x5 mm
change over switch running function
1 speed
for THREE-PHASE MOTOR
height 42 mm - width 40 mm
depth 56 mm



3057264 SELECTOR SWITCH 5 POLES PR17 9151C8 25A

contact capacity 17A 380V AC3 7,5Kw
square shaft 5x5 mm
reversing switch running function
for THREE-PHASE MOTOR
height 48 mm - width 50 mm
depth 57 mm



3057263 SELECTOR 4 POLES PR17 1104A4

contact capacity 17A 380V AC3 7,5Kw
square shaft 5x5 mm
start/stop function switch
h 48 mm - width 50 mm
depth 45 mm





Rotary switches



Suitable for:

Suitable for:

3057050 CONNECTING BRACKET connecting thermostat and switch



- | | | |
|--------------------|--------------------|--------------------|
| ALPENINOX 0A2205 | ALPENINOX 0KT779 | ALPENINOX 006712 |
| ALPENINOX 054376 | AMBACH 5006304040 | BARON 6A045900 |
| BERTO'S 22699200 | EBERHARDT 217726 | EBERHARDT 212830 |
| EGO 617079 | EGO 0000617079 | ERRE 2 5200995 |
| FOEMM 305150320700 | GICO 5200995 | GICO 5200996 |
| GIGA X44600 | LOTUS 537001200 | MARENO MA1988500 |
| MARENO MA921200 | MARENO 1988500 | MARENO 921200 |
| METOS 6A045900 | MODULAR 661.013.00 | ROSINOX RX94002813 |
| TECNOINOX | | |

3057014 SELECTOR SWITCH 0-1 POSITIONS contact capacity 16A 250V - max 150°C D spindle ø 6x4.6 mm back connection for thermostat



- | | | |
|----------------------|--------------------|--------------------|
| ALPENINOX 026945 | AMBACH 5060904036 | BARON 6A044800 |
| DESCO EL0140 | EBERHARDT 213920 | EGO 4941015700 |
| EGO 4922015500 | EGO 4941015300 | ERRE 2 52004115 |
| ERRE 2 00423 | FRI FRI 21558010 | GICO 52004115 |
| GICO 00423 | GIGA X49700 | GIGA X40700 |
| LOTUS 537000200 | MARENO MA710300 | MARENO 1037033200 |
| MARENO 218111 | MARENO 710300 | MBM RTBF900007 |
| METOS 6A044800 | MODULAR 661.000.00 | ROSINOX RX94805892 |
| TECNOINOX RC40100006 | | |

3057015 SELECTOR SWITCH 0-1 POSITIONS contact capacity 16A 250V - max 150°C D spindle ø 6x4.6 mm



- | | | |
|------------------------|------------------------|-------------------|
| ALPENINOX 003565 | ALPENINOX 028390 | ANGELO PO 32W0490 |
| ANGELO PO 32W3610 | BARON BN6A049300 | BARON 6A049300 |
| BONNET 300002 | EBERHARDT 213921 | EGO 4922015000 |
| ELECTROLUX 003565 | ELECTROLUX 028390 | GICO 52021625 |
| METOS BN6A049300 | METOS 6A049300 | OLIS BN6A049300 |
| OLIS 6A049300 | ROSINOX RX94805256 | SILKO 0101380 |
| THIRODE 300002 | WHIRLPOOL 771985000763 | WHIRLPOOL 128390 |
| WHIRLPOOL 481227328248 | ZANUSSI 028390 | ZANUSSI 003565 |

3057018 SELECTOR SWITCH 0-1 POSITIONS contact capacity 16A 250V - max 150°C D shaft ø 6x4.6 mm back connection for thermostat for Bain-marie (ALPENINOX) for Bratt pan (ALPENINOX) for Bratt pan (BARON) - Series 900 for Fry top (ALPENINOX) for Fryer (ZANUSSI) - Series N700 - Series PR700 for Oven under cooktop (ALPENINOX)



- | | | |
|-------------------|-------------------|------------------|
| ALPENINOX 0A2036 | BARON 41826630290 | EGO 4921015711 |
| ELECTROLUX 0A2036 | FRI FRI 400372 | WHIRLPOOL 202036 |
| ZANUSSI 0A2036 | | |



Suitable for:

Rotary switches



3057019 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
 D-shaft ø 6x4.6 mm
 for Boiling pan (ALPENINOX)
 for Bratt pan (ZANUSSI) - Series R700 - Series 700
 for Fry top (ALPENINOX)
 for Fryer (STAR 10)
 for Fryer (ZANUSSI) - Series R700 - Series 700
 for Kitchen (ALPENINOX)
 for Solid top range (ALPENINOX)



ALPENINOX 0A2227	ALPENINOX 003142	EGO 4922015700
ELECTROLUX 0A2227	ELECTROLUX 003142	EMMEPI 808145
GIORIK 6030007	SILANOS 901727	SOLYMAC
WHIRLPOOL 771985005771	WHIRLPOOL 202227	ZANUSSI 003142
ZANUSSI 0A2227		

3057026 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
 D shaft ø 6x4.6 mm
 for Bain-marie (EMMEPI) - Series 650
 for Bain-marie electric (OLIS) 72/02CBE
 72/02TCBE
 for Bratt pan electric (OLIS) 74/02KBEBI
 for Bratt pan gas (OLIS) 74/02KBGMB
 for Fryer (GICO) - Series 500 - Series 700
 Series 900 - Series 920
 for Fryer electric (OLIS) 72/02FRE - 74/02FRE
 92/02FRE - 92/04FRE
 for Hot cupboard (OLIS) TAC210 - TAC211 - TAC212
 for Kitchen gas (OLIS) 76/02CGGE
 for Oven under cooktop (GICO) - Series 500
 Series 700



ALPENINOX 054375	AMBASSADE 6528979	ATA K24034
BARON 6A046000	BERTO'S 22051000	DOSILET 91013
EBERHARDT 258100	EGO 4921015600	EGO 4921015501
EMMEPI 806286	ERRE 2 52002115	FOEMM 05150320550
FRI FRI 400372	GICO 52002115	GIORIK 6030015
MARENO 1037313200	MARENO MA1037313200	METOS 6A046000
OLIS 6A046000	RIEBER 33351201	TECNOINOX RC00037000
WHIRLPOOL 481227328245	WHIRLPOOL 771985002946	WHIRLPOOL 154375
ZANUSSI 054375		

3057140 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 25A 400V - max 150°C
 D-shaft ø 6x4.6 mm
 for Fry top (ZANUSSI) - Series HD900 - Series N900
 for Grill (ZANUSSI) - Series N700 - Series N900



ALPENINOX 006649	EGO 4341832030	ELECTROLUX 006649
MARENO CR0686110	ZANUSSI 006649	

3057177 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
 D-shaped pin ø 6x4.6 mm
 for Bain-marie (EMMEPI) - Series 700 - Series 750
 Series 900
 for Bain-marie (OLIS) - Series 700 - Series 900
 for Fry top (ALPENINOX)
 for Fry top (EMMEPI) - Series 700 - Series 750
 Series 900
 for Fry top (OLIS) - Series 700
 for Fry top (ZANUSSI) - Series N700 - Series PR700
 for Fryer (ALPENINOX)
 for Fryer (OLIS) - Series 700 - Series 900
 for Grill (ZANUSSI) - Series 700
 for Kitchen electric (ZANUSSI) - Series 900
 for Oven under cooktop (ALPENINOX)



ALPENINOX 0A2134	ALPENINOX 0H6605	ALPENINOX 004908
BARON BN6A046001	BARON 6A046001	BARON 826630150
BERTO'S 220503000	EBERHARDT 213938	EBERHARDT 252339
EBERHARDT 202767	EGO 4941015701	EGO 4941015500
EMMEPI C00690	FRI FRI 601215	FRI FRI 400371
GIGA X40900	JUNO-RÖDER-SENKING 293587	JUNO-RÖDER-SENKING 245599
METOS BN6A046001	METOS 6A046001	ROSINOX RX94806098
TECNOINOX RC0007000	TECNOINOX RC00070000	WHIRLPOOL 202134
WHIRLPOOL 481227328259		



Rotary switches




Suitable for:

Suitable for:

3057178 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
D-shaped pin 6x4.6 mm
for Fryer electric (GIORIK) FRE33 - FRE63 - FT33 FT63
for Self service counter (ZANUSSI)
for Warm table (ZANUSSI)



3057255 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
D spindle ø 6x4.6 mm
for Bratt pan (CAPIC)
for Fryer gas (CAPIC) AB20 - A20 - CA10 - C10 2045 - 3085
for Grill (CAPIC)



ALPENINOX 032677
EGO 4942915707
EMMEPI C00685
SILKO 0108007
ZANUSSI 032677

ANGELO PO 32W3830
ELECTROLUX 032677
GIGA 6030012
WHIRLPOOL 132677

EBERHARDT 214252
EMMEPI 808687
GIORIK 6030012
WHIRLPOOL 77198500964

ALPENINOX 0H6688
EGO 4921015610
ROSINOX RX94015070

BONNET 905108
ELECTROLUX 0H6688
THERMA 18005012

CAPIC E052584
JUNO-RÖDER-SENKING 247318
ZANUSSI 0H6688


3057002 SELECTOR SWITCH 0-1 0-1 POSITIONS

contact capacity 32A 250V - max 150°C
D shaft ø 6x4.6 mm



3057013 SELECTOR SWITCH 0-1 0-1 POSITIONS

contact capacity 32A 250V - max 150°C
D-shaft ø 6x4.6 mm
for Bain-marie (ZANUSSI) - Series H900
for Boiling pan (ZANUSSI) - Series H900
Series R701 - Series 700
for Bratt pan (MARENO) - Series 700
for Bratt pan (ZANUSSI) - Series H900
for Fry top (MARENO) - Series 700
for Fryer (ZANUSSI) - Series H900
for Pasta cooker (ZANUSSI) - Series H900
Series R701 - Series 700



ALPENINOX 0H6683
EBERHARDT 213940
ELECTROLUX 028590
EMMEPI 806116
JUNO-RÖDER-SENKING 247202
MBM RTCP900036
ROLLER GRILL A01002
WHIRLPOOL 483286009309
ZANUSSI 0H6683

ALPENINOX 028590
EGO 4334232000
ELOMA 532215
GICO 52003432
JUNO-RÖDER-SENKING 231413
MKN 203074
ROSINOX RX27334937
WHIRLPOOL 481227328242

AMBACH 5060909122
ELECTROLUX 0H6683
ELOMA E0187
GIGA X44000
MARENO 790700
PALUX 126608
SOGET 300799
ZANUSSI 028590

ALPENINOX 050857
MARENO 1475900
ZANUSSI 050857

EGO 4342032700
WHIRLPOOL 771985002317

ELECTROLUX 050857
WHIRLPOOL 150857



Suitable for:

Rotary switches



3057017 SELECTOR SWITCH 0-1 0-1 POSITIONS
 contact capacity 16A 250V - max 150°C
 D shaft \varnothing 6x4.6 mm
 for Boiling pan (ZANUSSI) - Series HD900
 for Bratt pan (ZANUSSI) - Series HD700
 Series R700
 for Fryer (ZANUSSI) - Series HD900
 for Potato heater (ZANUSSI) - Series HD700
 Series N700 - Series PR700



ALPENINOX 0A2162
 WHIRLPOOL 771985005763

EGO 4922015723
 WHIRLPOOL 202162

ELECTROLUX 0A2162
 ZANUSSI 0A2162

3057022 SELECTOR SWITCH 0-1 0-1 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Bain-marie (ZANUSSI) - Series N700
 Series PR700
 for Rotisserie electric (MCM) 1EE - 2EE - 3EE
 4EE - 6EE - 8EE
 for Toaster electric (DOSILET) TT0001 - TT4000



ALPENINOX 0A2241
 ELECTROLUX 0A2241
 WHIRLPOOL 481227328263
 ZANUSSI 0A2241

DOSILET 91012
 JUNO-RÖDER-SENKING 245596
 WHIRLPOOL 771985005773

EGO 4942015500
 MCM 030138-E
 WHIRLPOOL 202241

3057094 SELECTOR SWITCH 0-1 0-1 POSITIONS
 contact capacity 32A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm




ALPENINOX 0H6682
 EGO 4342032000
 ELECTROLUX 0K0472
 JUNO-RÖDER-SENKING 212269
 PALUX 291722
 ZANUSSI 0K0472

ALPENINOX 0K0472
 EGO 4332032000
 ELECTROLUX 0K1379
 JUNO-RÖDER-SENKING 231420
 ROSINOX RX94014842
 ZANUSSI 0K1379

ALPENINOX 0K1379
 ELECTROLUX 0H6682
 JUNO-RÖDER-SENKING 231422
 MKN 203564
 WHIRLPOOL 481227328244
 ZANUSSI 0H6682

3057003 SELECTOR SWITCH 0-1-2-3-4 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Boiling pan electric (ZANUSSI) - Series H900



ALPENINOX 051634
 WHIRLPOOL 771985002406

EGO 4925915770
 WHIRLPOOL 151634

ELECTROLUX 051634
 ZANUSSI 051634

3057004 SELECTOR SWITCH 0-1-2-3-4 POSITIONS
 contact capacity 16A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm
 for Boiling pan electric (ZANUSSI) - Series 700
 for Pasta cooker electric (ZANUSSI) CCP/E700
 HCP/E400 - HCP/E800 - MCP/E700 - M70EPC
 RCP/E700



ALPENINOX 051647
 WHIRLPOOL 771985002415

EGO 4925915769
 ZANUSSI 051647

ELECTROLUX 051647

3057001 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 32A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm
 for Pot stove gas (ZANUSSI) JUN90002 - JUN90012
 JUN90022 - JUN90042 - JUN90069 - JUN92012
 JUN92032



ALPENINOX 029147
 CAPIC E052520
 EGO 4324432000
 GICO 52002432
 JUNO-RÖDER-SENKING 245541
 MARENO 501400
 WHIRLPOOL 771985000764
 ZANUSSI 029147

AMBACH 5060908251
 CHARVET 02096A
 ELECTROLUX 029147
 GICO 00410
 KÜPPERSBUSCH 182752
 ROSINOX RX273349196
 WHIRLPOOL 129147

AMBACH 5060902396
 EGO 4324232000
 FOEMM 305010078050
 JUNO-RÖDER-SENKING 231424
 MARENO MA501400
 SOLYMAC P86C
 WHIRLPOOL 481227328237



Rotary switches



Suitable for:

3057064 SELECTOR SWITCH 0-3 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Boiling pan electric (ZANUSSI) KPI/E15
for Pasta cooker (ZANUSSI) - Series HD900




ALPENINOX 059544
WHIRLPOOL 771985003811

EGO 4624866803
ZANUSSI 059544

ELECTROLUX 059544

Suitable for:

3057142 SELECTOR SWITCH 0-3 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Oven under cooktop (WHIRLPOOL) - Series 700
Series 701
for Oven under cooktop (ZANUSSI) - Series HD700
Series H700 - Series PR700 - Series R701



ALPENINOX 0C7965
ELECTROLUX 053866
ZANUSSI 0C7965

ALPENINOX 053866
WHIRLPOOL 153866
ZANUSSI 053866

ELECTROLUX 0C7965
WHIRLPOOL 771985002754

3057164 SELECTOR SWITCH 0-3 POSITIONS
contact capacity 16A 250V - max 140°C
D-shaft \varnothing 6x4.6 mm
for Oven under cooktop electric (ZANUSSI)
Series N700 - Series N900




ALPENINOX 0C0320
ELECTROLUX 0C9725
ZANUSSI 0C9725

ALPENINOX 0C9725
WHIRLPOOL 771985011291

ELECTROLUX 0C0320
ZANUSSI 0C0320

3057006 SELECTOR SWITCH 0-4 POSITIONS
contact capacity 32A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Kitchen electric (ZANUSSI) - Series H900




ALPENINOX 025300
WHIRLPOOL 771985000685

EGO 4325232020
ZANUSSI 025300

ELECTROLUX 025300

3057031 SELECTOR SWITCH 0-4 POSITIONS
contact capacity 32A 250V-25A 400V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Pasta cooker electric (ANGELO PO)
Series JUNIOR - Series SENIOR - Series SUMMIT
for Pot stove electric (ANGELO PO) - Series ALPHA
Series DELTA - Series OMEGA - Series SENIOR
Series SUMMIT



ALPENINOX 0A2285
EGO 4325432000
ZANUSSI 0A2285

ANGELO PO 32W1050
ELECTROLUX 0A2285

ANGELO PO 32W0520
WHIRLPOOL 202285

3057093 SELECTOR SWITCH 0-4 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm



ALPENINOX 0H6602
ELOMA E0185
ZANUSSI 0H6602

EGO 4924215520
JUNO-RÖDER-SENKING 245595

ELECTROLUX 0H6602
MACFRIN 321800




Suitable for:

Rotary switches



3057141 SELECTOR SWITCH 0-4 POSITIONS

contact capacity 16A 250V - max 150°C
D-shaped pin 6x4.6 mm
for Oven under cooktop (ZANUSSI) - Series PR700



ALPENINOX 0C9080	ALPENINOX 004268	ELECTROLUX 0C9080
ELECTROLUX 004268	WHIRLPOOL 771985000441	ZANUSSI 0C9080
ZANUSSI 004268		

3057023 SELECTOR SWITCH 0-6 POSITIONS

contact capacity 32A 250V - max 150°C
D shaft ø 6x4.6 mm
for Bratt pan electric (COMETTO)
for Hot plate electric (COMETTO)
for Kitchen electric (EMMEPI) - Series 900
for Pot stove electric (COMETTO)
for Kitchen electric (ALPENINOX)
for Kitchen electric (EMMEPI) EE4F



ALPENINOX 0A2022	ALPENINOX 0K4922	AMBACH 5060904041
ANGELO PO 32W2920	ATA K24014	BONNET 300010
COMETTO 50002	EGO 4327232000	EMMEPI C00214
EMMEPI 806160	FOEMM 05010076150	JUNO-RÖDER-SENKING 231496
JUNO-RÖDER-SENKING 231069	LOTUS 537027700	MARENO 21131099
MARENO MA1937800	MARENO 1937800	MBM RTCU800151
MODULAR 961.000.00	MORICE DE0785	ROSINOX RX94015021
SOLYMAC P87C	TECNOINOX RC01482000	THIRODE 300010
WHIRLPOOL 202022		

3057076 SELECTOR SWITCH 0-6 POSITIONS

contact capacity 16A 250V - max 150°C
D shaft ø 6x4.6 mm
for Kitchen electric (ZANUSSI) - Series N700
Series PR700 - Series R701 - XC/E1 - XC/E2
XCF/E2 - XCV/E3



ALPENINOX 059238	EGO 4627266813	ELECTROLUX 059238
FORVED SNACKCOMMUT	WHIRLPOOL 771985003713	WHIRLPOOL 159238
ZANUSSI 059238		

3057089 SELECTOR SWITCH 0-6 POSITIONS

contact capacity 16A 250V - max 150°C
D shaft ø 6x4.6 mm
for Boiling pan (ZANUSSI)
for Pasta cooker (ZANUSSI) - Series N700
Series PR700



ALPENINOX 004741	EGO 4207000025	ELECTROLUX 004741
WHIRLPOOL 771985000478	ZANUSSI 004741	

3057092 SELECTOR SWITCH 0-6 POSITIONS

contact capacity 16A 250V - max 150°C
D-shaft ø 6x4.6 mm
for Kitchen electric (KÜPPERSBUSCH) - Series FEH
for Hot plate (BERTO'S) E7P2M



ALPENINOX 004915	ALPENINOX 053408	BERTO'S 22049900
EGO 4927215520	EGO 4927215747	ELECTROLUX 004915
ELECTROLUX 053408	EMMEPI 808148	EMMEPI 831097
GIORIK 6030014	KÜPPERSBUSCH 182774	KÜPPERSBUSCH 183206
PALUX 101703	POTIS PT0178	TECNOINOX RC00291000
WHIRLPOOL 771985002665	WHIRLPOOL 151647	WHIRLPOOL 153408
ZANUSSI 004915	ZANUSSI 053408	

3057307 CONNECTION BRACKET

small model
for connection with thermostats



AMBACH 5006304040	EGO 617078	WHIRLPOOL 771985005769
-------------------	------------	------------------------



Rotary switches



Suitable for:

Suitable for:

3057027 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 rear hole for thermostat
 for Fryer (MORICE)
 for Fryer electric (GIGA) SKF2E - Series 600
 Series 700 - Series 800 - Series 900
 for Grill (MORICE)
 for Hot plate (MORICE)
 for Kitchen (OM GAS) - Series MERCURY
 Series SCORPION
 for Kitchen (THIRODE) - Series 700 - Series 900
 for Kitchen electric (EMMEPI) - Series 650
 Series 700 - Series 750 - Series 900



AMBACH 5060904057
 EBERHARDT 214421
 EMMEPI 806117
 LOTUS 537000400
 MBM RTCU900110
 THIRODE 300176

AMBACH 5060940570
 EGO 4921015300
 GIGA Y16200
 MARENO MA1037035700
 MORICE DE0197
 WHIRLPOOL 483286009351

BERTO'S 22050400
 EMMEPI C00217
 HOBART 300176
 MARENO 1037035700
 SILKO 0109057

3057078 SELECTOR SWITCH 0-2 POSITIONS

contact capacity 16A 250V - max temperature 150°C
 D-shaped pin \varnothing 6x4.6 mm
 for Fryer electric (AMBACH) - Series EY
 Series FE



AMBACH 5060910023

EGO 4941915707

3057087 SELECTOR SWITCH 0-3 POSITIONS

contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Salamander electric (BONNET)



AMBACH 5060902384
 IMEGAS 01234260
 WHIRLPOOL 481227328251

BONNET 002736
 JEMI 240045

EGO 4924215000
 KÜPPERSBUSCH 183205

3057098 SELECTOR SWITCH 0-3 POSITIONS

contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Pasta cooker (MODULAR) - Series 600
 Series 700 - Series 900
 for Pasta cooker electric (DESCO) CPE2 - CPE2-7



AMBACH AM5060904035
 DESCO 60773
 MODULAR 661.037.00

AMBACH 5060904035
 EGO 4944015702

DESCO EL0127
 GIGA AEC011ZR10



Suitable for:

Rotary switches



3057024 SELECTOR SWITCH 0-7 POSITIONS

contact capacity 16A 250V - max 150°C
 D shaft \varnothing 6x4.6 mm
 for Kitchen electric (EMMEPI) - Series 650
 Series 700 - Series 750
 for Kitchen electric (GICO) - Series 700
 for Kitchen electric (GIGA) - Series 600
 Series 700 - Series 800 - Series 900
 for Kitchen electric (OFFCAR) - Series 700
 Series 900
 for Kitchen electric (OLIS) 72/02CEPT - 76/02CEPT
 for Pot stove electric (OLIS) 72/02TCE - 74/02CEPT
 74/02TCE - 76/02TCE - 92/04CE - 92/04TCE
 94/04CE - 94/04TCE



AMBACH 5060904034
 BARON 6A045500
 EBERHARDT 201443
 EGO 4927215000
 GICO 52002715
 LOTUS 537000300
 MORICE DE0781
 ROSINOX RX94015013
 THIRODE 300011

ANGELO PO 32W0760
 BONNET 300176
 EGO 4927215020
 FOEMM 0500083150
 GIGA X40800
 METOS 6A045500
 PALUX 246848
 SOLYMAC P87

BARON 826630070
 DESCO 60452
 EGO 4927215746
 GICO 00424
 GIGA X54100
 MODULAR 661.002.00
 ROSINOX RX94806010
 TECNOINOX RC40100004

3057205 SELECTOR SWITCH 0-6 POSITIONS

contact capacity 16A 250V - max 150°C
 D shaft \varnothing 6x4.6 mm
 for Kitchen electric (FAGOR) CE7-20 - CE7-40
 CE7-41 - CE9-41
 for Pot stove electric (FAGOR) CE9-20 - CE9-40



AMBASSADE 6553435
 WHIRLPOOL 481227328013

EGO 4627266500

FAGOR U673007000

3057316 SELECTOR SWITCH 3 POSITIONS

ON/FF/INSTANT
 for Boiling pan gas (AMBASSADE) PR0900G1MF




AMBASSADE 00077A

CHARVET 00077A

3057256 SELECTOR SWITCH 4 POSITIONS

contact capacity 16A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm
 for Oven under cooktop (COMETTO)
 for Oven under cooktop electric (AMBASSADE) CE1051
 CE1052 - CE641 - CE741 - CE841
 for Oven under cooktop gas (AMBASSADE) CG1051
 CG1052 - CG641 - CG731 - CG831



AMBASSADE 6552194

COMETTO 50026

EGO 4923815560

3057032 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 32A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm
 for Fryer (ANGELO PO)



ANGELO PO 32W0080

EGO 4331832000

3057037 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
 D shaft \varnothing 6x4.6 mm
 with double shaft
 for Fryer (ANGELO PO) - Series JUNIOR
 Series SENIOR




ANGELO PO 32W2550

EGO 4921915731



Suitable for:

3057030 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Kitchen (ANGELO PO) - Series ALPHA
 Series DELTA - Series SENIOR




ANGELO PO 32W1440
 EGO 4964215715

EGO 4921015300+
 EGO 4964215715+

EGO 4944215700+

Suitable for:


3057028 SELECTOR SWITCH 0-4 POSITIONS
 contact capacity 32A 250V-25A 400V - max 150°C
 D-shaped pin \varnothing 6x4.6 mm



ANGELO PO 32W0520

EGO 4325232000

3057187 SELECTOR SWITCH 0-4 POSITIONS
 contact capacity 16A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm
 for Kitchen electric (ANGELO PO)



ANGELO PO 32W1500

EGO 4925215723

3057069 SELECTOR SWITCH 0-5 POSITIONS
 contact capacity 25A 480V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Boiling pan (ANGELO PO) - Series DELTA
 Series OMEGA
 for Pasta cooker (ANGELO PO) - Series DELTA
 Series OMEGA




ANGELO PO 32W3260

EGO 4335232000

EGO 4335232020

5030542 SELECTOR SWITCH 2 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaped pin \varnothing 6x4.6 mm



ANGELO PO 3168540

EGO 4202900000

3057281 SELECTOR SWITCH 4 POSITIONS
 contact capacity 16A 250V - max 150°C
 D shaft \varnothing 6x4.6 mm
 for Pasta cooker (ANGELO PO) - Series ALPHA
 Series GAMMA - Series OMEGA



ANGELO PO 3162280

EGO 4204000023




Suitable for:

Rotary switches



3057082 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°
 D-shaft 6x4.6 mm
 for Fryer (BARON) - Series 700 - Series 900
 for Fryer (EMMEPI) - Series 650 - Series 700
 Series 750 - Series 900
 for Fryer (GIORIK) - Series 700 - Series 900
 for Fryer (OFFCAR) - Series 700 - Series 900
 for Pasta cooker (BARON) - Series 700 - Series 900
 for Pasta cooker (EMMEPI) - Series 650
 Series 700 - Series 750 - Series 900
 for Pasta cooker (GIORIK) - Series 700
 Series 900




BARON 85326030019
 EMMEPI 808052
 ROSINOX RX94805405

EBERHARDT 214269
 GIORIK 6030019
 SILKO 0108026

EGO 4941015705
 OFFCAR 862317

3057073 SELECTOR SWITCH 0-1 0-1 POSITIONS

contact capacity 16A 250V - max 150°
 D-shaft \varnothing 6x4.6 mm
 for Pot stove gas (OLIS) 96/04CGFL




BARON 6A046700
 COMETTO 50025
 MARENO MA1230100
 OLIS 6A046700

BARON 826630290
 EGO 4942015000
 METOS 6A046700
 RIEBER 91030314

CAPIC E052505
 MARENO 1230100
 MKN 203563

3057180 SELECTOR SWITCH 0-3 POSITIONS

contact capacity 16A 250V - max 150°
 D-shaft \varnothing 6x4.6 mm
 for Kitchen electric (MARENO) - Series 700
 Series 900
 for Pasta cooker electric (BERTO'S) CPE40 - E9CP40



BARON MA130900
 BERTO'S 22049800
 EGO 4934615701
 LOTUS 537034001
 METOS 6A046750
 SILKO 0101397

BARON MA1309000
 EBERHARDT 213937
 GIGA X44100
 MARENO MA1309000
 OLIS 6A046750
 WHIRLPOOL 483286009617

BARON 6A046750
 EBERHARDT 222041
 LOTUS 537034000
 MARENO 1309000
 ROSINOX RX94806478

3057305 SELECTOR SWITCH 0-1-2-3 POSITIONS

contact capacity 18A 240V - max 150°
 D-shaped pin 6x4.6 mm
 for Boiling pan electric (GIGA) CPEI - KPIGN27E
 KPI10E - KPI15E - KPI15EA - OPPI10E - OPPI15E
 OPPI15EA
 for Boiling pan electric (WHIRLPOOL) AGB372
 AGB375 - AGB377 - AGB382 - AGB396 - AGB399
 AGB401 - AGB511



BERTO'S 35050100
 EGO 4944015702
 OLIS BN6A001412

EGO 4927215746
 GIGA E11000
 WHIRLPOOL 483286009427

EGO 4927215802
 METOS BN6A001412

3057151 SELECTOR SWITCH 0-2 POSITIONS

contact capacity 16A 250V - max temperature 150°
 D spindle \varnothing 6x4.6 mm
 for Toaster electric (BERTO'S) 12T - 4T0 - 6T
 for Toaster electric (ELETTROBAR) 404 - 406 - 412
 for Toaster electric (SILANOS) FA3



BERTO'S 30051600
 SILANOS 901720

EGO 4914915705

ELETTROBAR 923011

3057306 SELECTOR SWITCH 4 POSITIONS

contact capacity 32A 250V - max 150°
 D shaft \varnothing 6x4.6 mm
 for Oven under cooktop electric (THIRODE)
 Series 1000 - Series 700 - Series 900



BONNET 300051
 MORICE DE0205

EGO 4324832060
 THIRODE 300051

HMI 300051
 WHIRLPOOL 481227328238



Rotary switches



Suitable for:

3057270 SELECTOR SWITCH 5 POSITIONS
contact capacity 16A 250V - max 150°C
D shaft \varnothing 6x4.6 mm



BONNET 300178
THIRODE 300178

EGO 420510000

HMI 300178

Suitable for:

3057269 3-POLE SELECTOR SWITCH V18/D/41388A/T100
240V - square shaft 5x5 mm
for Oven under cooktop electric (BONNET)
Series GRANDE CARTE - Series MAP
Series SYMPHONIE



BONNET 311243

3057268 SELECTOR SWITCH START/STOP
25 A - 220/380 V
square shaft 5x5 mm
for Fryer (SOLYMAC)
for Grill (SOLYMAC)



BOURGEOIS COMU3002

SOLYMAC P83

SOLYMAC P83B

3241755 BLACK KNOB
square hole 5x5 mm
for selector switch



BOURGEOIS MAN3007

SOLYMAC P72Q

3241756 RING FOR KNOB \varnothing 92 mm



BOURGEOIS CLAV3008

SOLYMAC P1033

3057258 SELECTOR SWITCH 2 POLES PR12 1102A4
contact capacity 12A 380V AC3 4Kw
square shaft 5x5 mm
start/stop function switch
h 42 mm - width 40 mm
depth 36 mm



BOURGEOIS COMU3002

3057257 SELECTOR SWITCH 0-2 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaped pin \varnothing 6x4.6 mm
for Oven under cooktop (CAPIC)



CAPIC E052525

EGO 4324832120




Suitable for:

Rotary switches



3057254 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Bain-marie electric (MORICE) - Series 900
 for Fryer electric (MORICE) - Series 900
 for Oven under cooktop electric (CAPIC)
 for Pasta cooker electric (MORICE) - Series 900



CAPIC E052510
WHIRLPOOL 481227328257

EGO 4932015000

MORICE DE0204


3211004 SWITCH CS 0258910 A2500
 contact capacity 25A 600V - max 60/75°C
 square shaft 6x6 mm
 for Rotisserie electric (CB)



CB 07CC0084

CB 07040976

3057095 SELECTOR SWITCH 0-1 POSITIONS
 contact capacity 16A 250V - max 150°C
 D spindle \varnothing 6x4.6 mm



CHARVET 300027

EGO 4931015020

3057308 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 32A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Hot plate electric (CHARVET)



CHARVET 02093A

EGO 4324032000

3057216 SELECTOR SWITCH 0-1 POSITIONS
 contact capacity 16A 230V - max 150°C
 D-shaped pin 6x4.6 mm
 for Panini grill electric (FB FAB A) - Series E
 Series S



DESCO 60777
EGO 4942915704
FIMAR CO1943

DIHR 9564
EMMEPI 809926
FORVED

EGO 4941015702
FB FAB A PR10007
METOS 9564

3057159 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Pasta cooker electric (OFFCAR) - Series 700
 Series 900
 for Salamander electric (GIORIK) SR512



DESCO EL0114
GIORIK 6030017
SILKO 0108221

EBERHARDT 214359
OFFCAR 862305

EGO 4944915703
OFFCAR 898973

3057170 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaped pin \varnothing 6x4.6 mm
 per models 7-8-10 litres
 for Fryer electric (DOSILET)



DOSILET 400007018

EGO 4924015500

3057121 SELECTOR SWITCH 0-1 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft 6x4.6 mm
 for Fry top (FAGOR) - Series 900
 for Fryer (FAGOR) - Series 900
 for Fryer (FAGOR) FTE705



EGO 4203400009

FAGOR X163007000




Rotary switches



Suitable for:

3057139 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaped pin \varnothing 6x4.6 mm



EGO 420440003

MBM RTFOC00694

Suitable for:

3057186 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Bratt pan (MBM) - Series MAGISTRA



EGO 4922015705

HOBART 144605-81


EMMEPI 814040

MBM RTCU700212

GIGA X51300

WHIRLPOOL 483286009387

3057196 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Bratt pan (JEMI) - Series 900



EGO 4623966541

JEMI 998165

3057083 SELECTOR SWITCH 0-2 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaped pin \varnothing 6x4.6 mm
for Oven under cooktop (MBM)



EGO 4923815000

MBM RTCU700079

EGO 4923815050

EMMEPI 807768

2101527 SELECTOR SWITCH 0-3 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaped pin \varnothing 6x4.6 mm



EGO 4924015000

3057060 SELECTOR SWITCH 0-3 POSITIONS
contact capacity 16A 250V - max 150°C
D-shaft \varnothing 6x4.6 mm
for Oven under cooktop (JEMI) - Series 550
Series 600 - Series 700 - Series 900



EGO 4204400026

JEMI 2004051

3241123 KNOB \varnothing 50 mm
D-shaped hole 6x4.6 mm



JEMI 2016012



Suitable for:

Rotary switches



3057090 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Boiling pan electric (MARENO) P9D-10E
 P9D-15E - P9DA-10E - P9DA-15E - P9DASB-10E
 P9DSB-10E



EGO 4942915705

MARENO 1419700

3057165 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Bain-marie electric (ROLLER GRILL) BMS
 for Grill (ROLLER GRILL) XL
 for Rotisserie electric (ROLLER GRILL) RBE12
 RBE4 - RBE8
 for Salamander electric (ROLLER GRILL) SEM60
 for Toaster electric (ROLLER GRILL) BAR100
 BAR106 - BAR200 - BAR206 - RST127 - RST128
 RST227




EGO 4924215001

HOBART 846676-6

ROLLER GRILL A01001

3057336 SELECTOR SWITCH 0-3 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaped pin \varnothing 6x4.6 mm
 for Boiling pan electric (MODULAR) - Series 700
 Series 900



EGO 4334232800

MODULAR 661.062.00

3057096 SELECTOR SWITCH 0-4 POSITIONS
 contact capacity 16A 250V - max 150°C
 D-shaft \varnothing 6x4.6 mm
 for Salamander electric (FRANKE) FR1/1E2




EGO 4925215530
FRANKE 10279800

ELOMA T0132
PALUX

FRANKE 5356072

3057045 SELECTOR SWITCH 0-7 POSITIONS
 contact capacity 16A 250V - - max 150°C
 D spindle \varnothing 6x4.6 mm



EGO 4927215500

3057079 SELECTOR SWITCH 0-9 POSITIONS
 contact capacity 16A 250V - max 150°C
 D shaft \varnothing 6x4.6 mm
 for Kitchen electric (WHIRLPOOL) AGB496 - AGB497
 for Kitchen gas (WHIRLPOOL) AGB493 - AGB495
 AGB582
 for Oven under cooktop electric (GIGA)
 Series 600 - Series 700 - Series 900



EGO 4200000015

GIGA X68204

WHIRLPOOL 483286000404



Rotary switches



Suitable for:

Suitable for:

5034977 SWITCH 0-3 POSITIONS

contacts 16A 250V - max 150°C
D-Shaft 6x4.6 mm
for Boiling pan (MARENO) - Series 700 - Series 900
Series 900 PROTAGONISTA NUOVA
for Pasta cooker (MARENO) - Series 700
Series 900 - Series 900 PROTAGONISTA NUOVA




EGO 420440025

GIORIK 6030040

MARENO CR0581810

2111991 SWITCH 0-9 POSITIONS

contacts 16A 250V - max 150°C
D-Shaft 6x4.6 mm
for Oven under cooktop (LOTUS) - Series 60
Series 65



EGO 4929815733

TECNOEKA 01200040

LOTUS 537019201

TECNOEKA 01950037000

LOTUS _75B0043

3059010 SINGLE POLE SELECTOR SWITCH

contact capacity 12A 250V - max 60/75°C
square shaft 5x5 mm
for Fryer electric (ELFRAMO) EB6



ELFRAMO 00005971

KOMEL 00005971

REPAGAS 8700027

ELFRAMO 25100001

KOMEL 25100001

ELFRAMO 597/A

KOMEL 597/A

3241091 BLACK KNOB ø 55 mm

square hole 5x5 mm
for Fryer electric (REPAGAS) EB12 - EB18 - EB8



ELFRAMO 00006500

KOMEL 00006500

REPAGAS 8700012

ELFRAMO 00006520

KOMEL 00006520

ELFRAMO 650

KOMEL 650

3059011 3-POLE SELECTOR SWITCH

contact capacity 16A 380V - max 60/75°C
square shaft 5x5 mm
for Fryer electric (ELFRAMO) EB18 - EB8



ELFRAMO 00005980

KOMEL 00005980

REPAGAS 8700023

ELFRAMO 25110001

KOMEL 25110001

ELFRAMO 598

KOMEL 598

3241091 BLACK KNOB ø 55 mm

square hole 5x5 mm
for Fryer electric (REPAGAS) EB12 - EB18 - EB8



ELFRAMO 00006500

KOMEL 00006500

REPAGAS 8700012

ELFRAMO 00006520


KOMEL 00006520

ELFRAMO 650

KOMEL 650

3057203 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 16A 250V - max 150°C
D-shaped pin ø 6x4.6 mm



ELOMA E0191

ELOMA E320006

ELOMA 320006

3057190 SELECTOR SWITCH 0-1 POSITIONS

contact capacity 32A 600V - max 75°C
rectangular shaft 4x5 mm
for Fryer electric (GIORIK) F15 - F20 - F215
F220 - F920 - F940



EMMEPI 807808

OFFCAR 862325

GIORIK 6030003

MBM RTBF800161



Suitable for:

3057184 BRACKET FOR SELECTOR SWITCH
for Fryer (FAGOR) FTE705



FAGOR X313001000

Rotary switches



Suitable for:

3057133 SELECTOR SWITCH 0-3 POSITIONS
contact capacity 16A 250V - max 125°C
D-shaft \varnothing 6x4.6 mm
for Kitchen (FAGOR) - Series 700
for Kitchen electric (FAGOR) CE7-41 - CE9-41



FAGOR U673006000

3057162 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 25A 600V - max 60/75°C
square shaft 5x5 mm



FIMAR CO1043

3057163 SELECTOR SWITCH 0-4 POSITIONS
contact capacity 16A 600V - max 60/75°C
square shaft 5x5 mm



FIMAR CO1045


3057146 SELECTOR SWITCH 0-7 POSITIONS
contact capacity 16A 400V - max 150°C
rectangular pin 4x5 mm
for Fryer (MACFRIN)



GIORIK 6030030

MACFRIN 96030030

3057174 SELECTOR SWITCH 0-9 POSITIONS
contact capacity 16A 250V - max 150°C
D shaft \varnothing 6x4.6 mm
for Oven under cooktop (LOTUS) - Series 600
Series 650



LOTUS 537019200

3057192 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 40A 600V
square pin 5x5 mm
for Fryer electric (MOVILFRIT) FH-17 - FH-25
FH-35
for Fryer electric (REPAGAS) FE17



MOVILFRIT 901404

REPAGAS 57103015

3057193 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 32A 600V
square pin 5x5 mm
for Fryer electric (MOVILFRIT) FH-10 - FH-17
for Fryer electric (REPAGAS) FE10 - FE8



MOVILFRIT 901405

REPAGAS 57203017



Rotary switches



Suitable for:

3057194 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 20A 300V - max 150°C
square pin 5x5 mm
for Bain-marie gas (REPAGAS) BM72 - BM92



REPAGAS 22304004

Suitable for:

3057195 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 20A 300V - max 150°C
square pin 5x5 mm
for Bain-marie gas (REPAGAS) BM71 - BM91



REPAGAS 27800010

3122785 SILICONE GASKET F. SELECTOR SWITCH
dimensions 50x20 mm
for Bratt pan electric (ROSINOX) MBM80E - SBM35E
for Bratt pan gas (ROSINOX) MBM80G
for Pot stove gas (ROSINOX) 120MFNDET



ROSINOX RX94013471

3057182 SELECTOR SWITCH 0-1 POSITIONS
contact capacity 16A 250V - max 75°C
square shaft 5x5 mm
for Fryer (SICOMEX) - Series LT - Series SF



SICOMEX 03001

SICOMEX 03919

3057158 SELECTOR SWITCH 0-4 POSITIONS
contact capacity 16A 600V - max 60/75°C
square shaft 5x5 mm



SIRMAN IB5806820

3057267 SELECTOR SWITCH PR26 7207A4 25A
4 positions - square shaft 5x5 mm
for Oven under cooktop (SOLYMAC)



SOLYMAC P85

3241755 BLACK KNOB
square hole 5x5 mm
for selector switch



BOURGEOIS MAN3007

SOLYMAC P72Q

3241756 RING FOR KNOB ø 92 mm



BOURGEOIS CLAV3008

SOLYMAC P1033