



Spare parts for:

Cooking equipment



Switches

- Change over switch
- Button
- Push switch
- Keyboards



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.





Suitable for:

Switches



3319500 "EMERGENCY STOP" PLATE



Suitable for:

3319729 BIPOLAR PUSH-BUTTON COMPLETE
ø 26 mm - total length 49 mm
for Bratt pan gas (THIRODE) B9PSA50G



THIRODE 133409

3319150 BIPOLAR PUSH-BUTTON 16A 250V BLACK
mounting hole ø 25 mm
for Oven under cooktop gas (ZANUSSI) - Series R701 Series 700



3319151 SWITCH PROTECTION CAP
ø external 34 mm
for push-buttons with mounting hole ø 25 mm
for Oven under cooktop gas (ZANUSSI) - Series R701 Series 700



ALPENINOX 053978
ELECTROLUX 058274
WHIRLPOOL 153978

ALPENINOX 058274
ROSINOX RX94805173
ZANUSSI 058274

ELECTROLUX 053978
SILKO 0101188
ZANUSSI 053978

ALPENINOX 053979
ELETTRORBAR 410005
GIGA D410005
ZANUSSI 053979

DEXION
ERRE 2 55463001
WHIRLPOOL 771985002806

ELECTROLUX 053979
GICO 55463001
WHIRLPOOL 153979

3319520 BLACK BIPOLAR SWITCH 10A 250V
mounting hole 21x40 mm
ON-OFF function
for Fryer gas (FRYMASTER) MJ45E



FRYMASTER 8070496

3319529 BLACK BIPOLAR SWITCH 10A 250V
silk-screen printing 0 - I
mounting hole 22x30 mm



BONNET 905914

3319146 BLACK BIPOLAR SWITCH 16A 250V
16(4)A 250V - silk-screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm
for Potato heater (GIORIK) 401L



EMMEPI 808146

GIORIK 6032031

SICOMEX 03508

3319154 BLACK BIPOLAR SWITCH 16A 250V
16(4)A 250V - with push-button cover
0-I silk-screen printing
max temperature 120°C
mounting hole 22x30 mm
for Hot cupboard (LAINOX) - Series AC



NUOVA SIMONELLI 16200027

NUOVA SIMONELLI 16300119

ROLLER GRILL A07002



Switches



Suitable for:

3319295 BLACK BIPOLAR SWITCH 16A 250V
16(4)A 250V - with green led lamp
temperature max 120°C
mounting hole 22x30 mm



AMBASSADE 6540129

WHIRLPOOL 771985008580

Suitable for:

3319501 SWITCH PROTECTION CAP
external dimensions 29x36 mm
for switches with mounting hole 22x30 mm



FRI FRI 400647

TECNOINOX

3319296 BLACK BIPOLAR SWITCH 16A 250V
with red led indicator light
max temperature 120°C
mounting hole 22x30 mm



ANIMO 02522

CF CENEDESE 63.7.0861

MILAN TOAST 14870

3319363 BLACK BIPOLAR SWITCH 16A 250V
with orange indicator light
silk-screen printing II - I
mounting hole 22x30 mm



FB FABA PR40027

3319371 BLACK BIPOLAR SWITCH 16A 250V
16(4)A 250V - silk-screen printing 0 - I
temperature max. 120°C
mounting hole 22x30 mm
for Fry top electric (ROLLER GRILL) PSR900EC



CF CENEDESE 63.7.0860

ROLLER GRILL A07027

ROLLER GRILL A07025

ROLLER GRILL A07030

3319748 BLACK BIPOLAR SWITCH 16A 250V
silk-screen printing 0 - I
mounting hole 22x23 mm



3319766 BLACK BIPOLAR SWITCH 16A 250V
16(4)A 250V
silk screen printing 0 - I
mounting hole 22x30 mm



3319463 BLACK DOUBLE-POLE SWITCH 16A 250V
16(4)A 250V
with orange indicator lamp and protection cap
silk-screet printing "light on"
max temperature 120°C
mounting hole 22x30 mm



CB 07040518



Suitable for:

Switches



3319445 BLACK FAN SWITCH 20A 277V

mounting hole 20x36 mm
ON-OFF function



LINCOLN 369260

Suitable for:

3319432 BLACK INGNITION RESET PUSH-BUTTON 3A 250

cable length 390 mm



LINCOLN 369771

3319475 BLACK LEVER SWITCH 20A 250V

threaded coupling \varnothing 12 mm
for Broiler (NIECO) - Series 922 - Series 932
Series 940 - Series 950 - Series 952 - Series 960
Series 962 - Series 980



NIECO 4099

3319468 BLACK SINGLE POLE SWITCH 16A 250V

16(4)A 250V - silk-screen printing 0 - I
max temperature 120°C
mounting hole 11x30 mm
for CAB FAST COLD 1-2-3/NEW FABY 1-2-3
for COFRIMELL FRIGO DRINK COF-COLDREAM-JETCOF-
MEGA25-MEGA40-NEWCOF



MODULAR RRC2206-00

NUOVA SIMONELLI 16300121

3319140 BLACK SINGLE-POLE SWITCH 16A 250V

lever-operated
for Toaster electric (ARISTARCO)
till 1/01/05
2P - 3P - 6P



ARISTARCO 632

3319478 BLACK SWITCH 10/15A 250/125V

6 contacts - 3 positions
mounting hole 20x40 mm
for Fryer electric (HENNY PENNY) C8000 - PFE590
PFE591 - PFE592
for Fryer gas (HENNY PENNY) OFG390 - OFG391



HENNY PENNY HP29898

3319760 BLACK SWITCH 20A 125-277V

silk-screen printing 0 - I
max temperature 85°C
mounting hole 20x40 mm
for Food-service trolley (ALTO-SHAAM)



ALTO-SHAAM 5010847

3319431 BLACK SWITCH 20A 250V

with green led indicator lamp
mounting hole 20x40 mm
ON-OFF function



LINCOLN 369432

LINCOLN 369805



Switches



Suitable for:

3319378 BLACK THREE-POLE SWITCH 16A 250V
16(4)A 250V - with orange indicator lamp
max temperature 120°C
mounting hole 22x30 mm
for Display cabinet warm (CF CENEDESE)



CF CENEDESE 63.7.0863

Suitable for:

3319644 BLACK TWO-POLE PUSH-BUTTON 16A
with protection cap
mounting hole 13x20 mm



DESCO R_62240

DESCO 62240

3319374 BLACK TWO-POLE PUSH-BUTTON 16A 250V
16(4)A 250V - with protection cap
silk-screen printing "ignition"
max temperature 120°C
mounting hole 22x30 mm
for Rotisserie gas (CB) G-12P - G-20P - P10/4
P10/5 - P10/6 - P10/8 - P7/5



CB 07040002

3319054 BLACK TWO-POLE SWITCH 16A 250V
16(4)A 250V - with green led indicator lamp
silk-screen printing "gearmotor"
max temperature 120°C
mounting hole 22x30 mm
for Rotisserie electric (CB)
for Sausage grill electric (CB)



CB 07040519

3319055 BLACK TWO-POLE SWITCH 16A 250V
16(4)A 250V - with red led indicator lamp
silk-screen printing "heating element"
max temperature 120°C
mounting hole 22x30 mm
for Rotisserie electric (CB) E-12P - E-8P



CB 07042133

3319254 BLACK TWO-POLE SWITCH 16A 250V
16(4)A 250V - with protection cap
max temperature 120°C
mounting hole 22x30 mm



ARISTARCO 1

BOURGEOIS INT006

CB 07040032

3319376 BLACK BIPOLAR PUSH-BUTTON 16A 250V
16(4)A 250V - with push-button cap
temperature max. 120°C
mounting hole 22x30 mm



ANIMO 02523

CB 07040033



Suitable for:

Switches



Suitable for:

3319375 BLACK TWO-POLE SWITCH 16A 250V
 with protection cap
 "manual - automatic" silk-screen printing
 max temperature 120°C
 mounting hole 22x30 mm



CB 07040011

3319920 BLACK TWO-POLE SWITCH 16A 250V



ALPENINOX 0A8754
 DIHR 15812
 UNOX VE168

ANGELO PO 32W4150
 ELECTROLUX 0A8754
 WHIRLPOOL 208754

ARISTARCO 4323
 METOS 15812
 ZANUSSI 0A8754

3319923 BLACK/RED CAM



ALPENINOX 0A8272

ELECTROLUX 0A8272

ZANUSSI 0A8272

3319646 GREEN/ORANGE CAM



ANGELO PO 33Q6440
 METOS 15824
 OLIS

DIHR 15824/A
 METOS 15824/A

DIHR 15824
 METOS

3319733 BLACK UNIPOLAR PUSH-BUTTON
 mounting hole 14x17 mm
 for Kitchen (THIRODE) B7.FV.CF.FG
 for Panini grill (BONNET) LHBLOC
 for Pot stove (BONNET) B9FV800GAL



BONNET 300157
 WHIRLPOOL

BONNET 302556

HOBART 302556

3319504 BLACK 3 POLES PUSH-BUTTON 6A 250V
 for IGNITER
 with cap
 mounting hole 25x15 mm



MORICE DE0040-1



Switches



Suitable for:

3319923 BLACK/RED CAM



ALPENINOX 0A8272

ELECTROLUX 0A8272

ZANUSSI 0A8272

Suitable for:

3319767 BLUE BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator light
silk screen printing 0 - I
mounting hole 22x30 mm



5024456 BLUE MONOPOLAR SWITCH 16A 250V
for IGNITION
with push-button cover
mounting hole 13x20 mm
for Bratt pan (ANGELO PO) - Series ALPHA



ANGELO PO 3066000

ANGELO PO 6300674

3319271 BUTTON SUPPORT



REPAGAS 44700004

UNOX VE161

3319510 CONTACT NO 10A 400V



EBERHARDT 256338

MARENO CR0413790

MARENO 2860900

MORICE DE1108

NUOVA SIMONELLI 18010774

SILKO CRO413790

SILKO CR0413790

3319380 DOUBLE SINGLE POLE SWITCH 16A 250V
mounting hole 28x53 mm
for Toaster (SAMMIC) TP-10



SAMMIC 6100408

3319364 DOUBLE THREE-POLE SWITCH 16A 250V
16(4)A 250V - with yellow led indicator lamp
temperature max. 120°C
mounting hole 22x30 mm



FB FABA PR4G026

3319160 GREEN BIPOLAR PUSH-BUTTON 16A 250V
16(4)A 250V - with indicator lamp
flash silk-screen printing
temperature max 120°C
mounting hole 22x30 mm



ALPENINOX 056717

ELECTROLUX 056717

WHIRLPOOL 156717

ZANUSSI 056717



Suitable for:

Switches



3319267 GREEN BIPOLAR PUSH-BUTTON 16A 250V

16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



Suitable for:

3319362 GREEN BIPOLAR SWITCH 16A 250V

16(4)A 250V - with indicator lamp
silk-screen printing 0 - I
temperature max. 120°C
mounting hole 22x30 mm
for Rotisserie (ROTISOL) SM1650
for Rotisserie gas (ROTISOL) SM1150 - SM1400



BLANCO 105912
FB FABA PR60008
ROTISOL INTV2

BLANCO 106868
MORICE DE3055

FB FABA PR10007
RIEBER 33350211

3319423 GREEN BIPOLAR SWITCH 16A 24V

temperature max 120°C
mounting hole 22x30 mm
for Bratt pan (EMMEPI) - Series 750 - Series 900



EMMEPI C00610

3319012 GREEN BIPOLAR SWITCH 16A 250V

16(4)A 250V
with indicator light and switch cover
screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm



ABNER M110607
ANIMO 02294
BERTO'S 22056600
EBERHARDT 222094
LOTUS 537015500
MARENO 4640500
MODULAR 763.001.00
RIEBER 33350217
WHIRLPOOL 153810

ALPENINOX 053810
ARISTARCO 364
DESCO EL0006
FIMAR CO1038
LOTUS 537001700
METALCARRELLI R0056
MODULAR M561003500
TECNOINOX RC00004702

ANGELO PO 32W0631
ARISTARCO 2496
EBERHARDT 10402
GIGA X50800
MARENO MA4640500
METALCARRELLI R0096
RIEBER 33350207
TECNOINOX RC00021000

3319013 GREEN BIPOLAR SWITCH 16A 250V

16(4)A 250V
with indicator lamp and switch cover
"0 - II" symbol screenprinted
max temperature 120°C
mounting hole 22x30 mm



ALPENINOX 053837
WHIRLPOOL 153837

ELECTROLUX 053837
ZANUSSI 053837

WHIRLPOOL 771985002749

3319014 GREEN BIPOLAR SWITCH 16A 250V

16(4)A 250V
with indicator lamp and switch cover
"fan" symbol screenprinted
max temperature 120°C
mounting hole 22x30 mm



ALPENINOX 054552
WHIRLPOOL 154552

ELECTROLUX 054552
ZANUSSI 054552

WHIRLPOOL 771985002978



Switches



Suitable for:

3319029 GREEN BIPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



EMMEPI 818181

MARENO 21110199

ROLLER GRILL A07032

Suitable for:

3319090 GREEN BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator lamp and switch cover
max temperature 120°C
mounting hole 22x30 mm



DIHR 15048

METOS 15048

TECNOINOX RC00200000

LOTUS 537001700

OLIS

WHIRLPOOL 771985006346

METOS

ROSINOX RX94809514

WHIRLPOOL 310042

3319163 GREEN BIPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator lamp
flash silk-screen printing
temperature max 120°C
mounting hole 22x30 mm



3319346 GREEN BIPOLAR SWITCH 16A 250V
with indicator light
mounting hole 22x30 mm
for Food-service trolley (BLANCO) - Series SAG
Series SAW - Series STW



BLANCO 105798

JEMI 2002423

3319361 GREEN BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator light and button cap
mounting hole \varnothing 25 mm



METALCARRELLI R0097

RIEBER 33351502

METALCARRELLI 003252040002

METALCARRELLI 003252040002+...

3319151 SWITCH PROTECTION CAP
 \varnothing external 34 mm
for push-buttons with mounting hole \varnothing 25 mm
for Oven under cooktop gas (ZANUSSI) - Series R701
Series 700



ALPENINOX 053979

ELETTROBAR 410005

GIGA D410005

ZANUSSI 053979

DEXION

ERRE 2 55463001

WHIRLPOOL 771985002806

ELECTROLUX 053979

GICO 55463001

WHIRLPOOL 153979

3319461 GREEN BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator lamp and button protection cap
"lamp" silk-screen print
max temperature 120°C
mounting hole 22x30 mm



3319765 GREEN BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator light
silk screen printing 0 - I
mounting hole 22x30 mm





Suitable for:

Switches



3319928 GREEN BIPOLAR SWITCH 16A 250V
 16(4)A 250V - with indicator lamp
 max.temperature 120°C
 mounting hole ø 25 mm



ALPENINOX 054518
 GICO 5209201
 WHIRLPOOL 771985002968

EBERHARDT 220755
 GICO 52221025
 WHIRLPOOL 154518

ELECTROLUX 054518
 WHIRLPOOL 483286009938
 ZANUSSI 054518

3319151 SWITCH PROTECTION CAP
 ø external 34 mm
 for push-buttons with mounting hole ø 25 mm
 for Oven under cooktop gas (ZANUSSI) - Series R701
 Series 700



ALPENINOX 053979
 ELETTRORBAR 410005
 GIGA D410005
 ZANUSSI 053979

DEXION
 ERRE 2 55463001
 WHIRLPOOL 771985002806

ELECTROLUX 053979
 GICO 55463001
 WHIRLPOOL 153979

3319944 GREEN BIPOLAR SWITCH 16A 250V
 16(4)A 250V - with indicator light
 0-I silk-screen printing
 temperature max 120°C
 mounting hole 22x30 mm



ALPENINOX 056703
 FORVED TOSTINTER
 ROLLER GRILL A07032
 TECNOINOX RC00000210

ELECTROLUX 056703
 FRANKE 995257
 ROSINOX RX94805496
 WHIRLPOOL 483286011125

EMMEPI 712110000
 FRI FRI 400627
 SILKO 0109015
 ZANUSSI 056703

3319030 GREEN CHANGE OVER SWITCH 16A 250V
 16(4)A 250V - with indicator lamp
 max temperature 120°C
 mounting hole 22x30 mm



DOSILET 91037
 MARENO 4640400
 SILANOS 903613

MARENO MA21110299
 NUOVA SIMONELLI 18010053

MARENO 21110299
 SILANOS 903610

3319091 GREEN CHANGE OVER SWITCH 250V 16A
 16(4)A 250V
 with indicator lamp and button protection cap
 max temperature 120°C
 mounting hole 22x30 mm



DIHR 15050
 OLIS

METOS
 ROSINOX RX94809506

METOS 15050

3319306 GREEN DOUBLE SWITCH 16A 250V
 16(4)A 250V - with indicator lamp
 temperature max 100°C
 mounting hole 22x30 mm



ANIMO 02569

1319203 GREEN MONOPOLAR SWITCH 16A 250V
 16(4)A 250V - with indicator light
 silkscreen printing 0 - I
 temperature max 120°C
 mounting hole 11x30 mm



3319967 GREEN SINGLE-POLE SWITCH 16A 250V
 16(4)A 250V - max temperature 120°C
 mounting hole 11x30 mm



ALPENINOX 004110
 EMMEPI 809477
 ZANUSSI 004110

ELECTROLUX 004110
 FIMAR CO1269

EMMEPI 809478
 FRI FRI 400553



Switches



Suitable for:

Suitable for:

3319309 GREEN THREE-POLE SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 100°C
mounting hole 22x30 mm



3319360 GREEN THREE-POLE SWITCH 16A 250V

16(4)A 250V
with indicator lamp and button protection cap
silk-screen print 0 - I
mounting hole 11x30 mm
for Food-service trolley (RIEBER) - Series STW
Series ZUB



RIEBER 33350206

3186636 GASKET FOR SWITCH

inner size 22x32 mm
internal size 22x32 mm
for Food-service trolley (RIEBER) BKW1 - BKW2



RIEBER 37280601

3319322 GREEN TWO-POLE PUSH-BUTTON 16A 250V

16(4)A 250V - silk-screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm



MARENO

1319202 GREEN TWO-POLE SWITCH 16A 250V

16(4)A 250V - with indicator lamp
silk-screen printing 0 - I
temperature max 120°C
mounting hole 22x30 mm
for Hood electric (MORETTI) TIVOLI KAPPA



ALPENINOX 056703

DESCO 01382

ELECTROLUX 056703

ZANUSSI 056703

ALPENINOX 081680

DOSILET 400007010

ELECTROLUX 081680

ZANUSSI 081680

AMBACH 5060903316

EBERHARDT 220707

WHIRLPOOL 771985010330

3319369 GREEN TWO-POLE SWITCH 16A 250V

with indicator lamp and protection cap
mounting hole \varnothing 38 mm



MOBILE CONTAINING 957035

3319464 GREEN TWO-POLE SWITCH 16A 250V

16(4)A 250V
with indicator lamp and protection cap
silk-screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm



CB 07040015

FORCAR SL0621

LOWERATOR 105778



Suitable for:

3319430 GREY TWO-POLE SWITCH 10A 250V
mounting hole 20x40 mm



GARLAND 2343500

3319545 LEVER SWITCH 10A 250V
threaded coupling \varnothing 12 mm
ON-OFF function



PITCO FRIALATOR P5047162

3319546 LEVER SWITCH 20A 250V
threaded coupling \varnothing 12 mm
ON-OFF-MOM ON function



PITCO FRIALATOR P5047164

3319266 ORANGE BIPOLAR PUSH-BUTTON 16A 250V
16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



Switches



Suitable for:

3319388 GREY TWO-POLE SWITCH 16A 380V
with red indicator light
silk-screen printing 0 - I
mounting hole 30x50 mm
for Hot cupboard electric (REPAGAS) AC-127
AC-167 - AM-127 - AM-167



REPAGAS 25305011

3319503 LEVER SWITCH 20A 250V
threaded coupling \varnothing 12 mm
function ON-OFF-ON



PITCO FRIALATOR P5047165

3319505 ON-OFF PLUG WITH SWITCH 10A 250V
built-in plug
mounting hole 27x42 mm



MORICE DE0206

MORICE DE0836

3319035 ORANGE BIPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



MARENO 21110399



Switches



Suitable for:

Suitable for:

3319088 ORANGE BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator lamp and push-button cover
temperature max 120°C
mounting hole 22x30 mm



ALPENINOX 056878
ARISTARCO 1146
ELECTROLUX 056880
ZANUSSI 056878

ALPENINOX 056879
ELECTROLUX 056878
SAMMIC 2306538
ZANUSSI 056879

ALPENINOX 056880
ELECTROLUX 056879
WHIRLPOOL 771985003416
ZANUSSI 056880

3319308 ORANGE BIPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator lamp
max temperature 100°C
mounting hole 22x30 mm



ANIMO 02567

3319320 ORANGE BIPOLAR SWITCH 16A 250V
silk-screen printing 0 - I
mounting hole 13x20 mm



BLANCO 105674

LOWERATOR 105674

3319514 ORANGE BIPOLAR SWITCH 16A 250V
with indicator light and push-button cover
silk-screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm



3319764 ORANGE BIPOLAR SWITCH 16A 250V
16(4)A 250V
with indicator light
silk screen printing 0 - I
mounting hole 22x30 mm



3319934 ORANGE BIPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator lamp
0-1 silk-screen printing
max temperature 120°C
mounting hole 22x30 mm



EDESA 6021130001
FAGOR 6001507003

FAGOR Z203003000
FAGOR 6021130001

FAGOR Z203003000
NUOVA SIMONELLI 15010045

3319261 ORANGE CHANGE OVER SWITCH 16A 250V
16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



1319204 ORANGE MONOPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator light
silkscreen printing 0 - I
temperature max 120°C
mounting hole 11x30 mm



MILAN TOAST 12285



Suitable for:

Switches



3319762 ORANGE SINGLE-POLE PUSH-BUTTON 16A 12V

with indicator light
max temperature 120°C
mounting hole 22x30 mm



Suitable for:

3319056 ORANGE TWO-POLE SWITCH 16A 250V

16(4)A 250V - with indicator lamp
with silk-screen printing "lamp"
max temperature 120°C
mounting hole 22x30 mm
for Rotisserie
for Self service counter



3319512 ORANGE TWO-POLE SWITCH 16A 250V

16(4)A 250V - with indicator lamp
silk-screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm
for Rotisserie (ROTISOL) SM1650
for Rotisserie electric (ROTISOL) - Series FBP
for Rotisserie gas (ROTISOL) SM1150 - SM1400



3452004 PROTECTION SWITCH COVER

for switches
for Bain-marie electric (CAPIC) W338010
for Fryer (CAPIC) AM11



ROTISOL INT02

CAPIC E053532

3319297 PUSH-BUTTON EXTENSION

external ø 7 mm
for circuit boards



3319015 RED BIPOLAR PUSH BUTTON 16A 250V

16(4)A 250V - with indicator lamp
silk-screen print 0 - I
max temperature 120°C
mounting hole 22x30 mm



ALPENINOX 002670
ZANUSSI 002670

ELECTROLUX 002670

WHIRLPOOL 771985000156

ALPENINOX 005899
EMMEPI 8C0961

ATA 1085
ZANUSSI 005899

ELECTROLUX 005899

1319612 RED BIPOLAR SWITCH 16A 250V

16(4)A 250V - with indicator light
silk-screen printing "flash"
temperature max 120°C
mounting hole 22x30 mm
for Pot stove electric (LOTUS) - Series 600
Series 650



3319019 RED BIPOLAR SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



LOTUS 537015600

FOEMM 05000078750

FOEMM 305000046250

NUOVA SIMONELLI 04200011



Switches



Suitable for:

3319763 RED BIPOLAR SWITCH 16A 250V

16(4)A 250V
with indicator light
silk screen printing 0 - I
mounting hole 22x30 mm



Suitable for:

3319947 RED BIPOLAR SWITCH 16A 250V

16(4)A 250V
with indicator light and push-button cap
max temperature 100°C
mounting hole 22x30 mm



MBM RTTAV00039

3319948 RED BIPOLAR SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max. temperature 120°C
mounting hole ø 25 mm



MBM RTFOC00585

NUOVA SIMONELLI 04200039

3319151 SWITCH PROTECTION CAP

ø external 34 mm
for push-buttons with mounting hole ø 25 mm
for Oven under cooktop gas (ZANUSSI) - Series R701
Series 700



ALPENINOX 053979

ELETTROBAR 410005

GIGA D410005

ZANUSSI 053979

DEXION

ERRE 2 55463001

WHIRLPOOL 771985002806

ELECTROLUX 053979

GICO 55463001

WHIRLPOOL 153979

3319018 RED CHANGE OVER SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



ATA 1087

3319304 RED DOUBLE SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 100°C
mounting hole 22x30 mm
for Toaster electric (CF CENEDESE) T920 - T930



CF CENEDESE 63.7.0852

3319756 RED MONOPOLAR SWITCH 16A 250V

16(4)A 250V - with indicator light
silk-screen printing 0 - I
max temperature 120°C
mounting holes 11x30 mm



4059843 RED PUSH BUTTON WITH BLOCK

1 NC contact
mounting hole ø 22 mm
for BRATT PAN



ALPENINOX 0A2196

ELECTROLUX 059843

ALPENINOX 059843

ZANUSSI 0A2196

ELECTROLUX 0A2196

ZANUSSI 059843



Suitable for:

Switches



3319732 RED PUSH-BUTTON COMPLETE 8A 250V
for Boiling pan gas (CHARVET) PRO900G1MF



AMBASSADE 03967A

CHARVET 03967A

Suitable for:

3319969 RED SINGLE POLE SWITCH 16A 250V
16(4)A 250V - max temperature 120°C
mounting hole 11x30 mm



ROLLER GRILL A07012

3319155 RED SINGLE-POLE PUSH-BUTTON 16A 250V
16(4)A 250V - with button protection cap
with indicator lamp
mounting hole \varnothing 25 mm



3319151 SWITCH PROTECTION CAP
 \varnothing external 34 mm
for push-buttons with mounting hole \varnothing 25 mm
for Oven under cooktop gas (ZANUSSI) - Series R701
Series 700



ALPENINOX 053979
ELETTOBAR 410005
GIGA D410005
ZANUSSI 053979

DEXION
ERRE 2 55463001
WHIRLPOOL 771985002806

ELECTROLUX 053979
GICO 55463001
WHIRLPOOL 153979

3319372 RED SINGLE-POLE PUSH-BUTTON 16A 250V
for IGNITION
with protection cap
mounting hole 13x20 mm
for Bain-marie gas (ANGELO PO) - Series ALPHA
for Fry top gas (ANGELO PO) - Series ALPHA
for Fryer gas (ANGELO PO) - Series ALPHA
for Grill gas (ANGELO PO) - Series ALPHA
for Pasta cooker gas (ANGELO PO) - Series ALPHA
for Pot stove gas (ANGELO PO) - Series ALPHA



ANGELO PO 3062550
DESCO 61286

ANGELO PO 3126060+3126050

ANGELO PO 6300676



Switches



Suitable for:

Suitable for:

3319373 RED SINGLE-POLE PUSH-BUTTON 16A 250V
 for IGNITION
 with protection cap
 silk-screen printing "lightning"
 max temperature 120°C
 mounting hole \varnothing 25 mm
 for Pot stove gas (BARON) - Series 1100
 Series 1400 - Series 700 - Series 900
 for Pot stove gas (OLIS) - Series 1100
 Series 1400 - Series 700 - Series 900

3319151 SWITCH PROTECTION CAP
 \varnothing external 34 mm
 for push-buttons with mounting hole \varnothing 25 mm
 for Oven under cooktop gas (ZANUSSI) - Series R701
 Series 700



BARON BN826630050
 EMMEPI 244230001

BARON 826630050
 METOS 2510607

BARTSCHER 016148
 OLIS 2510607

ALPENINOX 053979
 ELETTROBAR 410005
 GIGA D410005
 ZANUSSI 053979

DEXION
 ERRE 2 55463001
 WHIRLPOOL 771985002806

ELECTROLUX 053979
 GICO 55463001
 WHIRLPOOL 153979

3319429 RED SINGLE-POLE PUSH-BUTTON 16A 250V
 for IGNITER
 silk-screen printing "lightning"
 max temperature 120°C
 mounting hole 22x30 mm




GARLAND 2200300

3319498 RED STOP PUSH-BUTTON
 traction reset
 dimensions 70x80x55 mm




3319500 "EMERGENCY STOP" PLATE



3319499 RED STOP PUSH-BUTTON
 key reset
 dimensions 70x80x55 mm



3319500 "EMERGENCY STOP" PLATE





Suitable for:

Switches



Suitable for:

3319731 RED SWITCH 1-POLE 230V
 with indicator lamp
 mounting hole 17x12 mm
 for Bain-marie electric (CAPIC) W338010
 for Fryer (CAPIC) AM11



CAPIC E053530

3319139 RED THREE-POLE SWITCH 16A 250V
 16(4)A 250V
 with indicator lamp and button protection cap
 max temperature 120°C
 mounting hole 11x30 mm
 for Toaster electric (VEMA) FO2069



ANIMO 02865

VEMA XRFO1

3186636 GASKET FOR SWITCH
 inner size 22x32 mm
 internal size 22x32 mm
 for Food-service trolley (RIEBER) BKW1 - BKW2



RIEBER 37280601

3319307 RED THREE-POLE SWITCH 16A 250V
 16(4)A 250V - with indicator lamp
 max temperature 100°C
 mounting hole 22x30 mm



3319011 RED TWO-POLE PUSH-BUTTON 16A 250V
 16(4)A 250V - normally closed
 with indicator lamp and push-button cap
 max temperature 120°C
 mounting hole 22x30 mm



ALPENINOX 054547
 ELECTROLUX 055014
 WHIRLPOOL 154547
 ZANUSSI 055014

ALPENINOX 055014
 WHIRLPOOL 771985002977
 WHIRLPOOL 155014

ELECTROLUX 054547
 WHIRLPOOL 771985003069
 ZANUSSI 054547

3319270 RED UNIPOLAR PUSH-BUTTON 3A 250V
 with protection cap
 mounting hole \varnothing 16 mm
 for Pot stove electric (ZANUSSI)



ALPENINOX 002418
 EMMEPI 809886
 ZANUSSI 002418

AMBACH 5018609593
 WHIRLPOOL 771985000077

ELECTROLUX 002418
 WHIRLPOOL 102418

3319381 SINGLE-POLE BLACK PUSH-BUTTON 16A 250V
 with switch cover
 "double arrow" silkscreen printing
 temperature max 120°C
 mounting hole 22x30 mm
 for Bratt pan electric (FAGOR) - Series SBE
 for Bratt pan gas (FAGOR) - Series SBG



FAGOR X343002000



Switches



Suitable for:

3210010 SINGLE-POLE INSTANTANEOUS SWITCH 10A 250

lever-operated
threaded coupling \varnothing 12 mm
MOM-OFF-MOM function



Suitable for:

3210013 SINGLE-POLE LEVER SWITCH 15A 250V

2 positions
threaded coupling \varnothing 12 mm
ON-OFF-ON function




3319508 SINGLE-POLE LEVER SWITCH 15A 250V

with plate
threaded coupling \varnothing 12 mm
ON-OFF function



1319082 SINGLE-POLE PUSH BUTTON 16A 250V



MORICE DE0206(250V)

ANGELO PO 3040850

ARISTARCO 4322

DIHR 15813

ELFRAMO 28160253

EMMEPI 244230101

KOMEL 28160253

METOS 15813

ROSINOX RX94813820

ROSINOX RX94810898

SILANOS 905343

UNOX VE169

3319921 SINGLE-POLE SWITCH 16A 250V



3319923 BLACK/RED CAM



ALPENINOX 0A8274
ZANUSSI 0A8274

ARISTARCO 6992

ELECTROLUX 0A8274

ALPENINOX 0A8272

ELECTROLUX 0A8272

ZANUSSI 0A8272

3319686 START-STOP STRIP for lever switches-reversers



3319509 START-STOP SWITCH CASE



MORICE DE1091

3319510 CONTACT NO 10A 400V



EBERHARDT 256338

MARENO CR0413790

MARENO 2860900

MORICE DE1108

NUOVA SIMONELLI 18010774

SILKO CRO413790

SILKO CR0413790



Suitable for:

3319685 SWITCH CAP
for lever switches-reversers



Switches



Suitable for:

3319151 SWITCH PROTECTION CAP
ø external 34 mm
for push-buttons with mounting hole ø 25 mm
for Oven under cooktop gas (ZANUSSI) - Series R701
Series 700



ALPENINOX 053979
ELETTROBAR 410005
GIGA D410005
ZANUSSI 053979

DEXION
ERRE 2 55463001
WHIRLPOOL 771985002806

ELECTROLUX 053979
GICO 55463001
WHIRLPOOL 153979

3319501 SWITCH PROTECTION CAP
external dimensions 29x36 mm
for switches with mounting hole 22x30 mm



FRI FRI 400647

TECNOINOX

3210012 THREE-POLE INSTANT. REVERSER 10A 250V
lever-operated
threaded coupling ø 12 mm
MOM-OFF-MOM function



3210015 THREE-POLE LEVER REVERSER 15A 250V
2 positions
threaded coupling ø 12 mm
ON-OFF-ON function



3319477 THREE-POLE LEVER SWITCH 17A 277V
threaded coupling ø 12 mm
ON-OFF function
for Display cabinet warm (HENNY PENNY) CW114
CW216 - HCS5 - HCW5 - HCW8



HENNY PENNY HP22604

3319383 THREE-POLE SWITCH 16A 250V
for Bratt pan (FAGOR) SBG-915IMBP



ELFRAMO 28160275

FAGOR X022109000

KOMEL 28160275

3319379 TRIPLE SINGLE POLE SWITCH 16A 250V
mounting hole 28x77 mm
for Toaster (SAMMIC) TP-20



SAMMIC 6100410



Suitable for:

3210011 TWO-POLE INSTANTANEOUS REVERSER 10A 250V

lever-operated
threaded coupling \varnothing 12 mm
MOM-OFF-MOM function



Suitable for:

3210014 TWO-POLE LEVER REVERSER 15A 250V

2 positions
threaded coupling \varnothing 12 mm
ON-OFF-ON function



3319714 TWO-POLE LEVER SWITCH 16A 250V

threaded coupling \varnothing 12 mm
ON-OFF function
for Bain-marie electric (ROSINOX) BME1/1



3319686 START-STOP STRIP

for lever switches-reversers



ALTO-SHAAM SW3528

ROSINOX RX94026036


3319685 SWITCH CAP

for lever switches-reversers



3319730 UNIPOLAR PUSH-BUTTON COMPLETE

\varnothing 26 mm - total length 45 mm
for Bratt pan gas (THIRODE) B9PSA50G



3319268 WHITE BIPOLAR PUSH-BUTTON 16A 250V

16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



THIRODE 133410

1319210 WHITE BIPOLAR SWITCH 16A 250V

with indicator light and push-button cap
silk-screen print 0-1
temperature max 120°C
mounting hole 22x30



3319251 WHITE BIPOLAR SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



SAMMIC 2310416



Suitable for:

Switches



3319262 WHITE CHANGE OVER SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



Suitable for:

3319390 WHITE PUSH-BUTTON 16A 250V

with protection cap
1 contact NO
with cover for button
silkscreen "arrow"
mounting hole \varnothing 22 mm
for Bratt pan (JEMI) - Series 900



JEMI 240073

3319305 YELLOW DOUBLE SWITCH 16A 250V

16(4)A 250V - with indicator lamp
max temperature 100°C
mounting hole 22x30 mm

